

Get great detail
in your subjects!

Canon EOS Rebel T3i/600D

From Snapshots to Great Shots

Learn the best
ways to compose
your pictures!

Jeff Revell

Canon EOS Rebel T3i/600D:
From
Snapshots to
Great Shots

Jeff Revell



Canon EOS Rebel T3i / 600D: From Snapshots to Great Shots
Jeff Revell

Peachpit Press
1249 Eighth Street
Berkeley, CA 94710
510/524-2178
510/524-2221 (fax)

Find us on the Web at www.peachpit.com
To report errors, please send a note to errata@peachpit.com
Peachpit Press is a division of Pearson Education

Copyright © 2011 by Peachpit Press
All photography © Jeff Revell except where noted
Camera provided to author by B&H Photo (www.bhphotovideo.com)

Editor: Ted Waitt
Production Editor: Lisa Brazieal
Interior Design: Riezebos Holzbaur Design Group
Compositor: WolfsonDesign
Indexer: James Minkin
Cover Design: Aren Howell
Cover Image: Jeff Revell
Back Cover Author Photo: Scott Kelby

Notice of Rights

All rights reserved. No part of this book may be reproduced or transmitted in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. For information on getting permission reprints and excerpts, contact permissions@peachpit.com.

Notice of Liability

The information in this book is distributed on an "As Is" basis without warranty. While every precaution has been taken in the preparation of the book, neither the author nor Peachpit shall have any liability to any person or entity with respect to any loss or damage caused or alleged to be caused directly or indirectly by the instructions contained in this book or by the computer software and hardware products described in it.

Trademarks

All Canon products are trademarks or registered trademarks of Canon Inc.
Many of the designations used by manufacturers and sellers to distinguish their products are claimed as trademarks. Where those designations appear in this book, and Peachpit was aware of a trademark claim, the designations appear as requested by the owner of the trademark. All other product names and services identified throughout this book are used in editorial fashion only and for the benefit of such companies with no intention of infringement of the trademark. No such use, or the use of any trade name, is intended to convey endorsement or other affiliation with this book.

ISBN-13 978-0-321-77664-8

ISBN-10 0-321-77664-X

9 8 7 6 5 4 3 2 1

Printed and bound in the United States of America

DEDICATION

For all my friends at Kelby Media Group for their continuous friendship and inspiration—Scott Kelby, Dave Moser, Matt Kloskowski, RC Concepcion, Kathy Siler, and Brad Moore.

ACKNOWLEDGMENTS

Even though I have written plenty of books for this series (this makes number eight), the experience is always a little new. Just the other day I had a friend ask me if I wasn't tired of writing camera books, and the answer was a resounding, "No!" I love new cameras and photography gear, in general, and writing these books allows me to really get in-depth with the latest technology and see how it is shaping the photography of tomorrow. Of course I couldn't do that without the help of some great people like the ones at Peachpit Press. With the talents (and patience) of people like my editor Ted Waitt, production editor Lisa Brazieal, and all the other wonderful people who put this book together, we have continued to improve with every new edition.

And while the publisher and author have a big part in bringing you this book, none of it would have happened without the assistance of my friends at B&H Photo. They worked with me to ensure that I had a brand new camera in hand as soon as they started arriving on our shores. Of course, this doesn't surprise me at all because I have been purchasing photography equipment from them for years; I can say without a doubt that they are fantastic at what they do. They are always courteous and helpful, their knowledge is second to none, and they always give me a great deal. They are my number one go-to resource for anything photographic, so check them out on the web when you get the chance: www.bhphotovideo.com.



Contents

INTRODUCTION	viii
CHAPTER 1: THE T3i TOP TEN LIST	1
Ten Tips to Make Your Shooting More Productive Right Out of the Box	1
Poring Over the Camera	2
Poring Over the Camera	4
1. Charge Your Battery	5
2. Turn Off the Release Shutter without Card Setting	6
3. Set Your JPEG Image Quality	7
4. Turn Off the Auto ISO Setting	8
5. Setting Your Focus Point and Mode	10
6. Set the Correct White Balance	12
7. Adjust the Viewfinder Diopter	15
8. Know How to Override Autofocus	15
9. Review Your Shots	16
10. Hold Your Camera for Proper Shooting	22
Chapter 1 Assignments	23
CHAPTER 2: FIRST THINGS FIRST	25
A Few Things to Know and Do Before You Begin Taking Pictures	25
Poring Over the Picture	26
Poring Over the Picture	28
Choosing the Right Memory Card	30
Formatting Your Memory Card	31
Updating the T3i's Firmware	33
Cleaning the Sensor	36
Using the Right Format: RAW vs. JPEG	38
Lenses and Focal Lengths	40
What Is Exposure?	46
Motion and Depth of Field	49
Video and the T3i	52
Chapter 2 Assignments	59

CHAPTER 3: THE BASIC ZONE	61
Get Shooting with the Automatic Camera Modes	61
Poring Over the Picture	62
Poring Over the Picture	64
Scene Intelligent Auto Mode	66
Portrait Mode	67
Landscape Mode	69
Close-up Mode	70
Sports Mode	71
Night Portrait Mode	72
Flash Off Mode	73
Creative Auto Mode	75
Why You May Never Want to Use the Basic Zone Again	78
Chapter 3 Assignments	79
CHAPTER 4: THE CREATIVE ZONE	81
Taking Your Photography to the Next Level	81
Poring Over the Picture	82
Poring Over the Picture	84
P: Program Mode	86
Tv: Shutter Priority Mode	89
Av: Aperture Priority Mode	93
M: Manual Mode	98
A-DEP: Auto Depth of Field Mode	101
How I Shoot: A Closer Look at the Camera Settings I Use	103
Chapter 4 Assignments	104
CHAPTER 5: MOVING TARGET	107
The Tricks to Shooting Sports and More	107
Poring Over the Picture	108
Poring Over the Picture	110
Stop Right There!	112
Using Shutter Priority (Tv) Mode to Stop Motion	117
Using Aperture Priority (Av) Mode to Isolate Your Subject	119
Keep Them in Focus with AI Servo and Auto AF Focus Point Selection	120
Stop and Go with AI Focus AF	122
Manual Focus for Anticipated Action	123
Keeping Up with the Continuous Shooting Mode	125
A Sense of Motion	126
Tips for Shooting Action	128
Chapter 5 Assignments	130

CHAPTER 6: SAY CHEESE!	133
Settings and Features to Make Great Portraits	133
Poring Over the Picture	134
Poring Over the Picture	136
Automatic Portrait Mode	138
Using Aperture Priority Mode	138
Metering Modes for Portraits	141
Using the AE Lock Feature	143
Focusing: The Eyes Have It	144
Classic Black and White Portraits	146
The Portrait Picture Style for Better Skin Tones	149
Detect Faces with Live View	150
Use Fill Flash for Reducing Shadows	153
People on the Move	154
Tips for Shooting Better Portraits	155
Chapter 6 Assignments	163
CHAPTER 7: LANDSCAPE PHOTOGRAPHY	165
Tips, Tools, and Techniques to Get the Most Out of Your Landscape Photography	165
Poring Over the Picture	166
Poring Over the Picture	168
Sharp and In Focus: Using Tripods	170
Using A-DEP to Maximize Depth of Field	172
Selecting the Proper ISO	173
Using Noise Reduction	175
Selecting a White Balance	176
Using the Landscape Picture Style	177
Taming Bright Skies with Exposure Compensation	179
Shooting Beautiful Black and White Landscapes	181
The Golden Light	183
Where to Focus	184
Easier Focusing	186
Making Water Fluid	188
Directing the Viewer: A Word about Composition	190
Advanced Techniques to Explore	194
Chapter 7 Assignments	201
CHAPTER 8: MOOD LIGHTING	203
Shooting When the Lights Get Low	203
Poring Over the Picture	204
Poring Over the Picture	206

Raising the ISO: The Simple Solution	208
Using Very High ISOs	210
Stabilizing the Situation	211
Focusing in Low Light	215
Shooting Long Exposures	217
Using the Built-In Flash	218
Compensating for the Flash Exposure	222
Reducing Red-Eye	224
2nd Curtain Sync	226
Using an External Speedlite	229
Chapter 8 Assignments	233
CHAPTER 9: CREATIVE COMPOSITIONS	235
Improve Your Pictures with Sound Compositional Elements	235
Poring Over the Picture	236
Poring Over the Picture	238
Depth of Field	240
Angles	242
Point of View	243
Patterns	244
Color	244
Contrast	245
Leading Lines	247
Splitting the Frame	247
Chapter 9 Assignments	249
CHAPTER 10: ADVANCED TECHNIQUES	251
Impress Your Family and Friends	251
Poring Over the Picture	252
Spot Meter for More Exposure Control	254
Manual Mode	258
Avoiding Lens Flare	260
Using the Sun Creatively	260
Bracketing Exposures	262
Macro Photography	265
Auto Lighting Optimizer	266
The My Menu setting	267
Customize Your White Balance	268
Shooting Through Obstructions	270
Conclusion	272
Chapter 10 Assignments	273
INDEX	274

Introduction

Walk into any bookseller, go to the photography section, and you will see countless books on the subject of photography. Look a little further and you will locate the camera-specific books. It is this divide between the camera-specific and instructional photography books that inspired me to write this book. What I was seeing in the store was a lot of books that were just sort of missing the mark—especially when it came to using a specific brand and model of camera along with actual photographic instruction. So with that, I set about to write this book on the Canon T3i, not as a rehash of the owner's manual but as a resource to teach photography with the wonderful technology present in the T3i. I have put together a short Q&A to help you get a better understanding of just what it is that you can expect from this book.

Q: IS EVERY CAMERA FEATURE GOING TO BE COVERED?

A: Nope, just the ones I felt you need to know about in order to start taking great photos. Believe it or not, you already own a great resource that covers every feature of your camera: the owner's manual. Writing a book that just repeats this information would have been a waste of my time and your money. What I did want to write about was how to harness certain camera features to the benefit of your photography. As you read through the book, you will also see callouts that point you to specific pages in your owner's manual that are related to the topic being discussed. For example, in Chapter 6 I discuss the use of the AE-L button but there is more information available on this feature in the manual. I cover the function that applies to our specific needs but also give you the page numbers in the manual to explore this function even further.

Q: SO IF I ALREADY OWN THE MANUAL, WHY DO I NEED THIS BOOK?

A: The manual does a pretty good job of telling you how to use a feature or turn it on in the menus, but it doesn't necessarily tell you *why* and *when* you should use it. If you really want to improve your photography, you need to know the whys and whens to put all of those great camera features to use at the right time. To that extent, the manual just isn't going to cut it. It is, however, a great resource on the camera's features, and it is for that reason that I treat it like a companion to this book. You already own it, so why not get something of value from it?

Q: WHAT CAN I EXPECT TO LEARN FROM THIS BOOK?

A: Hopefully, you will learn how to take great photographs. My goal, and the reason the book is laid out the way it is, is to guide you through the basics of photography as they relate to different situations and scenarios. By using the features of your T3i and this book, you will learn about aperture, shutter speed, ISO, lens selection, depth of field, and many other photographic concepts. You will also find plenty of large full-page photos that include captions, shooting data, and callouts so you can see how all of the photography fundamentals come together to make great images. All the while, you will be learning how your camera works and how to apply its functions and features to your photography.

Q: WHAT ARE THE ASSIGNMENTS ALL ABOUT?

A: At the end of most of the chapters, you will find shooting assignments, where I give you some suggestions as to how you can apply the lessons of the chapter to help reinforce everything you just learned. Let's face it—using the camera is much more fun than reading about it, so the assignments are a way of taking a little break after each chapter and having some fun.

Q: SHOULD I READ THE BOOK STRAIGHT THROUGH OR CAN I SKIP AROUND FROM CHAPTER TO CHAPTER?

A: Here's the easy answer: yes and no. No, because the first four chapters give you the basic information that you need to know about your camera. These are the building blocks for using the camera. After that, yes, you can move around the book as you see fit because the later chapters are written to stand on their own as guides to specific types of photography or shooting situations. You can bounce from portraits to shooting landscapes and then maybe to a little action photography. It's all about your needs and how you want to address them. Or, you can read it straight through. The choice is up to you.

Q: I DON'T SEE ANY CHAPTERS DEVOTED TO VIDEO.

A: I know that one of the reasons you probably bought the T3i was its ability to capture video. I have covered some basic video setup information in Chapter 2 but I really wanted the focus of this book to center around the photographic capabilities and possibilities. Don't worry, though; read the next Q&A and I think you will be happy.

Q: IS THERE ANYTHING ELSE I SHOULD KNOW BEFORE GETTING STARTED?

A: In order to keep the book short and focused, I had to be pretty selective about what I put in each chapter. The problem is that there is a little more information that might come in handy after you've gone through all the chapters. So as an added value for you, I have written two bonus chapters called "Pimp My Ride" and "T3i Video: Beyond the Basics." The first chapter is full of information on photo accessories that will assist you in making better photographs. In it, you will find my recommendation for things like filters, tripods, and much more. The second chapter will lead you through some video tips and techniques to make your T3i movies even better. To access the bonus chapters, just log in or join peachpit.com (it's free), then enter the book's ISBN. After you register the book, a link to the bonus chapters will be listed on your Account page under Registered Products.

Q: IS THAT IT?

A: One last thought before you dive into the first chapter. My goal in writing this book has been to give you a resource that you can turn to for creating great photographs with your Canon T3i. Take some time to learn the basics and then put them to use. Photography, like most things, takes time to master and requires practice. I have been a photographer for 30 years and I'm still learning. Always remember, it's not the camera but the person using it who makes beautiful photographs. Have fun, make mistakes, and then learn from them. In no time, I'm sure you will transition from a person who takes snapshots to a photographer who makes great shots.

4

ISO 400
1/160 sec.
f/5.6
55mm lens





The Creative Zone

TAKING YOUR PHOTOGRAPHY TO THE NEXT LEVEL

The Creative zone is the name given by Canon to the shooting modes that offer you the greatest amount of control over your photography. To anyone who has been involved with photography for any period of time, these modes are known as the backbones of photography. They allow you to influence two of the most important factors for taking great photographs: *aperture* and *shutter speed*. To access these modes, you simply turn the Mode dial to the Creative mode of your choice and begin shooting. But wouldn't it be nice to know exactly what those modes control and how to make them do our bidding? Well, if you really want to take that next step in controlling your photography, it is essential that you understand not only how to control these modes, but why and when to adjust them so that you get the results you want. So let's move that Mode dial to the first of our Creative modes: Program mode.

PORING OVER THE PICTURE

It was a late summer day with a bright sun setting at my back, so a fairly low ISO of 400 still allowed for fast shutter speeds.

Because I was more concerned with motion rather than depth of field, I used the Tv (Shutter Priority) shooting mode.



One of my most anticipated summer activities is the motocross jumping event at my county fair. Each year, the motocross daredevils launch their bikes some 30–40 feet into the air while performing amazing acrobatic moves and then landing on a ramp that seems much too small for its task. And I am there to capture it all with a long lens and a fast shutter speed.



● The drive mode was set to Continuous so the camera could fire more than one shot.

● AI Servo focus helped lock the focus and then follow my subjects, so as I shot, everything stayed sharp.

ISO 400
1/2000 sec.
f/2.8
300mm lens


PORING OVER THE PICTURE

I know it's not really manly but I have to tell you, I have a thing for flowers. I'm not much into growing them or having them around the house; I prefer to photograph them. With so many varieties and ways of lighting and photographing them, they are always presenting me with new challenges. One of my favorite varieties to photograph is the orchid. This bunch, grown by a friend, was bursting with color and crying out to be shot, so I just had to oblige.

Although I was using a fairly fast shutter speed, I still used a tripod to eliminate any possibility of shake from handholding the camera.

It took several shots to get an accurate exposure since the dark flowers and background were fooling the camera's light meter.





I used the selective focus point to get the camera to focus on just the right spot without having to move the camera.

A black background was placed in the back to keep the emphasis on the flowers.

ISO 100
1/125 sec.
f/13
105mm lens

P: PROGRAM MODE



There is a reason that Program mode is only one click away from the Basic modes: with respect to apertures and shutter speeds, the camera is doing most of the thinking for you. So, if that is the case, why even bother with Program mode? First, let me say that it is very rare that I will use Program mode because it just doesn't give as much control over the image-making process as the other Creative modes. There are occasions, however, when it comes in handy, like when I am shooting in widely changing lighting conditions and I don't have the time to think through all of my options, or I'm not very concerned with having ultimate control of the scene. Think of a picnic outdoors in a partial shade/sun environment. I want great-looking pictures, but I'm not looking for anything to hang in a museum. If that's the scenario, why choose Program over one of the Basic modes? Because it gives me choices and control that none of the Basic modes, including Creative Auto, can deliver.

Manual Callout

To see a comparison of all of the different modes in the Basic and Creative zones, check out the tables on pages 268–269 of your owner's manual.

WHEN TO USE PROGRAM (P) MODE INSTEAD OF THE BASIC ZONE MODES

- When shooting in a casual environment where quick adjustments are needed
- When you want control over the ISO
- If you want or need to shoot in the Adobe RGB color space
- If you want to make corrections to the white balance

Let's go back to our picnic scenario. As I said, the light is moving from deep shadow to bright sunlight, which means that the camera is trying to balance our three photo factors (ISO, aperture, and shutter speed) to make a good exposure. From Chapter 1, we know that Auto ISO is just not a consideration, so we have already turned that feature off (you did change it, didn't you?). Well, in Program mode, you can choose which ISO you would like the camera to base its exposure on. The lower the ISO number, the better the quality of our photographs, but the less light sensitive the camera becomes. It's a balancing act with the main goal always being to keep the ISO as low as possible—too low an ISO, and we will get camera shake in our images from a long shutter speed; and too high an ISO means we will have an unacceptable amount of

digital noise. For our purposes, let's go ahead and select ISO 400 so that we provide enough sensitivity for those shadows while allowing the camera to use shutter speeds that are fast enough to stop motion.

STARTING POINTS FOR ISO SELECTION

There is a lot of discussion concerning ISO in this and other chapters, but it might be helpful if you know where your starting points should be for your ISO settings. The first thing you should always try to do is use the lowest possible ISO setting. That being said, here are some good starting points for your ISO settings:

- 100: Bright sunny day
- 200: Hazy or outdoor shade on a sunny day
- 400: Indoor lighting at night or cloudy conditions outside
- 800: Late night, low-light conditions or sporting arenas at night

These are just suggestions and your ISO selection will depend on a number of factors that will be discussed later in the book. You might have to push your ISO even higher as needed, but at least now you know where to start.

With the ISO selected, we can now make use of the other controls built into Program mode. By rotating the Main dial, we now have the ability to shift the program settings. Remember, your camera is using the internal light meter to pick what it believes are suitable exposure values, but sometimes it doesn't know what it's looking at and how you want those values applied (**Figures 4.1** and **4.2**). With the program shift, you can influence what the shot will look like. Do you need faster shutter speeds in order to stop the action? Just turn the Main dial clockwise. Do you want a smaller aperture so that you get a narrow depth of field? Then turn the dial counterclockwise until you get the desired aperture. The camera shifts the shutter speed and aperture accordingly in order to get a proper exposure, and you will get the benefit of your choice as a result.

FIGURE 4.1

(left) This is my first shot using Program mode. Because I was pointing the camera more towards the building in the shade, the exposure was longer.



FIGURE 4.2

(right) By zooming out and including more of the bright sky in the photo, there was less of the front of the shaded building to influence the light meter, resulting in a change of exposure.



Let's set up the camera for Program mode and see how we can make all of this come together.

SETTING UP AND SHOOTING IN PROGRAM MODE

1. Turn your camera on and then turn the Mode dial to align the P with the indicator line.
2. Select your ISO by pressing the ISO button on the top of the camera, and then turning the Main dial to the desired setting and press the ISO button again (the ISO selection will appear in the rear LCD panel).
3. Point the camera at your subject and then activate the camera meter by depressing the shutter button halfway.
4. View the exposure information in the bottom of the viewfinder or by looking at the display panel on the back of the camera.
5. While the meter is activated, use your index finger to roll the Main dial left and right to see the changed exposure values.
6. Select the exposure that is right for you and start shooting. (Don't worry if you aren't sure what the right exposure is. We will start working on making the right choices for those great shots beginning with the next chapter.)

TV: SHUTTER PRIORITY MODE



Tv mode is what we photographers commonly refer to as Shutter Priority mode. If you dig deep in your manual, you will actually see that Tv stands for “Time Value.” I’m not sure who came up with this term, but I can tell you that it wasn’t a photographer. In all my years of shooting, I don’t ever recall thinking, “Hey, this would be a great situation to use the Time Value mode.” However, you don’t need to know why it is called Tv mode; the important thing is to know why and when to use it.

Just as with Program mode, Tv mode gives us more freedom to control certain aspects of our photography. In this case, we are talking about shutter speed. The selected shutter speed determines just how long you expose your camera’s sensor to light. The longer it remains open, the more time your sensor has to gather light. The shutter speed also, to a large degree, determines how sharp your photographs are. This is different from the image being sharply in focus. One of the major influences on the sharpness of an image is camera shake as well as the subject’s movement. Because a slower shutter speed means that light from your subject is hitting the sensor for a longer period of time, any movement by you or your subject will show up in your photos as blur.

SHUTTER SPEEDS


A *slow* shutter speed refers to leaving the shutter open for a long period of time—like 1/30 of a second or longer. A *fast* shutter speed means that the shutter is open for a very short period of time—like 1/250 of a second or less.

WHEN TO USE SHUTTER PRIORITY (TV) MODE

- When working with fast-moving subjects where you want to freeze the action (**Figure 4.3**); much more on this is in Chapter 5
- When you want to emphasize movement in your subject with motion blur (**Figure 4.4**)
- When you want to use a long exposure to gather light over a long period of time (**Figure 4.5**); more on this is in Chapter 8
- When you want to create that silky-looking water in a waterfall (**Figure 4.6**)

FIGURE 4.3

Even the fastest of subjects can be frozen with the right shutter speed.



ISO 400
1/2000 sec.
f/2.8
300mm lens

FIGURE 4.4

Slowing down the shutter speed allows your photographs to convey a sense of movement.



ISO 500
1/2 sec.
f/22
86mm lens



ISO 400
25 sec.
f/22
30mm lens

FIGURE 4.5
A long exposure coupled with a small aperture and a steady tripod helped capture this beach scene at night.



ISO 100
1/4 sec.
f/32
100mm lens

FIGURE 4.6
Increasing the length of the exposure time gives flowing water a silky look.

As you can see, the subject of your photo usually determines whether or not you will use Tv mode. It is important that you are able to visualize the result of using a particular shutter speed. The great thing about shooting with digital cameras is that you get instant feedback by checking your shot on the LCD screen. But what if your subject won't give you a do-over? Such is often the case when shooting sporting events. It's not like you can go ask the quarterback to throw that touchdown pass again because your last shot was blurry from a slow shutter speed. This is why it's important to know what these speeds represent in terms of their abilities to stop the action and deliver a blur-free shot.

First, let's examine just how much control you have over the shutter speeds. The T3i has a shutter speed range from 1/4000 of a second all the way down to 30 seconds. With that much latitude, you should have enough control to capture almost any subject. The other thing to think about is that Tv mode is considered a "semiautomatic" mode. This means that you are taking control over one aspect of the total exposure while the camera handles the other. In this instance, you are controlling the shutter speed and the camera is controlling the aperture. This is important to know because there will be times that you want to use a particular shutter speed but your lens won't be able to accommodate your request.

For example, you might encounter this problem when shooting in low-light situations: if you are shooting a fast-moving subject that will blur at a shutter speed slower than 1/125 of a second but your lens's largest aperture is f/3.5, you might see that your aperture display in your viewfinder and the rear LCD panel will begin to blink. This is your warning that there won't be enough light available for the shot—due to the limitations of the lens—so your picture will be underexposed (too dark).

Another case where you might run into this situation is when you are shooting moving water. To get that look of silky, flowing water, it's usually necessary to use a shutter speed of at least 1/15 of a second, if not longer. If your waterfall is in full sunlight, you may get that blinking aperture display once again because the lens you are using only closes down to f/22 at its smallest opening. In this instance, your camera is warning you that you will be overexposing your image (too light). There are workarounds for these problems, which we will discuss later (see Chapter 7), but it is important to know that there can be limitations when using Tv mode.

SETTING UP AND SHOOTING IN TV MODE

1. Turn your camera on and then turn the Mode dial to align the Tv with the indicator line.
2. Select your ISO by pressing the ISO button on the top of the camera, and then turning the Main dial (the ISO selection will appear in the rear LCD panel).

3. Point the camera at your subject and then activate the camera meter by depressing the shutter button halfway.
4. View the exposure information in the bottom area of the viewfinder or by looking at the rear LCD panel.
5. While the meter is activated, use your index finger to roll the Main dial left and right to see the changed exposure values. Roll the dial to the right for faster shutter speeds and to the left for slower speeds.



AV: APERTURE PRIORITY MODE



You wouldn't know it from its name, but Av mode is one of the most useful and popular modes in the Creative zone. Av stands for Aperture Value and, like Time Value, it's another term that you'll seldom hear a photographer toss around. The mode, however, is one of my personal favorites, and I believe that it will quickly become one of yours, as well. Av, more commonly referred to as Aperture Priority mode, is also deemed a semiautomatic mode because it allows you to once again control one factor of exposure while the camera adjusts for the other.

Why, you may ask, is this one of my favorite modes? It's because the aperture of your lens dictates depth of field. Depth of field, along with composition, is a major factor in how you direct attention to what is important in your image. It is the controlling factor of how much area in your image is in focus. If you want to isolate a subject from the background, such as when shooting a portrait, you can use a large aperture to keep the focus on your subject and make both the foreground and background blurry. If you want to keep the entire scene sharply focused, such as with a landscape scene, then using a small aperture will render the greatest amount of depth of field possible.

WHEN TO USE APERTURE PRIORITY (AV) MODE

- When shooting portraits or wildlife (**Figure 4.7**)
- When shooting most landscape photography (**Figure 4.8**)
- When shooting macro, or close-up, photography (**Figure 4.9**)
- When shooting architectural photography, which often benefits from a large depth of field (**Figure 4.10**)

FIGURE 4.7

A fairly large aperture combined with a long focal length created a very blurry background, so all the emphasis was left on the subject.



FIGURE 4.8

The smaller aperture setting brings sharpness to near and far objects.



ISO 100
1/125 sec.
f/13
105mm lens



FIGURE 4.9
Small apertures
give more sharp-
ness in macro
images.

FIGURE 4.10

A wide-angle lens combined with a small aperture makes for a lot of depth of field.



ISO 400
1/160 sec.
f/16
28mm lens

F-STOPS AND APERTURE

As discussed earlier, when referring to the numeric value of your lens aperture, you will find it described as an *f-stop*. The f-stop is one of those old photography terms that, technically, relates to the focal length of the lens (e.g., 200mm) divided by the effective aperture diameter. These measurements are defined as “stops” and work incrementally with your shutter speed to determine proper exposure. Older camera lenses used one-stop increments to assist in exposure adjustments, such as 1.4, 2, 2.8, 4, 5.6, 8, 11, 16, and 22. Each stop represents about half the amount of light entering the lens iris as the larger stop before it. Today, most lenses don’t have f-stop markings since all adjustments to this setting are performed via the camera’s electronics. The stops are also now typically divided into 1/3-stop increments to allow much finer adjustments to exposures, as well as to match the incremental values of your camera’s ISO settings, which are also adjusted in 1/3-stop increments.

We have established that Aperture Priority (Av) mode is highly useful in controlling the depth of field in your image. But it’s also pivotal in determining the limits of available light that you can shoot in. Different lenses have different maximum apertures. The larger the maximum aperture, the less light you need in order to achieve a properly exposed image. You will recall that, when in Tv mode, there is a limit at which you can handhold your camera without introducing movement or hand shake, which causes blurriness in the final picture. If your lens has a larger aperture, you can let in more light all at once, which means that you can use faster shutter speeds. This is why lenses with large maximum apertures, such as f/1.4, are called “fast” lenses.

On the other hand, bright scenes require the use of a small aperture (such as f/16 or f/22), especially if you want to use a slower shutter speed. That small opening reduces the amount of incoming light, and this reduction of light requires that the shutter stay open longer.

SETTING UP AND SHOOTING IN AV MODE

1. Turn your camera on and then turn the Mode dial to align the Av with the indicator line.
2. Select your ISO by pressing the ISO button on the top of the camera, and then turning the Main dial.
3. Point the camera at your subject and then activate the camera meter by depressing the shutter button halfway.
4. View the exposure information in the bottom area of the viewfinder or by looking at the rear display panel.

5. While the meter is activated, use your index finger to roll the Main dial left and right to see the changed exposure values. Roll the dial to the right for a smaller aperture (higher f-stop number) and to the left for a larger aperture (smaller f-stop number).

ZOOM LENSES AND MAXIMUM APERTURES

Some zoom lenses (like the 18–55mm kit lens) have a variable maximum aperture. This means that the largest opening will change depending on the zoom setting. In the example of the 18–55mm zoom, the lens has a maximum aperture of f/3.5 at 18mm and only f/5.6 when the lens is zoomed out to 55mm. Fixed aperture zoom lenses maintain the same maximum aperture throughout the zoom range. They are typically much more expensive than their variable maximum aperture counterparts.

M: MANUAL MODE



Once upon a time, long before digital cameras and program modes, there was manual mode. In those days it wasn't called "manual mode" because there were no other modes. It was just photography. In fact, many photographers, including myself, cut their teeth on completely manual cameras. Let's face it—if you want to learn the effects of aperture and shutter speed on your photography, there is no better way to learn than by setting these adjustments yourself. However, today, with the advancement of camera technology, many new photographers never give this mode a second thought. That's truly a shame, as not only is it an excellent way to learn your photography basics, it's also an essential tool to have in your photographic bag of tricks.

When you have your camera set to Manual (M) mode, the camera meter will give you a reading of the scene you are photographing. It's your job, though, to set both the f-stop (aperture) and the shutter speed to achieve a correct exposure. If you need a faster shutter speed, you will have to make the reciprocal change to your f-stop. Using any other mode, such as Tv or Av, would mean that you just have to worry about one of these changes, but Manual mode means you have to do it all yourself. This can be a little challenging at first, but after a while you will have a complete understanding of how each change affects your exposure, which will, in turn, improve the way that you use the other modes.

WHEN TO USE MANUAL (M) MODE

- When learning how each exposure element interacts with the others (**Figure 4.11**)
- When your environment is fooling your light meter and you need to maintain a certain exposure setting (**Figure 4.12**)
- When shooting silhouetted subjects, which requires overriding the camera's meter readings (**Figure 4.13**)



FIGURE 4.11

Shooting in Manual mode is a great way to learn about how ISO, aperture, and shutter speed affect your exposure.

FIGURE 4.12

Beaches and snow are always a challenge for light meters.


ISO 200
1/200 sec.
f/11
38mm lens



FIGURE 4.13

Although the meter was doing a pretty good job of exposing for the bright sky, I used Manual mode to push the foreground elements into complete black silhouette.

ISO 200
1/500 sec.
f/8
70mm lens



SETTING UP AND SHOOTING IN MANUAL MODE

1. Turn the Mode dial to align the M with the indicator line.
2. Select your ISO by pressing the ISO button on the top of the camera, and then turning the Main dial.
3. Point the camera at your subject and then activate the camera meter by depressing the shutter button halfway.
4. View the exposure information in the bottom area of the viewfinder or by looking at the rear display panel.
5. While the meter is activated, use your index finger to roll the Main dial left and right to change your shutter speed value until the exposure mark is lined up with the zero mark. The exposure information is displayed by a scale with marks that run from -2 to +2 stops. A “proper” exposure will line up with the arrow mark in the middle. As the indicator moves to the left, it is a sign that you will be underexposing (there is not enough light hitting the sensor to provide adequate exposure). Move the indicator to the right and you will be providing more exposure than the camera meter calls for. This is overexposure.
6. To set your exposure using the aperture, depress the shutter release button until the meter is activated. Then, using your thumb, hold in on the Av button on the back of the camera and then use your index finger to turn the Main dial right for a smaller aperture (large f-stop number) or left for a larger aperture (small f-stop number).



A-DEP: AUTO DEPTH OF FIELD MODE



The A-DEP, or Auto Depth of Field, setting is on the Creative zone side of the dial, but in my opinion it should be over in the Basic zone. The mode works this way: As you depress the shutter release button to focus on your subject, the camera will use the other focus points to measure the distance of the other objects in the viewfinder. Then, it will determine what the appropriate aperture setting should be to render all of the objects in focus (**Figure 4.14**). The only way to adjust your exposure is to change the ISO. There will be more discussion of the A-DEP mode and how to use it in Chapter 7.

FIGURE 4.14

Landscapes with subjects that are at differing distances could benefit from the A-DEP mode.



ISO 400
1/80 sec.
f/14
24mm lens

HOW I SHOOT: A CLOSER LOOK AT THE CAMERA SETTINGS I USE

The great thing about working with a dSLR camera is that I can always feel confident that some things will remain unchanged from camera to camera. For me, these are the Aperture Priority (Av) and Shutter Priority (Tv) shooting modes. Although I like to think of myself as a generalist in terms of my photography, I do tend to lean heavily on the landscape and urban photography genres. Working in these areas means that I am almost always going to be concerned with my depth of field. Whether it's isolating my subject with a large aperture or trying to maximize the overall sharpness of a sweeping landscape, I always keep an eye on my aperture setting.

If I do have a need to control the action, I use Shutter Priority. If I am trying to create a silky waterfall effect, I can depend on Tv to provide that long shutter speed that it will deliver. Maybe I am shooting a motocross jumper. I definitely need the fast shutter speeds that will freeze the fast-moving action. While the other camera modes have their place, I think you will find that, like myself and most other working pros, you will use the Av and Tv modes for 90 percent of your shooting.


The other concern that I have when I am setting up my camera is just how low I can keep my ISO. I raise the ISO only as a last resort because each increase in sensitivity is an opportunity for more digital noise to enter my image. To that end, I always have the High ISO Noise Reduction feature turned on Standard (see Chapter 7).

To make quick changes while I shoot, I often use the Exposure Compensation feature (covered in Chapter 7) so that I can make small over- and underexposure changes. This is different than changing the aperture or shutter; it is more like fooling the camera meter into thinking the scene is brighter or darker than it actually is.

One of the reasons I change my exposure is to make corrections when I see the "blinkies" while looking at my images on the rear LCD. Blinkies are the warning signal that part of my image has been overexposed to the point that I no longer have any detail in the highlights. The highlight alert will flash wherever the potential exists for overexposure. The only unfortunate thing about this feature is that it doesn't work with the full-screen preview mode. You have to set your camera display to one of the Histogram modes and then you will see the highlight alert (**Figure 4.15**).

FIGURE 4.15
The T3i's highlight alert screen.

The flashing black areas are alerting me that these highlights are overexposed and will lose detail.



Notice how the histogram is pushed up against the right side of the graph.

As you work your way through the coming chapters, you will see other tips and tricks I use in my daily photography, but the most important tip I can give is that you take the time to understand the features of your camera so that you can leverage the technology in a knowledgeable way. This will result in better photographs.

Chapter 4 Assignments

The information covered in this chapter will define how you work with your camera from this point on. Granted, there may be times that you just want to grab some quick pictures and will resort to the Basic zone, but to get serious with your photography, you should learn the modes in the Creative zone.

Starting off with Program mode

Set your camera on Program mode and start shooting. Become familiar with the adjustments you can make to your exposure by turning the Main dial. While shooting, make sure that you keep an eye on your ISO.

Learning to control time with the Tv mode

Find some moving subjects and then set your camera to Tv mode. Have someone ride their bike back and forth or even just photograph cars as they go by. Start with a slow shutter speed of around 1/30 of a second and then start shooting with faster and faster shutter speeds. Keep shooting until you can freeze the action. Now find something that isn't moving, like a flower, and work your shutter speed from something fast like 1/500 of a second and then work your way down to about 1/4 of a second. The point is to see how well you can handhold your camera before you start introducing hand shake into the image.

Controlling depth of field with the Av mode

The name of the game with Av mode is depth of field. Set up three items in equal distance from you. I would use chess pieces or something similar. Now focus on the middle item and set your camera to the largest aperture that your lens allows (remember, large aperture means a small number like f/3.5). Now, while still focusing on the middle subject, start shooting with ever-smaller apertures until you are at the smallest f-stop for your lens. If you have a zoom lens, try doing this exercise with the lens at the widest and then the most telephoto settings. Now move up to subjects that are farther away, like telephone poles, and shoot them in the same way. The idea is to get a feel for how each aperture setting affects your depth of field.

Giving and taking with Manual mode

Go outside on a sunny day and, using the camera in Manual mode, set your ISO to 100, your shutter speed to 1/125 of a second, and your aperture to f/16. Now press your shutter release button to get a meter reading. You should be pretty close to that zero mark. If not, make small adjustments to one of your settings until it hits that mark. Now is where the fun begins. Start moving your shutter speed slower, to 1/60, and then set your aperture to f/22. Now go the other way. Set your aperture on f/8 and your shutter speed to 1/500. Now review your images. If all went well, all the exposures should look the same. This is because you balanced the light with reciprocal changes to the aperture and shutter speed. Now go back to our original setting of 1/125 at f/16 and try just moving the shutter speed without changing the aperture. Just make 1/3-stop changes (1/125 to 1/100 to 1/80 to 1/60), and then review your images to see what a 1/3 stop of overexposure looks like. Then do the same thing going in the opposite way. It's hard to know if you want to over- or underexpose a scene until you have actually done it and seen the results.

Share your results with the book's Flickr group!

Join the group here: [flickr.com/groups/canonrebel3i600dfromsnapshotstogreatshots](https://www.flickr.com/groups/canonrebel3i600dfromsnapshotstogreatshots)

INDEX

- 1st and 2nd Curtain Sync modes, 226–229
- A**
- action photography, 107–131
 - annotated examples of, 82–83, 108–111
 - assignments on shooting, 130–131
 - automatic mode for, 71
 - composing shots in, 128–130
 - continuous shooting mode for, 125–126
 - conveying motion in, 126–128
 - depth of field in, 119–120
 - direction of travel in, 112–113
 - focus modes used for, 120–124
 - ISO setting and, 117–118
 - isolating subjects in, 119–120
 - portraits as, 154–155
 - shutter speed and, 89, 90, 112–115, 117–118
 - speed of subject in, 114
 - stopping motion in, 117–118
 - subject-to-camera distance in, 115
 - tips for shooting, 128–130
 - A-DEP mode, 101–102, 172–173, 220
 - AË Lock feature, 143–144, 221
 - AI Focus mode, 10, 78, 122–123
 - AI Servo mode, 78, 120–121
 - ambience setting, 76
 - angular lines, 242
 - animal photography
 - wildlife photography, 28–29, 93, 94
 - zoo photography, 252–253, 270–271
 - Aperture Priority (Av) mode, 93–98
 - assignment on using, 105
 - flash sync speeds in, 219, 220
 - isolating subjects using, 119–120
 - portrait photography and, 138–140
 - setting up and shooting in, 97–98
 - situations for using, 93–97, 265
 - aperture settings
 - action photography and, 119–120
 - depth of field and, 51, 93, 119–120
 - exposure and, 47, 48–49
 - f-stops and, 48, 97
 - landscape photography and, 93, 94
 - portrait photography and, 138–140
 - prioritizing, 93–98
 - zoom lenses and, 46, 98
 - architectural photography, 93, 96
 - audio recording, 55–56
 - Auto Cleaning feature, 36
 - Auto Depth of Field. *See* A-DEP mode
 - Auto Exposure Bracketing (AEB), 200, 262–264
 - Auto Focus (AF) point mode, 121–122
 - Auto ISO setting, 9, 74
 - Auto Lighting Optimizer, 266–267
 - Auto white balance setting, 13
 - autofocus system, 15–16, 215
 - Av mode. *See* Aperture Priority (Av) mode
- B**
- backgrounds
 - blurring, 51, 67, 138, 139
 - isolating subjects from, 51, 120
 - sharpness setting for, 76
 - backup battery, 5
 - Basic shooting modes, 13, 61, 66–79
 - assignments on using, 79
 - Close-up mode, 70
 - Creative Auto mode, 75–77
 - Flash Off mode, 73–74
 - Landscape mode, 69
 - limitations of, 78
 - Night Portrait mode, 72–73
 - Portrait mode, 67–68
 - Scene Intelligent Auto mode, 66–67
 - Sports mode, 71
 - battery, charging, 5
 - black and white images
 - landscape photos as, 181–182
 - portraits as, 146–149
 - blinkies, 103–104, 179
 - blur
 - background, 51, 67, 138, 139
 - motion, 49, 50, 127–128, 131
 - bonus chapters, 58, 272
 - bracketing exposures, 201, 262–264, 273
 - brightness, 20, 190
 - buffer, 126
 - built-in flash, 218–222
 - Bulb shutter setting, 258–259, 273
- C**
- Canon Speedlites, 229–232
 - Canon T3i camera
 - features illustration, 2–4
 - firmware updates, 33–35
 - properly holding, 22, 23
 - catchlight, 153
 - Center-Weighted metering mode, 141
 - charging the battery, 5
 - children
 - action portraits of, 154
 - shooting at their level, 160, 161
 - Clean Now feature, 36, 37
 - cleaning the sensor, 36–37, 59
 - clipping, 20–21
 - Close-up mode, 70, 79
 - close-up photography, 265
 - annotated examples of, 64–65, 84–85
 - aperture priority mode for, 93, 95, 265
 - assignment on shooting, 273
 - automatic mode for, 70
 - Cloudy setting, 13, 176
 - color composition, 244–245
 - color temperature, 14, 183
 - composition, 235–249
 - action photo, 128–130
 - angular lines and, 242
 - annotated examples of, 236–239
 - assignments on, 249
 - color and, 244–245
 - contrast and, 245–246
 - depth of field and, 240–241
 - framing and, 247–248
 - landscape, 62–63, 190–193
 - leading lines and, 247
 - patterns and, 244
 - point of view and, 243
 - portrait, 155–162
 - rule of thirds and, 190–192
 - continuous shooting mode, 124, 125–126
 - contrast, 245–246
 - Creative Auto (CA) mode, 75–77
 - assignment on using, 79
 - description of, 75
 - settings in, 76–77
 - Creative shooting modes, 13, 81, 86–105
 - A-DEP mode, 101–102
 - Aperture Priority mode, 93–98
 - assignments on using, 104–105
 - Manual mode, 98–101
 - Program mode, 86–88
 - Shutter Priority mode, 89–93
 - Custom white balance setting, 13
- D**
- Daylight setting, 13, 176
 - deleting images, 19
 - depth, creating, 192–193
 - depth of field
 - action photos and, 119–120

- A-DEP mode and, 101–102, 172–173
- aperture settings and, 51, 93, 119–120
- composition and, 240–241
- landscapes and, 184–186, 201
- lenses and, 42, 43
- portraits and, 138, 140, 163

Depth of Field preview button, 185–186

Digital Photo Professional software, 39

digital zoom feature, 54

diopter adjustment, 15

Display button, 17–18, 19

distance compression, 43

distortion, 157

drive modes, 76–77, 124, 125–126

dynamic range, 38

E

environmental portraits, 140

EOS Utility program, 35

Ɛ-TTL II metering, 220–221

Evaluative metering mode, 141–142, 221

exposure, 46–49

- bracketing, 201, 262–264
- calculating, 48–49
- factors of, 46–47
- histograms of, 20–21
- long, 89, 91, 217

Exposure Compensation feature, 103, 179–180, 188

Exposure Triangle, 46–47

exposure value (EV), 46

external flash, 229–232

eyes

- catchlight in, 153
- focusing on, 144–146
- red-eye reduction, 224–226

F

Face Detection mode, 150–151

“fake” panoramas, 194–195

fill flash, 153–154

filters

- black & white photography, 148, 181–182
- polarizing and neutral density, 188

firmworks, 258

firmware updates, 33–35, 59

flash

- built-in, 218–222
- CA mode settings, 77
- disabling, 216
- external, 229–232
- fill, 153–154
- metering modes, 220–222

- range/distance, 221
- red-eye reduction, 224–226
- synchronization, 218, 219–220, 226–229

Flash Exposure Compensation feature, 222–224

Flash Exposure (FE) Lock feature, 221–222

Flash Off mode, 73–74

Flash white balance setting, 13

flower photography, 84–85, 209, 265

Fluorescent setting, 13, 176

Focus Assist mode, 215–216

focus modes, 78

- AI Focus, 10, 78, 122–123
- AI Servo, 78, 120–121
- assignments on, 23, 131
- manual, 15–16, 123–124, 131, 215
- One Shot, 11, 12, 78, 123, 144, 146
- setting/choosing, 11, 123

focus points, 11, 121–122

focusing

- for action photography, 120–124
- for landscape photography, 184–187
- for low-light photography, 214–216
- for portraits, 144–146
- for video recording, 52, 56

focusing system, 10–12

formatting memory cards, 31–32, 59

framing images, 155–156, 160, 161, 247–248

f-stops, 47, 48–49, 97

See also aperture settings

G

Grid overlay feature, 152, 201

H

handholding your camera, 22, 211–212, 233

HDMI cable, 58

High Capacity (SDHC) cards, 30

high dynamic range (HDR) images, 199–201

High ISO Speed Noise Reduction feature, 103, 208–210

high-definition video, 52

high-key vs. low-key images, 181

Highlight Alert feature, 103–104, 179, 188

histograms, 18–21

- display modes for, 18–19
- value of using, 20–21

horizon line, 247

hyper focal distance (HFD), 184–186, 201

I

image formats, 38–40

- JPEG, 7–8, 38
- RAW, 38–39

image quality settings, 8, 40

Image Review button, 58, 116

image stabilization (IS) lenses, 171, 211–213

interlaced video, 53

ISO setting, 8–9

- action photos and, 117–118
- changing on the fly, 10, 118
- expansion feature, 210–211
- exposure and, 47, 48–49
- flash range and, 221
- landscape photos and, 173–174
- low-light situations and, 208–211
- noise and, 10, 173–174, 175
- Program mode and, 86–87
- starting points for, 87
- steps for selecting, 9

J

JPEG format, 7–8

- quality settings, 8
- RAW + JPEG option, 40
- reasons for using, 38

K

Kelvin temperature scale, 14

kit lenses, 46

L

Landscape mode, 69, 79

landscape photography, 165–201

- A-DEP mode for, 172–173
- annotated examples of, 166–169
- aperture settings and, 93, 94
- assignments on shooting, 201
- automatic mode for, 69
- black and white, 181–182
- composition of, 62–63, 190–193
- exposure compensation for, 179–180, 188
- focusing for, 184–187
- HDR images and, 199–201
- ISO settings for, 173–174
- noise reduction for, 175
- panoramas and, 194–198
- picture style for, 69, 177–179
- sunrise/sunset in, 183–184

landscape photography (*continued*)
 tripods used for, 170–171, 184, 187
 waterfall shots in, 188–189
 white balance settings for, 176–177

LCD display
 reviewing photos in, 16–21, 23
 reviewing videos in, 58
 zooming in on, 116

leading lines, 247

lens flare, 260

lenses, 40–46
 assignments on using, 59, 131
 focal lengths for, 41–46
 image stabilization, 171, 211–213
 normal, 43, 44
 recommended, 46
 telephoto, 43, 45
 wide-angle, 41–42
 zoom, 46

lighting
 Auto Lighting Optimizer and, 266–267
 red-eye reduction and, 224
See also flash; low-light photography; sunlight

lightning storms, 259, 260

Live View feature, 150–152
 Face Detection mode, 150–151
 Grid overlay option, 152, 201
 video recording and, 52
 white balance settings, 176, 177

long exposures, 89, 91, 217, 233

Low Level Format option, 32

low-light photography, 203–233
 annotated examples of, 204–207
 assignments on shooting, 233
 automatic modes for, 72–74
 built-in flash for, 218–222
 external flash for, 229–232
 flash compensation for, 222–224
 flash sync modes and, 226–229
 focusing for, 214–216
 image stabilization lenses for, 211–213
 long exposures for, 217
 raising the ISO for, 208–211
 red-eye reduction in, 224–226

luminance, 20

M

macro photography. *See* close-up photography

Magnify Image button, 116

manual focus (MF) mode, 15–16, 23, 123–124, 131, 215

Manual (M) mode, 98–101, 258–259
 assignment on using, 105
 Bulb setting in, 258–259
 flash sync speeds in, 220
 setting up and shooting in, 101
 situations for using, 99–100

megapixels (MP), 39

memory cards, 30–32
 choosing, 30–31
 formatting, 31–32, 59
 Release Shutter without Card setting, 6–7
 updating the firmware using, 35
 video recording and, 31

metering modes, 141, 220–222
 Center-Weighted, 141
 Evaluative, 141–142, 221
 Partial, 141, 142–143
 Spot, 141, 254–256

microphone
 built-in, 55
 external, 56

Mirror Lockup feature, 259

mirror reflections, 242

Monochrome picture style, 146–149, 181–182

motion
 assignments on shooting, 130–131
 continuous shooting mode for, 125–126
 depth of field and, 119–120
 examples of shooting, 108–111
 shutter speed and, 49–50, 89, 90, 112–115, 117–118
 techniques for conveying, 126–128
 tips for shooting, 128–130
See also action photography

motion blur, 49, 50, 127–128, 131

Movie mode, 52

multiple-image panoramas, 196–198

My Menu function, 267–268

N

natural light. *See* sunlight

neutral density filter, 188

Night Portrait mode, 72–73, 219

nighttime photography. *See* low-light photography

noise
 features for reducing, 175, 208–210
 ISO setting and, 10, 173–174, 175
 normal lenses, 43, 44
 NTSC video standard, 53

O

obstructions, 270–271

off-camera flash, 229–232

One Shot focus mode, 11, 12, 23, 78, 123, 144, 146

overexposure warning, 103–104, 179

P

PAL video standard, 53

panning, 126–127, 131

panoramas, 194–198
 creating “fake,” 194–195
 multiple-image, 196–198

Partial metering mode, 141, 142–143

patterns, 244

picture styles
 Landscape, 69, 177–179
 Monochrome, 146–149, 181–182
 Portrait, 67–68, 149

pixel resolution, 39

point of view, 243

polarizing filter, 188

pop-up flash, 218–222

Portrait mode, 67–68, 79, 138

portrait orientation, 158

portraits, 133–163
 action shots as, 154–155
 AE Lock feature for, 143–144
 annotated examples of, 134–137
 Aperture Priority mode for, 138–140
 assignments on shooting, 163
 automatic mode for, 67–68, 138
 black and white, 146–149
 composition of, 155–162
 depth of field in, 138, 140, 163
 environmental, 140
 Face Detection mode for, 150–151
 fill flash for, 153–154
 focusing for, 144–146
 Grid overlay option for, 152
 lenses used for, 68, 138, 140, 157
 metering modes for, 141–143
 Night Portrait mode for, 72–73
 picture styles for, 67–68, 146–149, 163
 tips for shooting, 155–162

prime lenses, 46

Program (P) mode, 86–88
 assignment on using, 104
 flash sync speed in, 219
 setting up and shooting in, 88
 situations for using, 86–88

progressive video, 53

Q

- quality settings, 40
 - JPEG format, 8
 - video, 52-54
- Quick Control screen, 143, 151

R

- RAW format, 38-39
 - advice for shooting in, 39
 - HDR images and, 200
 - RAW + JPEG option, 40
 - reasons for using, 38-39
- reciprocal exposures, 48-49
- Red-Eye Reduction feature, 224-226
- Reduce Image button, 116
- reflections, photographing, 240, 241, 242
- Release Shutter without Card setting, 6-7
- remote switch, 259
- resolution
 - image, 39
 - video, 52-53
- reviewing photos, 16-21
 - assignment on, 23
 - display modes for, 17-19
 - histograms used in, 18-21
 - time setting for, 17
 - zooming in for, 116
- reviewing videos, 58
- rule of thirds, 190-192, 201

S

- Scene Intelligent Auto mode, 66-67, 79
- SD, SDHC, and SDXC memory cards, 30
- self-timer, 66, 77, 213
- sensor cleaning, 36-37, 59
- Shade setting, 13, 176
- sharpness of images, 76, 186, 190
- Shutter Priority (Tv) mode, 89-93
 - action photos and, 117-118
 - assignment on using, 105
 - flash sync speeds in, 219
 - setting up and shooting in, 92-93
 - situations for using, 89-92
- shutter speed
 - explanation of, 89
 - exposure and, 47, 48-49
 - flash synchronization and, 218, 219-220
 - motion and, 49-50, 89, 90, 112-115, 117-118

- prioritizing, 89-93
- silhouetted subjects, 99, 100
- single-point focusing, 10, 23, 144, 146
- sound recording, 55-56
- Speedlites, 229-232
- Sports mode, 71, 79
- sports photography. *See* action photography
- Spot metering mode, 141, 254-256, 273
- sunlight
 - creative use of, 260-261
 - golden hours of, 183-184
 - lens flare from, 260
 - portraits and, 159, 160, 163
- sunny 16 rule, 48
- sunrise/sunset photos, 183-184, 256-257, 273
- synchronized flash, 218, 219-220, 226-229

T

- tack sharp images, 186
- telephoto lenses, 43, 45
- Trash button, 19
- tripods, 170-171, 184, 187, 265
- Tungsten setting, 13
- TV connection, 58
- Tv mode. *See* Shutter Priority (Tv) mode

U

- updating the firmware, 33-35, 59

V

- video ports, 58
- video recording, 52-58
 - assignment on, 59
 - bonus chapter on, 58
 - digital zoom feature, 54
 - focusing the camera for, 52, 56
 - frame rates for, 53
 - memory cards for, 31
 - quality settings, 52-54
 - reviewing recorded videos, 58
 - sound recording with, 55-56
 - starting/stopping, 52
 - taking pictures while, 56-57
 - Video Snapshot feature, 57
- video standards, 53
- viewfinder diopter, 15

W

- waterfall photos, 89, 91, 188-189
- white balance settings, 12-14
 - assignment on using, 23
 - choices available for, 13
 - color temperature and, 14
 - creating custom, 268-270
 - landscape photos and, 176-177
 - Live View feature and, 176, 177
 - steps for selecting, 14
- wide-angle lenses, 41-42, 140, 157
- wildlife photography, 28-29, 93, 94
- wireless flash, 229-232
- wireless remote, 259

Z

- zoo photography, 252-253, 270-271
- zoom lenses, 46, 98
- zooming the LCD display, 116