

# Android™ Tips and Tricks



que

Guy Hart-Davis

FREE SAMPLE CHAPTER



SHARE WITH OTHERS

# Android<sup>TM</sup> Tips and Tricks

Guy Hart-Davis

**que<sup>®</sup>**

800 East 96th Street,  
Indianapolis, Indiana 46240



## ANDROID® TIPS AND TRICKS

COPYRIGHT © 2015 BY PEARSON EDUCATION, INC.

All rights reserved. No part of this book shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without written permission from the publisher. No patent liability is assumed with respect to the use of the information contained herein. Although every precaution has been taken in the preparation of this book, the publisher and author assume no responsibility for errors or omissions. Nor is any liability assumed for damages resulting from the use of the information contained herein.

ISBN-13: 978-0-7897-5385-4

ISBN-10: 0-7897-5385-5

Library of Congress Control Number: 2014956782

Printed in the United States of America

First Printing December 2014

### TRADEMARKS

All terms mentioned in this book that are known to be trademarks or service marks have been appropriately capitalized. Que Publishing cannot attest to the accuracy of this information. Use of a term in this book should not be regarded as affecting the validity of any trademark or service mark.

### WARNING AND DISCLAIMER

Every effort has been made to make this book as complete and as accurate as possible, but no warranty or fitness is implied. The information provided is on an "as is" basis. The author and the publisher shall have neither liability nor responsibility to any person or entity with respect to any loss or damages arising from the information contained in this book.

### SPECIAL SALES

For information about buying this title in bulk quantities, or for special sales opportunities (which may include electronic versions; custom cover designs; and content particular to your business, training goals, marketing focus, or branding interests), please contact our corporate sales department at [corpsales@pearsoned.com](mailto:corpsales@pearsoned.com) or (800) 382-3419.

For government sales inquiries, please contact [governmentsales@pearsoned.com](mailto:governmentsales@pearsoned.com).

For questions about sales outside the U.S., please contact [international@pearsoned.com](mailto:international@pearsoned.com).

EDITOR-IN-CHIEF

Greg Wiegand

ACQUISITIONS EDITOR

Michelle Newcomb

DEVELOPMENT EDITOR

William Abner

MANAGING EDITOR

Sandra Schroeder

PROJECT EDITOR

Seth Kerney

COPY EDITOR

Chuck Hutchinson

INDEXER

Rebecca Salerno

PROOFREADER

Jess DeGabriele

TECHNICAL EDITORS

Vince Averello

Christian Kenyeres

EDITORIAL ASSISTANT

Cindy Teeters

BOOK DESIGNER

Mark Shirar

COMPOSITOR

Mary Sudul

# CONTENTS AT A GLANCE

	Introduction .....	1
<b>1</b>	Getting Up to Speed .....	15
<b>2</b>	Syncing Your Device .....	59
<b>3</b>	Customizing Your Device .....	87
<b>4</b>	Connecting to Networks and Devices .....	119
<b>5</b>	Installing, Running, and Managing Apps .....	161
<b>6</b>	Taking Gmail to the Pro Level .....	179
<b>7</b>	Becoming Expert with the Email App .....	209
<b>8</b>	Browsing with Chrome .....	245
<b>9</b>	Maximizing Your Productivity .....	271
<b>10</b>	Making the Most of Phone and Messaging .....	317
<b>11</b>	Exploiting Camera, Photos, and Videos .....	353
<b>12</b>	Enjoying Your Music Everywhere .....	377
<b>13</b>	Staying in Touch via Social Networking .....	407
<b>14</b>	Using Samsung TouchWiz .....	447
<b>15</b>	Using HTC Sense .....	485
	Index .....	515

# TABLE OF CONTENTS

Introduction .....	1
<b>1 Getting Up to Speed .....</b>	<b>15</b>
Identifying Your Device's Android Version and its Skin .....	15
Understanding Android Version Numbers and Names .....	16
Finding Out Which Android Version Your Device Is Running .....	16
Establishing Whether Your Device Is Using a Skin .....	17
Setting Different Volume Levels for Different Audio Sources .....	19
Managing Your Notifications .....	20
Responding to a Notification .....	20
Turning the Notification Light On or Off .....	22
Turning Off Notifications for an App .....	22
Clearing Repeat Notifications .....	22
Entering Text .....	24
Using the Keyboard and Spelling Correction .....	24
Entering Text Using a Hardware Keyboard .....	29
Entering Text Using Dictation .....	31
Entering Emoji .....	33
Using Alternative Keyboards .....	33
Setting Up a Tablet for Multiple Users .....	34
Creating a User Account .....	34
Creating a Restricted Profile .....	37
Switching Among User Accounts and Profiles .....	38
Deleting a User Account or Restricted Profile .....	39
Understanding and Avoiding Problems .....	39
Getting the Best Battery Performance .....	40
Identifying Power Hogs .....	40
Eking Out Battery Life .....	43
Recharging Secrets .....	45
Managing Files and Storage .....	47
Adding an SD Card .....	48
Choosing a File Manager .....	51
Checking Free Space and Seeing What's Taking Up Space .....	52
Recovering Space .....	54

<b>2</b>	<b>Syncing Your Device</b>	<b>59</b>
	Understanding Your Options for Syncing Your Device	60
	Choosing the Right Sync App	60
	Getting and Installing Your Sync App	62
	Installing a Sync App on Windows	62
	Choosing What Happens When You Connect Your Device to Windows	64
	Installing Android File Transfer on OS X	65
	Using Your Sync App	67
	Using Sync Apps on Windows	67
	Using Android File Transfer on OS X	70
	Loading Files on Your Device	71
	Updating, Backing Up, and Restoring Your Device	72
	Keeping Your Device Updated	73
	Backing Up Your Device	76
	Restoring Your Device	79
	Setting Up and Using Remote Lock and Wiping	81
	Setting Up Remote Find and Wiping	82
	Remotely Locking and Wiping Your Device	83
<b>3</b>	<b>Customizing Your Device</b>	<b>87</b>
	Setting Up Your Home Screens	87
	Adding and Removing Home Screens	88
	Adding Apps to Your Home Screens	89
	Adding Widgets to Your Home Screens	89
	Adding Web Addresses to Your Home Screens	91
	Organizing Home Screen Items into Folders	92
	Adding Dropbox Folders to Your Home Screens	93
	Repositioning Items on Your Home Screens	93
	Removing Items from Your Home Screens	94
	Rearranging Your Home Screens	94
	Setting the Wallpaper	94
	Using a Different Launcher	96
	Choosing a Launcher	97
	Installing a Launcher	99
	Setting Your Default Launcher	99
	Switching Among Launchers	100
	Changing Your Default Launcher	100
	Making No Launcher the Default	101
	Configuring Input Options	102

Configuring the Lock Screen.....	105
Choosing the Best Locking Method.....	105
Setting Up Locking on Your Device.....	106
Putting Widgets on the Lock Screen.....	107
Putting Your Owner Information on the Lock Screen.....	108
Choosing Location Settings to Protect Your Privacy.....	109
Encrypting Your Device.....	112
Encrypting the Data on Your Device.....	113
Decrypting the Data on Your Device.....	115
Performing a Hard Reset.....	117
<b>4 Connecting to Networks and Devices.....</b>	<b>119</b>
Using Airplane Mode.....	119
Taking Control of Cellular Connections.....	120
Displaying the Mobile Networks Screen.....	120
Enabling and Disabling Data and Roaming.....	121
Choosing Between 3G and 4G Networks.....	122
Configuring a New Access Point.....	123
Connecting to a Different Carrier.....	123
Keeping Within Your Data Plan.....	124
Managing Your Wi-Fi Connections.....	128
Turning Wi-Fi On and Off.....	128
Connecting to Wi-Fi Networks.....	130
Connecting to a Closed Network.....	131
Setting Up a Network Using WPS.....	132
Using Wi-Fi Direct.....	133
Installing Digital Certificates.....	135
Choosing Advanced Wi-Fi Settings.....	137
Whitelisting Your Device on a Wi-Fi Network.....	139
Configuring IP Settings Manually.....	140
Connecting Through a Proxy Server.....	142
Improving Your Wi-Fi Connections.....	144
Forgetting a Network.....	145
Sharing Your Device's Internet Connection.....	146
Sharing the Internet Connection via USB Tethering.....	147
Sharing the Internet Connection via Portable Wi-Fi Hotspot.....	148
Connecting Bluetooth Devices.....	150
Pairing a Bluetooth Device with Your Android Device.....	150
Transferring Files to Another Device via Bluetooth.....	152

Sharing an Internet Connection via Bluetooth Tethering .....	153
Using VPNs .....	155
Setting Up a VPN Connection .....	156
Connecting via the VPN .....	157

## **5 Installing, Running, and Managing Apps ..... 161**

Evaluating Permissions When Installing Apps .....	161
Getting a Refund on an App .....	163
Configuring Your Play Store Account .....	164
Sideloaded Apps .....	166
Installing a File Manager .....	167
Getting the Package File for the App .....	167
Setting Android to Allow Apps from Unknown Sources .....	169
Sideloaded the App .....	170
Running Apps .....	170
Working with the Recent Apps Screen .....	171
Switching Apps with the Recent Apps Screen .....	172
Closing an App from the Recent Apps Screen .....	173
Opening the App Info Screen for an App .....	173
Forcing an App to Stop .....	173
Clearing an App's Cache, Data, or Defaults .....	174
Uninstalling Apps .....	174
Rebooting into Safe Mode .....	175
Resetting App Preferences .....	176

## **6 Taking Gmail to the Pro Level ..... 179**

Setting Up Your Other Gmail Accounts .....	180
Configuring Your Gmail Accounts to Work Your Way .....	181
Choosing General Settings .....	182
Configuring Account-Specific Settings .....	185
Triaging and Reading Your Messages .....	192
Navigating Among Your Accounts and Labels .....	192
Working in the Conversation List .....	192
Reading Your Messages .....	195
Writing and Sending Messages .....	196
Labeling and Archiving Your Messages .....	198



Dealing with Problem Mail and Problem Senders .....	200
Searching for Messages .....	201
Searching with Keywords .....	201
Searching with Advanced Search Operators .....	201
Searching with Boolean Operators and Grouping .....	204
Setting Up 2-Step Verification .....	205
Setting Up 2-Step Verification Using a Computer .....	205
Setting Up 2-Step Verification Using an Android Device .....	207
Logging In to Your Account with 2-Step Verification Enabled .....	207

**7****Becoming Expert with the Email App..... 209**

Setting Up Your Non-Gmail Accounts .....	210
Gathering the Information Needed to Set Up an Email Account .....	210
Setting Up an Email Account .....	213
Setting Up Exchange Server Accounts .....	220
Getting the Information Needed for Your Exchange Server Account .....	221
Entering Your Exchange Server Account Details .....	222
Deleting an Account from the Email App .....	227
Sending and Receiving Messages .....	228
Creating and Sending a Message .....	229
Receiving and Reading Messages .....	232
Replying to Messages and Forwarding Messages .....	235
Setting Up and Using Quick Responses .....	236
Setting Up Your Quick Responses .....	237
Using Your Quick Responses .....	238
Saving and Reopening Drafts .....	238
Navigating Your Mailboxes .....	238
Choosing General Settings .....	240
Choosing Account-Specific Settings .....	241

**8****Browsing with Chrome..... 245**

Choosing Essential Chrome Settings .....	246
Configuring Your Google Account .....	247
Choosing Your Search Engine .....	250
Setting Up Autofill Forms .....	250
Working with the Save Passwords Feature .....	251
Choosing Privacy Settings and Clearing Browsing Data .....	252

Choosing Accessibility Settings.....	254
Choosing Content Settings.....	255
Managing Bandwidth and Preloading.....	258
Browsing the Web with Chrome.....	259
Navigating Among Web Pages.....	259
Managing and Switching Tabs.....	261
Making the Most of Bookmarks.....	263
Returning to a Tab You Recently Closed.....	265
Viewing Your Chrome Tabs Open on Other Devices.....	265
Returning to a Page You Visited Earlier.....	265
Browsing Incognito.....	266
Requesting a Desktop Site.....	267
Using Chrome to Mobile.....	268
Installing Chrome to Mobile on Your Computer.....	268
Setting Up Your Mobile Device.....	269
Sending Pages to Your Device.....	269

## 9

<b>Maximizing Your Productivity.....</b>	<b>271</b>
Streamlining Your Life with Google Now.....	272
Navigating and Customizing Google Now.....	272
Accessing Google Now from the Lock Screen.....	282
Working with Reminders in Google Now.....	282
Navigating with Maps.....	284
Making Sure You Know Essential Maps Moves.....	284
Saving Maps for Offline Use.....	287
Choosing Key Settings for Maps.....	289
Managing Your Contacts.....	291
Adding a New Contact.....	291
Displaying Only the Contacts You Want to See.....	292
Joining and Separating Contacts.....	293
Importing and Exporting Contacts.....	294
Mastering Your Schedule with Calendar.....	295
Configuring the Calendar App.....	296
Choosing Which Calendars to Display.....	298
Controlling How the Calendar Appears.....	298
Creating Events.....	299
Inviting Others to an Event.....	299
Dealing with Invitations.....	300
Sharing Your Google Calendars.....	300

Transferring and Syncing Files with Google Drive .....	301
Setting Up Google Drive .....	301
Navigating Google Drive .....	302
Configuring the Cache, Encryption, and Data Usage .....	304
Creating a Folder .....	305
Adding Documents to Google Drive .....	306
Keeping Documents on Your Device .....	306
Printing Documents .....	307
Printing to Local Printers .....	307
Print to an HP Printer Using the HP Print Service Plugin .....	308
Printing to Cloud Printers .....	308
Printing on Your Existing Printer .....	309
Using a Chromecast Device .....	310
Setting Up a Chromecast with Your Android Device .....	311
Casting Your Screen to the Chromecast Device .....	314
Playing Music to the Chromecast Device .....	315

## 10

**Making the Most of Phone and Messaging ..... 317**

Becoming Expert with the Phone App .....	317
Making Calls the Easy Way .....	318
Saving Time with the Call Log and History .....	320
Taking Calls—or Avoiding Them .....	325
Configuring the Phone App to Work Your Way .....	327
Setting Custom Ringtones for Important Callers .....	334
Blocking and Screening Calls .....	335
Setting a SIM Card Lock .....	336
Chatting, Talking, and Conferencing via Hangouts .....	338
Getting an Account .....	339
Getting Started with Hangouts .....	339
Making Hangouts Comfortable for You .....	340
Configuring SMS in Hangouts .....	343
Communicating via Hangouts .....	345

## 11

**Exploiting Camera, Photos, and Videos ..... 353**

Getting Great Photos with the Camera App .....	354
Opening the Camera App and Navigating Its Interface .....	354
Accessing the Camera from the Lock Screen .....	356
Configuring the Camera App to Suit Your Needs .....	357
Taking Regular Photos .....	360
Taking Photo Sphere Photos .....	368
Taking Panorama Photos .....	369

Taking Photos with the Lens Blur Feature.....	369
Editing Your Photos .....	372
Shooting Videos.....	375
Capturing Screenshots .....	376

## **12 Enjoying Your Music Everywhere..... 377**

Understanding Your Options for Listening to Music on Your Device.....	378
Getting Your Music onto Your Device .....	378
Understanding Which Music Formats Your Device Can Play.....	379
Getting Your CDs onto Your Android Device.....	381
Transcoding Existing Files.....	385
Syncing Songs Directly with doubleTwist.....	386
Getting the Most Out of the Play Music App .....	387
Getting Started with Play Music .....	387
Setting Up an Account.....	389
Syncing Your 20,000 Songs to Play Music.....	389
Buying Songs from the Play Store.....	391
Navigating the Play Music App.....	392
Playing Songs.....	394
Downloading Songs.....	396
Deleting Songs from Your Device and Your Library.....	397
Configuring the Play Music App.....	398
Creating Playlists.....	401
Improving Your Music with the Equalizer .....	403
Turning On the Equalizer.....	403
Creating a Custom Equalization.....	405
Using Other Music Apps .....	405
Three Apps for Identifying Music.....	405
Three Streaming Services.....	406

## **13 Staying in Touch via Social Networking ..... 407**

Getting Serious with Facebook.....	407
Making the Right Decision When Logging In.....	408
Getting and Configuring Facebook Messenger.....	409
Making Facebook Work Your Way.....	415
Choosing Essential Privacy Settings.....	417
Securing Your Facebook Account with Two-Factor Authentication.....	426

Using Multiple Facebook Accounts on the Same Device .....	431
Removing Your Facebook Account from Your Device .....	433
Making the Most of Twitter .....	434
Signing In to Twitter .....	434
Navigating the Twitter App .....	435
Configuring the Twitter App .....	437
Securing Your Twitter Account with Login Verification .....	442
Using Multiple Twitter Accounts .....	445
<b>14 Using Samsung TouchWiz .....</b>	<b>447</b>
Getting Up to Speed with TouchWiz Essentials .....	448
Using the Buttons in TouchWiz .....	448
Navigating the Home Screen .....	449
Customizing Your Home Screen .....	450
Using Gestures to Control Your Samsung Device .....	452
Customizing the Apps Screen .....	453
Working with Quick Settings and Settings .....	455
Using the Notifications Panel and the Quick Settings Bar .....	455
Using the Quick Settings Panel .....	457
Navigating the Settings App .....	458
Using the Toolbox .....	460
Using Multi Window .....	462
Understanding the Samsung Hub, S Apps, and Samsung Apps .....	465
Using the Camera App's Extra Features .....	466
Mastering the Essentials of the Camera App .....	467
Making the Most of the Camera Modes .....	468
Setting the Camera to Take the Photos and Videos You Want .....	469
Browsing with Samsung's Internet Browser .....	474
Grasping the Essentials of the Internet App .....	474
Saving Pages and Reading Them Later .....	476
Returning to Web Pages with Bookmarks .....	476
Opening Multiple Windows and Navigating Among Them .....	477
Loading Your Favorite Pages onto the Quick Access Screen .....	478
Adding a Web Page Shortcut to Your Home Screen .....	479
Browsing Incognito .....	479
Syncing Open Pages Through a Samsung Account .....	479

Sharing via S Beam.....	479
Making the Most of the Galaxy Note's S Pen.....	480
Improving Performance by Turning Off TouchWiz Features.....	482

**15****Using HTC Sense ..... 485**

Taking a Five-Minute Tour of the Essentials.....	485
Unlocking Your Phone.....	486
Getting the Hang of the Soft Buttons.....	486
Navigating the Long Screens.....	487
Navigating the Tabs.....	487
Getting to Grips with the Three-Finger Gestures.....	488
Navigating and Customizing the Quick Settings Panel.....	489
Setting Up the Lock Screen on Your HTC Phone.....	490
Making the Most of the Home Screen.....	492
Customizing HTC BlinkFeed.....	494
Putting What You Need on Your Home Screens.....	496
Getting More Out of the Status Bar.....	497
Navigating the Apps Screen.....	498
Sorting the Apps Your Way.....	498
Hiding the Apps You Don't Want to See.....	500
Changing the Grid Size.....	500
Phoning and Gesticulating.....	501
Getting Around the Phone App's Five Tabs.....	501
Using Gestures When Your Phone Rings.....	502
Enjoying Music with the Sense Music App.....	503
Using the Camera's Extra Features.....	505
Shooting with the Camera App.....	506
Configuring the Camera App to Take the Photos You Want.....	507
Choosing Other Settings.....	510
Shooting Both Ways with Dual Capture Mode.....	513
Bringing Scenes to Life with HTC Zoe.....	513

Index.....	515
------------	-----

## ABOUT THE AUTHOR

**Guy Hart-Davis** is coauthor of *My Samsung Galaxy Note 3* and *My HTC One*, and the author of nearly one hundred computer books.

## DEDICATION

*I dedicate this book to my son, Edward, who tests Android<sup>†</sup> hardware and software to destruction so that I don't have to.*

## ACKNOWLEDGMENTS

My thanks go to the people whose hard work helped create this book you're reading. In particular, I'd like to thank the following people:

- Michelle Newcomb, for asking me to write the book.
- William Abner, for developing the outline and content.
- Vince Averello and Christian Kenyeres, for reviewing the manuscript for technical accuracy and contributing suggestions for improving the book.
- Seth Kerney, for coordinating the book project.
- Chuck Hutchinson, for editing the manuscript with a light touch.
- Jess DeGabriele, for proofreading the book.
- Rebecca Salerno, for creating the index.



## WE WANT TO HEAR FROM YOU!

As the reader of this book, *you* are our most important critic and commentator. We value your opinion and want to know what we're doing right, what we could do better, what areas you'd like to see us publish in, and any other words of wisdom you're willing to pass our way.

We welcome your comments. You can email or write to let us know what you did or didn't like about this book—as well as what we can do to make our books better.

*Please note that we cannot help you with technical problems related to the topic of this book.*

When you write, please be sure to include this book's title and author as well as your name and email address. We will carefully review your comments and share them with the author and editors who worked on the book.

**Email:** [feedback@quepublishing.com](mailto:feedback@quepublishing.com)

**Mail:** Que Publishing  
ATTN: Reader Feedback  
800 East 96th Street  
Indianapolis, IN 46240 USA

## READER SERVICES

Visit our website and register this book at [quepublishing.com/register](http://quepublishing.com/register) for convenient access to any updates, downloads, or errata that might be available for this book.

# Introduction



This short introduction is intended to make sure you know the essentials for navigating your Android device.

If you're already familiar with Android, feel free to skip the introduction and dive straight into Chapter 1, "Getting Up to Speed"—or into whichever chapter will be most helpful to you.

## GRASPING THE ESSENTIALS OF ANDROID NAVIGATION

Google has made Android as easy to navigate as possible using straightforward taps and gestures on the touch screen.

This section covers navigating the lock screen, the Home screen, and the Apps screen; opening the Notifications panel and the Quick Settings panel; and opening the Settings app.




## NAVIGATING THE LOCK, HOME, AND APPS SCREENS

As you work with your device, you will likely use three screens the most. These are the lock screen, which protects your security; the Home screen, which is your home base in Android; and the Apps screen, from which you launch the apps you want to use.

### UNLOCKING THE LOCK SCREEN

When you start your Android device, it normally displays the lock screen. This security screen has two purposes: to prevent Android from responding to accidental touches on the screen and (optionally) to make the user authenticate himself by using the unlock method that the owner has set.

You can apply different unlock methods to the lock screen. The default unlock move is a simple swipe that provides no security at all, but you can apply strong security by requiring a PIN or passcode. Figure I-1 shows the lock screen secured with the PIN unlock method.




**FIGURE I-1**

*To unlock a device secured with a PIN, type the PIN at the lock screen and tap the arrow below the 9 button.*

**! CAUTION** You can turn off the lock screen by tapping the None button on the Choose Screen Lock screen in the Settings app. This move is seldom wise except for devices you are using for demonstration purposes.

## GETTING AROUND THE HOME SCREEN AND USING THE BUTTONS

After you've unlocked your device, the Home screen appears. The Home screen is your base for taking actions in Android and typically contains several types of items. Figure I-2 shows a Home screen with its essential parts labeled:



**FIGURE I-2**

*The Home screen consists of a series of horizontal panels that give you access to many different Android features.*

- **Status bar.** The status bar appears at the top of the Home screen and most other screens.
- **Google Search box.** This box enables you to search quickly straight from the Home screen. You can tap the microphone icon and speak your search terms.

- **Clock widget.** A *widget* is a small, single-purpose app, such as the Clock widget shown here. You can put any of a wide variety of widgets on the Home screen to display the information you find useful or entertaining.
- **App icon.** You can place icons for apps on the Home screen so that you can access them quickly.
- **Folder icon.** You can put your Home screen icons into folders to keep them organized.
- **Home screen panel indicator.** The Home screen consists of a series of panels that you can scroll among by swiping or dragging left or right. The larger dot shows the current panel in the series of panels.
- **Apps button.** Tap this button to display the Apps screen (discussed in the next section).
- **Favorites tray.** This tray contains a handful of icons for apps that you want to have available on every Home screen panel.
- **Back button.** Tap this button to return to the previous screen or to cancel out of a dialog box.
- **Home button.** Tap this button to display the Home screen. Android displays whichever Home screen panel you used last. Tap the Home button again to display your main Home screen panel.


**TIP**

Tap and hold the Home button to access the Google Now information feature. You can also tap the Home button and swipe up to access Google Now.

- **Recent Apps button.** Tap this button to display the Recent Apps screen. You can then tap the app you want to display.

## USING THE APPS SCREEN

From the Home screen, tap the Apps button to display the Apps screen. This screen (see Figure I-3) consists of one or more panels among which you can move by dragging or swiping left or right.

**FIGURE I-3**


*On the Apps screen, drag or swipe left or right to find the app you want, and then tap its icon.*

When you find the app you want to use, tap its icon. That app's screen then appears.

## OPENING THE NOTIFICATIONS PANEL

The Notifications panel contains notifications raised by apps to alert you to events. For example, when you receive a message in Gmail, the Gmail app raises a notification in the Notifications panel. Similarly, when Android detects that a software update has become available, it displays a notification to let you know about the update.

To open the Notifications panel (shown in Figure I-4), drag or swipe down from the top of the screen with one finger. On a phone, you can drag or swipe down on the left, in the middle, or on the right; on a tablet, drag or swipe down in the left half of the top of the screen. You can then view your notifications, deal with any that need your attention, and close the Notifications panel again by dragging or swiping upward.

**FIGURE I-4**


*Drag or swipe down from the top of the screen to open the Notifications panel.*

## OPENING THE QUICK SETTINGS PANEL

The Quick Settings panel is a screen that gives you swift access to frequently used settings. You can open the Quick Settings panel in any of these three ways:

- Pull down from the top of the screen with two fingers on a phone.
- Pull down in the right half of the top of the screen with one finger on a tablet.
- Open the Notifications panel and then tap the Quick Settings Panel icon in its upper-right corner.

Figure I-5 shows the Quick Settings panel on a phone.

**FIGURE I-5**

*The Quick Settings panel gives you instant access to essential settings.*

To close the Quick Settings panel, drag or swipe up.

**TIP**

On a phone, tap the Notifications Panel button to switch from the Quick Settings panel to the Notifications panel.

## OPENING THE SETTINGS APP

Android has a vast number of settings that you can customize to configure your device the way you want it. You configure most of the settings through the Settings app. You can open the Settings app in three easy ways, as explained next. From here on, this book tells you to “Open the Settings app” rather than telling you which way to open it.



The quickest way to open the Settings app is to use the Quick Settings panel:

1. Open the Quick Settings panel by pulling down from the top of the screen with two fingers on a phone or with one finger on the right side of the top of the screen on a tablet.
2. Tap the Settings icon to open the Settings app.

Alternatively, you can open the Settings app from the Notifications panel:

1. Pull down from the top of the screen with one finger to open the Notifications panel.
2. Tap the Quick Settings icon to display the Quick Settings panel.
3. Tap the Settings icon to open the Settings app.

Or you can simply open the Settings app from the Apps screen like any other app:

1. Tap the Home button to display the Home screen.
2. Tap the Apps icon to display the Apps screen.
3. Tap the Settings icon to open the Settings app.



## NOTE


Some Android skins make major changes to the Settings app, so if your device uses a skin, you may need to find your own way to the settings. See Chapter 14, “Using Samsung TouchWiz,” and Chapter 15, “Using HTC Sense.”

## USING THE MENUS, CONTROLS, AND DIALOG BOXES

To enable you to give commands easily and clearly, Android uses menus, controls such as check boxes and radio buttons, and dialog boxes.

### USING THE MENU


Many apps include a Menu button that you can tap to display a menu of commands. For example, in Google’s browser app, Chrome, you tap the Menu button (an icon with a vertical line of three dots) to display the menu (see Figure I-6), and then tap the command you want to use.

**FIGURE I-6**

*Tap the Menu button (the three dots) to open the menu, and then tap the command.*

## WORKING WITH CONTROLS

Android uses check boxes to enable you to turn individual options on and off. For example, in Figure I-7, the *Swipe to Archive* box and the *Sender Image* box are checked, indicating that these options are turned on, while the *Reply All* box is unchecked, meaning that this option is turned off.


**FIGURE I-7**

*Tap a box to check it (turning the option on) or uncheck it (turning the option off).*

**NOTE**

This book uses the term *check* to mean tapping a box to put a check mark in it and the term *uncheck* to mean tapping a box to remove the check mark from it. If the box is already checked or unchecked (as appropriate), you don't need to change the setting.

Android uses groups of radio buttons to enable you to make a choice among two or more mutually exclusive options. For example, in the Archive & Delete Actions dialog box shown in Figure I-8, the Show Archive Only radio button is selected, showing the blue circle. Tapping the Show Delete Only radio button or the Show Archive & Delete radio button deselects the Show Archive Only radio button, because only one radio button in the group can be selected at any time.



The image shows a dialog box with a light gray background and a thin blue border. At the top, the title 'Archive & delete actions' is written in a blue sans-serif font. Below the title is a horizontal blue line. There are three rows of radio button options, each with a text label on the left and a radio button on the right. The first row is 'Show archive only' with a selected radio button (a blue dot in the center). The second row is 'Show delete only' with an unselected radio button (an empty circle). The third row is 'Show archive & delete' with an unselected radio button. At the bottom of the dialog box is a single button labeled 'Cancel' in a gray sans-serif font.

Archive & delete actions	
Show archive only	<input checked="" type="radio"/>
Show delete only	<input type="radio"/>
Show archive & delete	<input type="radio"/>
Cancel	

**FIGURE I-8**

*Tap a radio button to select that option, deselecting whichever other option in the group is currently selected.*


## MAKING CHOICES IN DIALOG BOXES

When you need to make a decision, Android displays a dialog box to present the choices clearly. You can't take other actions until you have dismissed the dialog box.

If a dialog box contains only radio buttons, as in Figure I-8, tapping a radio button closes the dialog box.

Otherwise, you normally tap a command button, such as the OK button or the Cancel button, to dismiss the dialog box. For example, in the Ringtones dialog box (see Figure I-9), you tap a radio button to select the ringtone you want to use, but the dialog box remains open. You then tap the OK button to close the dialog box, accepting the choice you have made, or tap the Cancel button to close the dialog box without making a choice.

Some dialog boxes appear only to confirm an action you have taken and so contain only an OK button.

**FIGURE I-9**

*Many dialog boxes contain command buttons, such as the OK button and Cancel button shown here.*

## USING THE TOUCHSCREEN

Android uses seven main gestures on the touchscreen:

- **Tap.** Tap the screen and then lift your finger.
- **Tap and hold.** Tap the screen and keep your finger on it, usually until a menu appears or another change occurs. This action is also called “long-press.”
- **Double-tap.** Tap the screen twice in rapid succession.
- **Drag.** Tap an item on the screen, keep your finger on the screen, and then drag the item to its destination. In many cases, you need to tap and hold for a moment before the item becomes free for dragging.
- **Swipe.** Move your finger left, right, up, or down across the screen.
- **Pinch in.** Place your finger and thumb (or two fingers, if you prefer) apart on the screen and then pinch them together. This action is often used for zooming out (for example, on a map or a photo).

- **Pinch out.** Place your finger and thumb (or two fingers) together on the screen and then spread them apart. This action is often used for zooming in.

## Preventing the Screen from Rotating

Most Android devices include sensors (such as accelerometers) that detect the device's orientation. Android can automatically rotate the display to match the way the screen is pointing.

This automatic rotation is often handy, but you may want to turn it off at times, such as when you are holding your device nearly flat rather than upright. To turn off automatic rotation, open the Settings app, tap the Display button, and then uncheck the Auto-Rotate Screen box.

*This page intentionally left blank*

## IN THIS CHAPTER

- Identifying skins, managing notifications, and entering text
- Setting up a tablet for multiple users
- Optimizing battery performance and managing storage

# 1



## GETTING UP TO SPEED

This chapter will get you familiar with your Android device so that you can get the most benefit out of the rest of this book. You'll start by establishing which version of Android your device is running and whether it uses stock Android or a skin. You'll then move into setting volume levels for your various audio sources; managing your notifications; and entering text using the onscreen keyboard, hardware keyboards, and dictation. After that, it's time to examine how you set up a tablet for multiple users, get the best battery performance from your device, and manage files and storage on it.

## IDENTIFYING YOUR DEVICE'S ANDROID VERSION AND ITS SKIN

At this writing, you can choose from a vast range of devices that run the Android operating system (OS). These devices not only have widely varying capabilities but also run different versions of Android. To make matters even more confusing, many devices also use what's called a *skin*, a layer





of software that runs on top of the Android OS, makes it look different, and gives it additional capabilities.

All this means that, to get the most out of this book, you need to know not only exactly what device you have but what version of Android it’s running—and what skin, if any. Armed with this knowledge, you can identify which tips and tricks apply to your device, its version of Android, and its skin.

UNDERSTANDING ANDROID VERSION NUMBERS AND NAMES

Table 1.1 shows Android’s versions as of fall 2014, starting with the latest version. Each version has a number and a name. For example, the latest version is Android 4.4, which is called KitKat; Android 5.0, Lollipop, is imminent.

Table 1.1    Android Version Numbers and Names

Version Numbers	Version Name
4.4	KitKat
4.1–4.3	Jelly Bean
4.0	Ice Cream Sandwich
3.0–3.2.6	Honeycomb
2.3	Gingerbread
2.2	Froyo
2.0–2.1	Éclair
1.6	Donut
1.5	Cupcake

At this writing, the current version of Android is KitKat (4.4). Jelly Bean (versions 4.1–4.3) is widely used, but so is Ice Cream Sandwich. Some Honeycomb (versions 3.0–3.2.6) are still in use.

FINDING OUT WHICH ANDROID VERSION YOUR DEVICE IS RUNNING

To find out which version of Android your device is running, follow these steps:

1. Open the Settings app.
2. Scroll down to the bottom of the list.

3. Tap the About Phone button or the About Tablet button to display the About Phone screen or the About Tablet screen. (On some devices, the button and screen may be called About Device.)
4. Look at the Android Version readout. You'll see a number such as 4.4.2 (which means your device is running KitKat) or 4.0.4 (which indicates Ice Cream Sandwich).


## ESTABLISHING WHETHER YOUR DEVICE IS USING A SKIN

A skin is an extra layer of software that makes the Android user interface look different and work differently. Skins typically provide extra functionality that is not available in stock Android, so by adding a skin, a manufacturer can provide extra features to a device, make it more attractive, or make it easier to use.

These are all points in favor of skins. But because implementing a skin involves running extra software, a skin tends to make your Android device respond more slowly. If the device has a powerful processor and plenty of RAM, it may have enough punch to run Android and the skin without slowing down. But if the device is underpowered, a skin may make it slow and cumbersome to use.

Google periodically issues new versions of Android with new features, new looks, or other improvements. If you have one of Google's branded devices, such as the Nexus 5 phone or the Nexus 7 tablet, you can update to the newest version immediately. By contrast, manufacturers that provide custom versions of Android need to create new custom versions for their devices, which takes time and money. So if your device has a skin, you will likely have to wait months before a new version becomes available—and that's for one of the manufacturer's latest or biggest-selling devices. For older or lesser devices, manufacturers may not provide updated versions of Android.

The easiest way to tell whether your device has a skin is to see whether it's different from the stock Android screens shown in most of this book. For example, Figure 1.1 shows the Settings screen in stock Android on the left and the Settings screen in Samsung's TouchWiz skin on the right. You can clearly see the huge differences between the two.

**FIGURE 1.1**

*Samsung's TouchWiz skin (right) makes huge visual changes from stock Android (left).*

## Tips for Choosing an Android Device

If you're looking for an Android device, take your time because there's a wide array of options. Here are four suggestions to help:


- **Android version.** If possible, get a device that has the latest version of Android. At this writing, that means KitKat (Android 4.4). You can get bargains on older devices, but be clear that you may not be able to update them to newer versions of Android.
- **Battery.** If you plan to use your device extensively, look for a model that enables you to easily change the battery.
- **Budget device.** When buying a budget Android device, choose a vanilla device—one without a skin—for better performance. A vanilla device is also more likely to receive Android OS updates quickly than a device with a skin.
- **SD card.** Look for one that accepts an SD card so that you can easily increase the storage, load your media files, and switch quickly between libraries of content.

## SETTING DIFFERENT VOLUME LEVELS FOR DIFFERENT AUDIO SOURCES

Android enables you to set different volume levels for media playback, ringtones and notifications, and alarms. You can adjust the levels to make sure that notifications don't swamp the music you're enjoying and that alarms are loud enough to wake you or get your attention.

Here's how to set different audio levels for different audio sources:

1. Open the Settings app.
2. Tap the Sound button in the Device section to display the Sound screen.
3. Tap the Volumes button to display the Volumes dialog box (see Figure 1.2).



**FIGURE 1.2**

*Drag the sliders in the Volumes dialog box to set the relative volumes for media playback, ringtones and notifications, and alarms.*



### NOTE

The Volumes dialog box on your device may display a different number of sliders than Figure 1.2 shows. For example, it may have a Ringtone slider and a Notifications slider instead of a Ringtone & Notifications slider.

4. Drag the sliders for Music, Video, Games, & Other Media; Ringtone & Notifications; and Alarms.
5. Tap the OK button.

## MANAGING YOUR NOTIFICATIONS

Android displays notifications to help you keep up with your messages, appointments, and other events. You can choose which apps can give you notifications. If your device has a notification light, you can control whether Android pulses the light to make you aware of notifications you have not yet viewed.

## RESPONDING TO A NOTIFICATION

When an app raises a notification, the notification appears briefly at the top of the screen and then disappears. Drag down from the top of the screen to display the Notifications pane (see Figure 1.3). You can then take the following actions:


- Tap a button on the notification to take an action. For example, on a Missed Call notification, you can tap the Call Back button to return the call or tap the Message button to send a message to the caller.
- Swipe a notification left or right to dismiss it.
- Tap the Clear All button (the button that shows three horizontal bars staggered like a staircase) to clear all the notifications you can dismiss.



### NOTE

You cannot dismiss system notifications such as the Connected as a Media Device notification shown in Figure 1.3.

- If the notification is collapsed, tap it and drag down to expand it.
- Tap and hold the notification until the App Info pop-up button appears, and then tap the button to display the App Info screen for the app.
- Tap a notification to go to the app that raised it.

**FIGURE 1.3**

*Tap a notification in the Notifications pane to go to the app that raised the notification.*

## Catching Up with Notifications You Missed

If you clear all notifications by mistake, or you clear them deliberately and realize that you didn't read something vital, don't worry—you can easily catch up with them by using a Settings Shortcut widget to display the Notifications screen.

Tap and hold empty space on the Home screen until the customization controls appear; then tap the Widgets icon to display the widgets list. Tap and hold the Settings Shortcut widget until it appears on the Home screen. When you lift your finger, the Settings Shortcut screen appears. Tap the Notifications button to make the Settings Shortcut widget take you to the Notifications screen.

You can now tap your Notifications widget to display the Notifications screen. This screen shows all your recent notifications, so you can easily catch up on what you missed. You can tap a notification to display the App Info screen for the app that raised the notification, not to go to the app itself.

Android clears the Notifications screen when you restart your device.

## TURNING THE NOTIFICATION LIGHT ON OR OFF

If your device has a notification light, you can make the light blink to alert you to notifications you haven't yet seen. Here's how to control whether the light blinks:

1. Open the Settings app.
2. Tap the Display button to go to the Display screen.
3. Tap to check or uncheck the Pulse Notification Light check box.

## TURNING OFF NOTIFICATIONS FOR AN APP

Here's how to turn off notifications for an app:

1. Open the Settings app.
2. Tap the Apps button in the Device section to display the Apps screen. The Apps screen displays the Downloaded tab at first.
3. If the app for which you want to turn off notifications does not appear on the downloaded tab, swipe left once to display the Running tab or twice to display the All tab.
4. Tap the app's button to display its App Info screen.
5. Tap to clear the Show Notifications check box.



### TIP

Here are two ways to quickly display an app's App Info screen. If the app is currently running, tap the Recent Apps button, tap and hold the app's thumbnail in the Recent Apps list, and then tap the App Info button on the pop-up menu. If the app has raised a notification, tap and hold the notification on the Notifications panel, and then tap the App Info button on the pop-up menu.


## CLEARING REPEAT NOTIFICATIONS

Sometimes Android may display the same notifications repeatedly. Usually, this happens with download notifications, but other apps can also raise notifications more than once.

If you find this happening, first restart your device. Restarting can solve any number of problems, and it takes only a minute or two.

If restarting doesn't suppress old download notifications, you may need to clear the cache and data for the Download Manager app. To do so, follow these steps:

1. Open the Settings app.
2. Tap the Apps button in the Device section to display the Apps screen.
3. Swipe left twice to display the All list.
4. Tap the Download Manager button to display the App Info screen for the Download Manager app.
5. Tap the Clear Cache button to clear the cached data.
6. Tap the Clear Data button. The Delete App Data? dialog box opens (see Figure 1.4).

**FIGURE 1.4**

*You may need to delete the app data for the Download Manager app to get rid of repeated download notifications.*

7. Tap the OK button.
8. Tap the Force Stop button. The Force Stop? dialog box opens.
9. Tap the OK button.

Restart your phone after clearing Download Manager's cache and data.

**TIP**

Another way to clear old notifications is to install a notification-management app. You can find various notification-management apps on the Play Store, but watch out for two things. First, make sure the app doesn't require Internet access. Second, make sure that the app doesn't require your phone to be rooted. Rooting gives you access to the root account, which enables you to take full control of your device's software and hardware and install unapproved software on it.



## ENTERING TEXT

To enter text on your Android device, you can use the onscreen keyboard, a hardware keyboard, or dictation. You can also enter emoticons to liven up your messages or documents.

## USING THE KEYBOARD AND SPELLING CORRECTION

The most straightforward means of entering text in a document is the onscreen keyboard. Android automatically displays the onscreen keyboard when you touch a text field in a document or the user interface. The keyboard has a letters layout, a symbols and numbers layout, and an extended symbols layout.

Here's what you need to know about the keyboard:


- **Switch among layouts.** Tap the ?123 button to display the symbols and numbers layout. From there, tap the ABC button to return to the letters layout or tap the =< button to display the extended symbols layout. From the extended symbols layout, tap the ABC button to display the letters layout or tap the ?123 button to return to the symbols and numbers layout.



### NOTE

You can hide the keyboard by tapping the Back button (this button appears as a downward-caret icon when the keyboard is displayed). You may want to hide the keyboard so that you can read larger amounts of text or navigate to other text fields. To display the keyboard once more, tap in the text field again.

- **Type numbers from the letters keyboard.** The top row of letters on the letters layout has a number in the upper-right corner, from 1 on the Q key to 0 (zero) on the P key. To type the number, tap and hold the appropriate key until the pop-up panel appears, and then lift your finger. Some of the pop-up panels also contain alternate characters (discussed next), but the numbers are the default characters.
- **Type alternate characters.** The vowel keys, some letter keys (such as N, S, and C), and many of the symbol keys give access to pop-up panels containing alternate characters. For example, tapping and holding the A key opens a pop-up panel with alternate characters such as ã and æ (see Figure 1.5); and tapping and holding the asterisk key gives you access to star, dagger, and double-dagger symbols. So when you need to type a character that does not appear on any of the keyboard layouts, tap and hold the key for the base character, and then tap the character on the pop-up panel.

**FIGURE 1.5**

*Tap and hold a character to display a pop-up panel of alternate characters, and then tap the character that you want to enter.*

- **Type real fractions.** To type a real fraction, display the symbols and numbers layout, tap and hold the number key for the first part of the fraction, and then tap the fraction on the pop-up menu that appears. For example, tap and hold the 1 key to type  $\frac{1}{2}$ , or tap and hold the 5 key to type  $\frac{5}{8}$ .
- **Type quickly with Gesture Typing.** The Gesture Typing feature enables you to type words by sliding your finger from one letter to another over the keyboard without removing it. At the end of a word, you can either swipe over the spacebar to type a space and continue swiping the next word, or lift your finger off the screen and then put it back down to start the next word.

## Turning On Gesture Typing and Configuring It

If Gesture Typing doesn't work on your device, you may need to turn it on. You may also need to configure it to work the way you prefer. Follow these steps:

1. Tap and hold the key to the left of the spacebar on the keyboard. Depending on your device and the keyboard, this may be the comma key or the Voice Input key (the microphone icon).
2. When the Settings icon appears, release the button to display the Input Options menu.

3. Tap the Google Keyboard Settings button to display the Google Keyboard Settings screen.
4. Select the Enable Gesture Typing check box to turn on Gesture Typing.
5. Select the Dynamic Floating Preview check box if you want to see a preview of the word as you slide.
6. Select the Phrase Gesture check box if you want to be able to type spaces by sliding your finger over the spacebar.
7. Tap the Back button to return to the document you were working in.

- **Using suggestions.** By default, the Google Keyboard displays suggestions as you type in the area above the top row of the keyboard. The suggestion with three dots below it is the default one; you can enter this word by tapping the spacebar or a punctuation key (such as the period key). You can enter another suggestion by tapping it. To see the full list of suggestions, tap and hold any of the suggestions until the pop-up panel appears (see Figure 1.6).



**FIGURE 1.6**

*Tap and hold a suggestion to display the full list of suggestions. You can then tap a suggestion to insert it in the document.*


## CONFIGURING TEXT CORRECTION

Android's Text Correction feature automatically corrects words and phrases you type that appear to be wrong. You can control how aggressively Text Correction

corrects text, so if you find Android changing too many words and phrases that you actually want to use, try turning down the degree of correction.

Here's how to configure Text Correction:

1. Open the Settings app.
2. Tap the Language & Input button in the Personal section to display the Language & Input screen.
3. Tap the Settings button (the sliders icon) to the right of the Google Keyboard button in the Keyboard & Input Methods section. The Google Keyboard Settings screen appears. Figure 1.7 shows the Text Correction section of this screen.



**FIGURE 1.7**

*Use the controls in the Text Correction section of the Google Keyboard Settings screen to configure automatic corrections, correction suggestions, and add-on dictionaries.*

4. Check the Auto-Capitalization check box in the General section if you want Android to automatically capitalize the first letter of each sentence or new paragraph.

**TIP**

If you want to load or remove add-on dictionaries, tap the Add-On Dictionaries button on the Google Keyboard Settings screen. On the Add-On Dictionaries screen that appears, tap the Refresh button to get the latest list of add-on dictionaries. You can then install an add-on dictionary by tapping its button and then tapping the Install button that appears, or delete a dictionary by tapping its button and then tapping the Delete button that appears.

5. Check the Block Offensive Words check box if you want Android to suppress words that some people may find offensive.
6. Tap the Auto-Correction button to display the Auto-Correction dialog box, and then tap the option button for the degree of correction you want: Off, Modest, Aggressive, or Very Aggressive. You'll probably want to experiment with the Modest and Aggressive settings to see which suits you best.
7. To control whether Android displays correction suggestions, tap the Show Correction Suggestions button, and then tap the appropriate button in the Show Correction Suggestions dialog box: Always Show, Show in Portrait Mode, or Always Hide.

**TIP**

The Show in Portrait Mode setting for Show Correction Suggestions is useful on phones and small tablets, on which the keyboard and correction suggestions together take up much of the screen in landscape mode.

8. Check the Personalized Suggestions check box if you want Google Keyboard to learn words and phrases from what you type. Personalized suggestions are usually helpful.

## ADDING WORDS TO YOUR PERSONAL DICTIONARY

Android enables you to maintain a personal dictionary containing words that are correctly spelled but do not appear in Android's dictionary. By adding words to your personal dictionary, you can prevent Android from querying them. You can also create a shortcut for any word or phrase so that you can enter it by typing the shortcut.

1. Open the Settings app.
2. Tap the Language & Input button in the Personal section to display the Language & Input screen.

3. Tap the Personal Dictionary button to display the Personal Dictionary screen.
4. Tap the + button to display an input screen.
5. Type the word or phrase on the upper line.
6. Tap the Shortcut field and type any shortcut you want to use for the word or phrase.
7. Tap the Back button to finish adding the word.

**TIP**

You can also add a word to the personal dictionary when typing. Finish typing the word but don't type a space or punctuation. Tap the word in the suggestions bar, and then tap the Touch Again to Save prompt that appears. (On some devices, you may not see the Touch Again to Save prompt.)

**NOTE**

To edit or delete a word or shortcut, tap it on the Personal Dictionary screen. Android opens the word for editing. You can then change the word or shortcut or tap the Delete icon (the trash can) to delete it.

## ENTERING TEXT USING A HARDWARE KEYBOARD

The stock Android onscreen keyboard is easy enough to use, but very few people are able to touch-type on it, especially on a phone rather than a tablet. So if you need to type large amounts of text on your Android device, you should think seriously about connecting a hardware keyboard to it.

You can connect a wide variety of keyboards via either Bluetooth or a cable. Bluetooth is handy, especially if you get a Bluetooth keyboard built into a case that fits your device. See Chapter 4, “Connecting to Networks and Devices,” for instructions of connecting Bluetooth devices.

But if you simply need to enter a lot of text quickly, any regular USB keyboard will do the trick as long as your device supports the USB On-the-Go standard. Get a USB A female to micro USB B male adapter cable that also supports USB OTG, plug the keyboard into the USB female port, and plug the micro USB jack into your device.



NOTE

USB OTG is short for USB On-The-Go. USB OTG enables a device (such as an Android phone or tablet) to act as a USB host, so you can plug in USB hardware and use it.

After connecting a hardware keyboard, you can use the keyboard shortcuts explained in Table 1.2 to navigate through text.

Table 1.2 Keyboard Shortcuts for Hardware Keyboards

Keyboard Shortcut	What It Does
Left arrow	Moves the insertion point one character to the left.
Right arrow	Moves the insertion point one character to the right.
Up arrow	Moves the insertion point up one line.
Down arrow	Moves the insertion point down one line.
Ctrl+Left arrow	Moves the insertion point to the beginning of the current word (if the insertion point is within a word) or to the beginning of the previous word (if it is not).
Ctrl+Right arrow	Moves the insertion point to the beginning of the next word.
Alt+Left arrow	Moves the insertion point to the beginning of the line.
Alt+Right arrow	Moves the insertion point to the end of the line.
Alt+Up arrow	Moves the insertion point to the beginning of the document or text field.
Alt+Down arrow	Moves the insertion point to the end of the document or text field.
Alt+Delete	Deletes the current line.
Ctrl+A	Selects all the content of the document or the active field.
Ctrl+C	Copies the selection (if there is one) or the entire document (if not).

Keyboard Shortcut	What It Does
Ctrl+X	Cuts the selection (if there is one) or the entire document (if not).
Ctrl+V	Pastes the most recent Clipboard item.

**TIP**

You can select text using the keyboard by holding down Shift while you press the navigation keys or keyboard shortcuts. For example, press Shift+Right arrow to select the character to the right of the insertion point (or to extend the existing selection by one character to the right) or press Shift+Alt+Right arrow to select from the insertion point's current position to the end of the line.

## Changing the Layout of a Hardware Keyboard

After connecting a hardware keyboard, you can change the layout if necessary. For example, you may prefer the Dvorak layout to QWERTY, or you may want the layout for a different language or region.

Open the Settings app, tap the Language & Input button, and then go to the Physical Keyboard section of the Language & Input screen.

Tap the keyboard's button (this shows the keyboard's description, such as Logitech USB Keyboard) to display the Choose Keyboard Layout dialog box. If the layout you want appears, tap it to apply it. If not, tap the Set Up Keyboard Layouts button to display the Keyboard Layouts screen, and then tap the check box for each keyboard layout you want to make available.

Tap the Back button, tap the appropriate keyboard in the Choose Keyboard Layout dialog box, and then start typing using that layout.

## ENTERING TEXT USING DICTATION

Typing is the standard way of entering text, but you may be able to enter text more quickly—and accurately—by using the Google Voice Typing feature.

Google Voice Typing may already be set up on your phone or tablet. If so, you're good to go, but you may want to set up your input languages or install offline speech recognition.



Follow these steps to set up and configure Google Voice Typing:

1. Open the Settings app.
2. Tap the Language & Input button in the Personal section to display the Language & Input screen.
3. Check the Google Voice Typing check box.
4. Tap the Settings button on the right of the Google Voice Typing button to display the Google Voice Typing Settings screen.
5. If you want to select input languages, tap the Choose Input Languages button and work on the Choose Input Languages screen.
6. Check the Block Offensive Words check box if you want Google Voice Typing to censor your input.
7. Tap the Offline Speech Recognition button to display the Download Languages screen. This screen has three tabs: Installed, All, and Auto-Update. The Installed tab appears first.
8. Review your current languages on the Installed tab.
9. If you need to install another language for offline speech recognition, tap the All tab, and then tap the language you want to download and install.
10. Tap the Auto-Update tab to reveal its controls, and then tap the option button for the way you want to update. Your choices are Do Not Auto-Update Languages; Auto-Update Languages At Any Time; Data Charges May Apply; and Auto-Update Languages over Wi-Fi Only.

**TIP**

The Auto-Update Languages over Wi-Fi Only setting is the best choice for keeping your Google Voice Typing languages up to date without incurring data charges from downloading over the cellular network.

After you've turned on Google Voice Typing, tap the microphone button to the left of the spacebar on the onscreen keyboard to start dictation.

**TIP**

If you plan to dictate a lot, use a high-quality headset microphone. Google Voice Typing delivers impressive results with just the open microphone built into your device, but you can get much clearer input by using a headset microphone.

## ENTERING EMOJI


The Google Keyboard provides a large selection of emoticons that you can enter in your messages and documents. To access the emoticons, tap and hold the Enter key at the lower-right corner of the onscreen keyboard, and then tap the smiley-face icon on the pop-up panel.



### NOTE

Depending on your device and keyboard configuration, you may be able to access emoticons by tapping an emoticon key that appears on the keyboard or by tapping and holding the key to the left of the keyboard and then tapping the Emoticons button on the pop-up panel.

With the emoticons displayed (see Figure 1.8), tap the Tab button for the category you want to view, and then scroll right to see further characters. Tap the Recents tab button (the leftmost button, with the clock icon) to see the characters you've used recently. Tap the ABC button to return to the letters keyboard.



**FIGURE 1.8**

*You can easily enter emoticons in your messages and documents by using the Google Keyboard.*

## USING ALTERNATIVE KEYBOARDS

If you find the Google Keyboard difficult to use, you can install another keyboard that suits you better. You'll find a wide variety of alternative keyboards in the Play Store. Here are three alternative keyboards to consider:

- Hacker's Keyboard (free) is a highly customizable keyboard that includes keys you normally find on hardware keyboards, such as Ctrl and Tab, but not on Android keyboards. This keyboard is great for remote access to computers.
- SwiftKey is a trace keyboard (like the Gesture Typing feature on the Google Keyboard) with strong predictive text features. Download the SwiftKey Trial app to give the keyboard a spin and see if you want to pay for the full version.
- Smart Keyboard Pro (\$2.75) is a customizable keyboard that includes skins for different looks and optional transparency. You can customize the key height separately for portrait and landscape orientations; hide the period and comma keys; and switch among Normal mode, T9 mode, and Compact mode. Smart Keyboard Pro includes a calibration tool that you can run to improve accuracy if you find you tend to tap the wrong keys. Download the free Smart Keyboard Trial to test; you can then pay for the upgrade to Pro if you like it.

## SETTING UP A TABLET FOR MULTIPLE USERS

Android includes multiuser features for tablets, so if you have a tablet, you can set it up with a separate account for each user. By creating user accounts, you give each user his own home screen, settings, and storage for documents. Each user can send and receive email and browse the Web without sharing his messages and history with other users. Each user can choose a different unlock method to keep his data safe.

Instead of creating a user account for another person, you can create a *restricted profile*, a kind of limited account that enables the user to access only some apps and content on your account. Like a user account, a restricted profile has a separate space and data on the tablet. You might want to create a restricted profile for a child that you allow to occasionally use your tablet.

## CREATING A USER ACCOUNT


When you create a new user account, it is best to have the person who will use the account with you so that she can set up the account immediately. In this way, you can ensure that the right person sets up the user account; you can also insist that the person sets an unlock method on the account to help protect the tablet.

If you must set up the new user account when the person is not available, the account appears on the lock screen without a security method. Anyone with

access to the tablet can set up the user account, and there is no obligation to set an unlock method.

Here's how to create a user account:


1. Open the Settings app.
2. Tap the Users button in the Device section to display the Users screen.
3. Tap the Add User or Profile button to display the Add dialog box (see Figure 1.9).



**FIGURE 1.9**

*In the Add dialog box, tap the User button to start creating a new user account on your tablet.*


4. Tap the User button to display the Add New User dialog box (see Figure 1.10).



**FIGURE 1.10**

*Tap the OK button in the Add New User dialog box.*

5. Tap the OK button. Android displays the Set Up User Now? dialog box (see Figure 1.11).

**FIGURE 1.11**

*In the Set Up User Now? dialog box, tap the Set Up Now button if the user is available to set up her user account. Otherwise, tap the Not Now button.*

6. If the user is with you and can set up the account now, tap the Set Up Now button and hand over the tablet to the user. Otherwise, tap the Not Now button.
7. Assuming you tap the Set Up Now button, the lock screen appears, showing an account button called New User. This account button is selected automatically. The user can swipe to unlock the screen, tap the Next button on the Welcome screen that appears, and then follow through the steps to set up the account.

If you tap the Not Now button in the Set Up User Now? dialog box, the user account appears in the Users & Profiles list on the Users screen as New User, Not Set Up. When the user is present and can set up the account, lock the tablet by opening the Quick Settings panel and tapping your account picture. The user can then tap the New User icon, swipe to unlock the screen, and follow through the screens to set up the account.


## Understanding Owner and Nonowner Accounts

To create a new user account on your tablet, you must log in using the owner account. This is the account you used when you first set up the tablet. As long as that account is the only account that your tablet contains, there's no confusion; but if your tablet already contains multiple user accounts, and you find that the Add User or Profile button does not appear on the Users screen, the reason is most likely that you are using a nonowner account.

## CREATING A RESTRICTED PROFILE

Here's how to create a restricted profile for a user:

1. Open the Settings app.
2. Tap the Users button in the Device section to display the Users screen.
3. Tap the Add User or Profile button to display the Add dialog box.
4. Tap the Restricted Profile button to display the Application and Content Restrictions screen (see Figure 1.12).



**FIGURE 1.12**

*On the Application and Content Restrictions screen, choose which apps to make available in the restricted profile.*

## Setting a Screen Lock to Protect Your Apps and Data

For the restricted profile feature to work, you must use a screen lock to protect your apps and data. So if you haven't yet set a screen lock, Android prompts you to set a lock when you tap the Restricted Profile button in the Add dialog box. Tap the Set Lock button to display the Unlock Selection screen, tap the lock type you want (Pattern, PIN, or Password), and then follow through the steps for setting the lock. Android then displays the Application and Content Restrictions screen, and you can continue with step 5 in the main text.

5. Tap the New Profile button at the top to display the Profile Info dialog box.
6. To add a custom icon to the profile, tap the default icon on the left side of the dialog box, tap the Take Photo button or the Choose Photo from Gallery button on the pop-up menu, and then take the photo or select the existing photo to use. You can then crop the photo as needed.
7. Type the name for the profile, replacing the default name, New Profile.
8. Tap the OK button to close the Profile Info dialog box and apply the name.
9. Touch the Settings icon to the left of the On/Off switch on the Settings button to display the list of settings. You can then tap a check box to control whether the user can use the feature. For example, select the Location check box to enable the user to use the Location feature.
10. Specify which apps you want the user to be able to use by setting its switch to the On position. Make sure the switch for each app you don't want the user to use is set to the Off position.
11. Tap the Back button to return to the Users screen.

## SWITCHING AMONG USER ACCOUNTS AND PROFILES

After you set up an account for each full user and a restricted profile for each person who needs less freedom, you can easily switch among the accounts and profiles. Follow these steps:

1. Pull down from the upper-right corner of the screen to display the Quick Settings panel.
2. Touch your user account icon to lock the tablet. The lock screen appears, showing the list of users as circular buttons at the bottom. The larger circle indicates the last user. The lock screen shows that user's lock screen wallpaper and unlock method (for example, swipe or password).

**TIP**

You can also lock your tablet by pressing the Power button briefly. The tablet turns off, and the screen goes dark. Press the Power button again to wake the tablet. The lock screen appears, and you can choose which account or profile to use.

3. Tap the button for the user account or restricted profile to which you want to switch. The circle for that account or profile grows larger, and the lock screen changes to show the wallpaper and unlock method set for that account or profile.
4. Unlock the screen by using that unlock method. For example, type the password and press the Enter key.

## DELETING A USER ACCOUNT OR RESTRICTED PROFILE

If you no longer need a particular user account or restricted profile, you can delete it from your tablet. Follow these steps:

1. Open the Settings app.
2. Tap the Users button in the Device section to display the Users screen.
3. Tap the Delete icon (the trash can) on the button for the account. The Remove User? dialog box or the Remove Profile? dialog box opens, warning you that the user's or profile's space and data will disappear from the tablet.
4. Tap the Delete button to finish removing the user account or profile.

## UNDERSTANDING AND AVOIDING PROBLEMS

Sharing a tablet with others can be a great way to get more computing out of your hardware budget, but it may bring some problems with security, storage space, and performance.

Apart from actually having to share the physical device, you need to ensure security for your data and that of each user. Make sure you lock the tablet consistently so that nobody can access it without entering a PIN or passcode.

Be aware that each user can accept updated app permissions for the tablet as a whole. This means you should create full user accounts only for people you can trust to deal sensibly with app updates.

With several users storing data and files (especially media files) on the tablet, space may run low. You will need to manage the device's storage using the techniques discussed later in this chapter.



If several users have sessions open at the same time, the tablet may start running more slowly because it is low on memory. You can try closing apps, or getting other users to close their apps so yours will run better, but you will normally be better off restarting the tablet.

## GETTING THE BEST BATTERY PERFORMANCE

To get the most use out of your Android phone or tablet, you will need to manage its battery life. You can do this using either the tools that come with the device or with extra tools that you add. You can identify features and apps that consume large amounts of power so that you can either disable them or simply not use them. You can reduce the amount of power your device needs by choosing settings to spare power. And you can give yourself the means to recharge your device at every opportunity.

### IDENTIFYING POWER HOGS


To identify power-hogging features and apps, follow these steps:

1. Open the Quick Settings panel. For example, pull down from the top of the screen with two fingers.
2. Tap the Power icon to display the Battery screen (see Figure 1.13). This screen shows currently running features and apps listed in descending order by power consumption—in other words, greediest first.

**FIGURE 1.13**

*Look at the Battery screen to see which features and apps have been consuming the most battery power.*

3. Tap the Battery graph at the top to display the History Details screen (see Figure 1.14). This screen shows a larger battery chart, enabling you to see the relative rates of power consumption more clearly, and bar charts showing when each feature was consuming power.


**FIGURE 1.14**

*The History Details screen shows you exactly when each feature was consuming power.*

4. Tap the Back button to return to the Battery screen.
5. Tap the button for a feature or app whose usage details you want to view. The Use Details screen appears. Figure 1.15 shows the Use Details screen for Google Play services.

**NOTE**

The Use Details screen for some apps and features includes controls for adjusting the battery usage.

**FIGURE 1.15**

*The Use Details screen gives you specifics on what an app has been doing.*

## EKING OUT BATTERY LIFE

To get the most runtime out of your device, you need to reduce power consumption to an acceptable minimum. What that means depends on what the device is and what you're doing with it.

Here are 10 ways you can easily reduce the amount of power your device consumes:

- **Turn down the display brightness.** Open the Quick Settings panel, tap the Brightness icon, and then drag the slider as far to the left as you can bear. The display gets through a huge amount of power, especially on a tablet with a large screen.
- **Set a short sleep interval.** Open the Settings app, tap the Display button, and then tap the Sleep button to display the Sleep dialog box. Tap a short time, such as 15 Seconds or 1 Minute, to save power by turning off the screen quickly when you're not using it.
- **Use Airplane mode when you can go offline.** Open the Quick Settings panel and tap the Airplane Mode icon to quickly shut down all communications services. Repeat the move when you need to go back online.

**TIP**

Turn on Airplane mode when you don't absolutely need connectivity and you're in a place with no signal or poor signal, such as rural wastelands or convention centers. Otherwise, your device will happily squander valuable battery power on chasing will-o'-the-wisp signals.

- **Turn off communications services you don't need.** Open the Quick Settings panel and tap the icon for any communications service that is currently turned on but which you can afford to turn off: Cellular (on a phone or cellular-capable tablet), Wi-Fi, or Bluetooth. If your device has Near Field Communication (NFC), turn that off as well.
- **Set the Location mode to Battery Saving.** Open the Settings app and tap the Location button in the Personal section to display the Location screen. Tap the Mode button at the top to display the Location Mode screen, and then tap the Battery Saving button. Alternatively, set the Location switch on the Location screen to the Off position to turn off location tracking entirely.
- **Check for email less frequently.** Unless it's vital that you receive all your messages as soon as possible, reduce the frequency of checking for new messages to a minimum. See Chapter 6, "Taking Gmail to the Pro Level," for instructions on configuring the Gmail app and Chapter 7, "Becoming Expert with the Email App," for instructions on configuring the Email app.
- **Store copies of cloud files on your device.** Services such as Dropbox are great because they enable you to access your documents from anywhere you have an Internet connection. But to save power, you can store copies of files on your phone or tablet so that you don't need to download them. For example, in Dropbox, you can mark a file as a favorite to make Android store a copy of it locally.
- **Avoid playing videos and music.** Playing videos eats through battery power quickly because it uses the screen, but even playing back music takes a fair amount of power. If you find your Android device runs out of power regularly, consider getting a minute music player (such as an iPod shuffle or one of its competitors) so that you can listen to your essential music without running down the battery on your phone or tablet.
- **Turn off live wallpapers.** Live wallpapers look pretty, but they make your device's processor work harder and consume power. To turn off live wallpapers, open the Settings app, tap the Display button to go to the Display screen, and then tap the Wallpaper button to display the Choose Wallpaper From screen. You can then tap the Wallpapers button to set a

static wallpaper, tap the Gallery button to choose a picture from the Gallery app, or touch the Photos button to use a photo from the Camera app.

- **Streamline your Home screens.** Widgets that require updating, such as those for email or social networking, consume power both through updating and network connections, so run as few widgets as possible if you're trying to squeeze more time out of your battery.



**TIP** Some skins and devices offer extra power-management features. For example, the Samsung Galaxy S 5's Ultra Power Saving mode enables you to shut off all nonessential features and even uses black-and-white output to reduce the power draw. Look into any extra features that your device provides for getting you through power shortages.

## RECHARGING SECRETS

As you saw in the previous sections, you can take various actions to reduce your device's power consumption. But given that most of these actions make your device not only less useful but also harder to use, you may prefer to take a damn-the-torpedoes approach and confront the power problem head on by running your device at full bore but also recharging it whenever you get the chance.

Here are suggestions for recharging your Android device:

- **Carry a spare battery.** If your phone or tablet enables you to easily change batteries, carry one or two spare—and fully charged—batteries with you wherever you go and swap them out as needed. Being able to easily change batteries is one of the great advantages of some Samsung phones, such as the Galaxy Note 4 and the Galaxy S 5.
- **Get a battery case.** If your phone or tablet is a high-profile device, you may be able to find a case with a built-in battery. If you consistently need more battery power than the built-in battery delivers, a battery case can be a great solution.
- **Get an external battery or portable charger.** No matter which device you have, you can choose from a wide range of external batteries, also called *portable chargers*, to which you connect your device via USB to recharge it. If you live in a sunny climate, consider getting one with a solar charger.
- **Upgrade the battery.** If your device's battery is user-replaceable, you may be able to replace it with a higher-capacity version. First, if your device is

still under warranty, check whether replacing the battery will invalidate the warranty; if so, decide whether this is a sacrifice you're prepared to make in your pursuit of power or whether to wait until the warranty expired. Next, look up the specs for your device's battery, and then search on the Internet for a higher-capacity version.

**! CAUTION** When buying a third-party charger or battery for your Android device, read professional and user reviews to make sure you choose a quality unit. A poorly made charger can not only overload your device, damaging the battery, but can also be a fire hazard to the place where you use it. A poorly made battery can damage your Android device directly. Also check the battery's date of manufacture before buying. A lithium-ion battery gradually loses capacity over two to three years because of oxidization, so make sure the battery you buy is fresh.

- **Get a car charger.** If you drive a car, get a car charger so that you can plug your device in to charge for the duration of each journey. That should more than offset the power taken by using your device for navigation in the car.
- **Get a spare charger.** Carrying a charger to and from work is a headache, especially when you leave the charger at your workplace for the weekend. Get a spare charger to keep at work.
- **Carry a USB cable.** When no external battery or dedicated charger is available, plug your device into the USB port on whichever computer is handy. The battery may charge more slowly, but you'll pick up at least some power.

## Understanding How Device Batteries Charge

These days, most devices use lithium-ion batteries, which deliver a good amount of power relative to their size, are usually very stable, and prefer frequent charging to full discharging and recharging.

To get the most out of your device's battery, you need to understand the essentials of how it works so that you can charge it in the ways that work best for the battery and for yourself.

Some manufacturers recommend charging the battery fully at the first charge. Most experts agree that this isn't necessary, suggesting that the manufacturers have carried the recommendation over from the days of nickel batteries, which

*did* require a full charge at first. But if you want to go ahead and give your device's battery a full charge at first, it will do no harm.

A battery's life is measured in charge cycles; a typical lithium-ion battery gives around 500 charge cycles. A *charge cycle* involves charging and discharging the battery fully. Normally, you'll use partial charge cycles rather than full charge cycles for your device's battery, using the device for a while and then plugging it into a power source to recharge. Partial charge cycles add up to full charge cycles as you'd expect, so if you discharge your battery 50% on Monday, 25% on Tuesday, and 25% on Wednesday, charging it up again each evening, you've consumed a full charge cycle.

Using partial charge cycles like this is in general the best way to treat a lithium-ion battery. This is in contrast to some older battery technologies, in which partially discharging and recharging the battery could cause a "memory effect" that reduced the battery's charge capability to the amount you had used.

If you want to keep your device's battery working well, it's a good idea to give it a full discharge and recharge every 30 or so charge cycles—say, once a month if you use your device heavily, or once every couple of months for moderate use. This full discharge and recharge helps to sync the battery's fuel gauge with the actual state of the battery's charge. Without this discharge and recharge, the fuel gauge gradually becomes less accurate, so the power status Android reports to you may not be correct.

Most recent lithium-ion batteries charge relatively quickly up to the 80% level and then charge more slowly for the last 20%. So charging your device for 20 minutes can bump up the level substantially if the battery is depleted, but if the battery is above the 80% level, it may add only a few percent.

Some third-party chargers claim to be able to charge a lithium-ion battery fully in just a few minutes. Experts agree that such instant charging is not possible and that attempting to charge in this way is likely to damage the battery.

Never charge a lithium-ion battery in freezing conditions, because doing so can damage the battery. If the battery gets really cold (for example, because you leave your phone in the car in winter), allow it to warm up before you try to charge it.

## MANAGING FILES AND STORAGE

You might be familiar with Parkinson's Law, which states that "work expands so as to fill the time available for its completion"—but do you know the Law's corollary that states "Storage requirements will increase to meet storage capacity"?



Sadly, this corollary seems to be all too true: However much storage space you have, on your Android device in this case, you'll find you want to carry around that quantity of files—or usually more. Between the songs and movies you bring for entertainment, the books and documents you need for work or study, and the files you create directly on your device, the built-in storage can quickly become full. This is especially true if you record video, which can chew through several gigabytes of storage space in next to no time.

Most devices come with only a modest amount of storage space. At this writing, manufacturers pretend that 16GB is a generous size and charge a savage premium for higher-capacity devices. So chances are that you'll need to manage the files and storage on your device.

**NOTE**

Whether you can use SD cards with your device or not, back it up frequently in case it suffers an accident or you delete a priceless file by accident.

## ADDING AN SD CARD

If your device accepts an SD card, add the highest-capacity SD card that works. If your device's SD card is awkward to insert and remove, you will probably want to leave a single card in place, but if you can swap SD cards easily, you can use several of them. This gives you an easy way to quickly load files onto your device from your computer: Copy them to the SD card, and then insert it in your Android device.

**TIP**

Before adding an SD card, read your device's documentation to find out the largest size of SD card it supports. Then search online to see if other people who have the device have gotten a larger SD card to work—and if so, which make and model of card. The manufacturers' recommendations are often conservative or out of date, so be prepared to research your device and SD cards if you need the maximum storage possible.

## Understanding KitKat's Limitations on SD Card Storage

Android devices have a strange relationship with SD cards. On the one hand, few manufacturers sell high-capacity devices, so you pretty much need to add an SD card in order to give yourself plenty of storage. On the other hand, Google's own devices don't have SD card slots, and Google keeps making changes to the ways in which Android apps can use SD cards. Most of the recent changes have been restrictive, limiting the ways in which apps can use SD cards.

The latest changes, introduced in KitKat, largely prevent third-party apps from writing data to the SD card. Before this, if you gave a third-party app permission to access the SD card, it could read and write to any folder on the SD card. But now, even with permission to access the SD card, a third-party app can write only to folders it creates or folders of which it takes ownership. And if you uninstall the third-party app, you also delete the app's folders and their contents.

Google made these changes for good reason: The SD card uses the old file allocation table (FAT) file system, which doesn't support file and folder permissions of the type that most modern operating systems do. So whereas in the Windows NT File System (NTFS for short), the Mac HFS Plus file system (also called Mac OS Extended file system), and most Linux file systems, you or the OS can set separate permissions on each file or folder, in FAT you cannot: Any app that has access to a FAT volume can access all that volume's folders and files. This lack of security enables any malicious or ill-programmed app to compromise sensitive data on the SD card.

Locking down the SD card like this increases your security, but it makes the SD card that much less useful to you. For example, a third-party camera app may no longer be able to store photos and videos on the SD card, or a video-editing app may no longer be able to edit videos. The problem is most acute for file-management apps, which can no longer create folders, move files, or perform other essential actions in areas of the SD card they don't themselves own.

If you need to run apps that worked using the SD card on older versions of Android but don't work under KitKat, you may need to root your device. This book doesn't cover rooting, but you can find instructions by searching online for *root* and your device's name. Proceed with great care because rooting can "brick" a device, rendering it useless (even as a brick).

If you root your device, you can install a fix such as the KitKat External SD Card Patch (free from the Play Store), which enables apps to write to the SD card again. You can also connect a physically external storage device, such as a USB memory stick or a USB drive, to your device. The result is physically awkward but enables you to add massive amounts of storage to the device.

Android expects SD cards to use the FAT file system. Almost all SD cards come formatted with FAT, so if you've got a new card, you're good to go. If the SD card is formatted with another file system, you need to reformat it before your device can use it.

You can reformat the SD card on your device itself or by using a computer. The following sections explain how to reformat an SD card on Android, on Windows, and on OS X.

**! CAUTION** Reformatting an SD card removes any files and folders it currently contains. You may also want to reformat an SD card to remove all its contents.

## FORMATTING AN SD CARD ON ANDROID

Here's how to format an SD card on Android:

1. Insert the SD card into the slot.
2. Open the Settings app.
3. Tap the Storage button in the Device section.
4. Tap the Unmount SD Card button to unmount the SD card from the file system.
5. Tap the Format SD Card button.
6. Tap the OK button in the confirmation dialog box that opens.

## FORMATTING AN SD CARD ON WINDOWS

Here's how to format an SD card on Windows:

1. Insert the SD card into a card reader built into or connected to your computer.
2. Open a File Explorer window showing This PC (on Windows 8) or a Windows Explorer window showing Computer or My Computer (on earlier versions).
3. Right-click the SD card and then click Format on the shortcut menu to open the Format dialog box.
4. Click the File System drop-down list and then click FAT32.
5. Clear the Quick Format check box to make Windows check the SD card for errors while formatting it.

6. Click the Start button.
7. Click the OK button in the confirmation dialog box that opens.
8. When the Format Complete dialog box opens, click the OK button.
9. Right-click the SD card and then click Eject to eject the card.
10. Remove the card from the card reader.

## FORMATTING AN SD CARD ON OS X


Here's how to format an SD card on OS X:

1. Insert the SD card into a card reader built into or connected to your Mac.
2. Click the Launchpad icon on the Dock, type **dis**, and then click the Disk Utility icon to launch Disk Utility.
3. In the left pane, click the SD card. The right pane displays controls for managing the card.
4. Click the Erase tab to display its controls.
5. Click the Format pop-up menu and then click ExFat.
6. Click the Name field and type the name you want to give the card.
7. Click the Erase button.
8. Click the Erase button in the confirmation dialog that opens.
9. After the format operation finishes, click the Eject button on the toolbar.
10. Remove the card from the card reader.

## CHOOSING A FILE MANAGER

You can manage files and folders on your device by running a file manager on the device itself. Some devices include file managers, whereas others don't. If your device doesn't have a file manager, download and install one from the Play Store.

Both ES File Explorer (see Figure 1.16) and ASTRO File Manager are powerful file managers that are easy to use. Both are free from the Play Store; ASTRO File Manager also offers a paid version, ASTRO File Manager Pro, which removes the ads.

**FIGURE 1.16**

*If your device doesn't come with a file manager, you can install one from the Play Store, such as ES File Manager.*

**NOTE**

Because of the KitKat limitations discussed in the previous section, file managers can manage only the apps on the internal storage, not on the SD card.

## CHECKING FREE SPACE AND SEEING WHAT'S TAKING UP SPACE

To see how much space you have left on your device, open the Settings app and touch the Storage button. The Storage screen appears (see Figure 1.17), showing the Internal Storage section at the top and the SD Card (if your device has an SD card) further down the screen.

**FIGURE 1.17**

*Use the Storage screen to identify which types of files are taking up your device's storage space.*

The Storage screen is easy to read:

- The bar chart at the top of the Internal Storage section shows what proportion of your device's storage is in use and how much is free. The color bars show you the file types.
- The Total Space readout gives your device's total capacity.

**NOTE**

The Total Space readout on the Storage screen shows a capacity lower than your device's nominal capacity for two reasons. First, manufacturers give the nominal capacity in gigabytes calculated using billions of bytes ( $1000^3$  bytes) rather than the gigabytes that computers actually use ( $1024^3$  bytes), which are 7.4% bigger; so a device with 16GB nominal capacity has a true capacity of 14.9GB. Second, the operating system takes up several gigabytes of space.

- The Available readout shows how much space is available.
- The Apps readout shows how much space the apps are taking up. You can tap the Apps button to display the Apps screen, from which you can uninstall apps to recover space.
- The Pictures, Videos readout shows how much space your pictures and videos are occupying. You can tap this button to view your photos in the Gallery app or the Photos app. You can delete photos using these apps if necessary.
- The Audio readout shows how much space your audio files—such as songs, ringtones, and podcasts—are taking. You can tap this button to display the Open From panel, which gives you several ways to browse the files. But usually it is easier to manage your music from your computer if you sync your device with it.
- The Downloads readout shows the amount of space occupied by files you have downloaded. You can tap the Downloads button to display the Downloads screen, from which you can delete files to free up space.
- The Cached Data readout shows how much space is devoted to cached data. *Cached data* is data saved by apps to enable them to display it more quickly; for example, web browsers cache recent web pages in case you visit them again.
- This Misc. readout shows how much space miscellaneous files are occupying.

## RECOVERING SPACE


After reading the previous section about the Storage screen, you can likely see several straightforward ways of recovering space on your device: You can delete apps you no longer need; remove pictures, videos, and audio items; delete any downloaded files; and clear your cached data.

## DELETING APPS

If you've installed a lot of apps, deleting any that you don't use is a good way to start recovering space on your device.

Open the Settings app and tap the Apps button in the Device section to display the Apps screen. This screen can display the apps sorted either by name in alphabetical order or by size in descending order. If the apps appear in alphabetical order, tap the Menu button and then tap Sort by Size to get a list with the biggest apps at the top.

If you want to see what's taking up space, tap the Menu button and then tap Sort by Size (see Figure 1.18) to get a list of apps in descending order of size.

**FIGURE 1.18**

*On the Apps screen, tap the Menu button and then tap Sort by Size to see which apps are taking up the most room.*

To remove an app, tap its button on the Apps screen. The App Info screen for the app appears, and you can tap the Uninstall button to uninstall the app.

## REMOVING PICTURES AND VIDEOS

Pictures can take up a large amount of space on your device, and videos can eat up all your remaining storage in just a few minutes of shooting.

You can access your photos and videos by tapping the Pictures, Videos button on the Storage screen. If the Complete Action Using dialog box opens, tap the app you want to use (such as Gallery) and then tap the Always button or the Just Once button, as appropriate. You can then use the app to select individual photos or videos and delete them as necessary.



**TIP**

Managing your photos and videos using the Gallery app or the Photos app on your device works fine up to a point. But if you need to remove whole swaths of photos or reels of videos, it's easier to connect your device to your computer and manage them from there.

## REMOVING AUDIO ITEMS

If you need to remove audio items from your device, tap the Audio button on the Storage screen. Android displays the Open From pane, in which you can touch the app in which you want to view the files.

**TIP**

As with photos and videos, removing large numbers of audio items from your Android device using the device itself tends to be awkward. If you use your device with a computer, use the computer to remove the files.


## DELETING DOWNLOADED FILES

If you no longer need files you have downloaded to your device, delete them to recover space on it. Tap the Downloads button on the Storage screen to display the Downloads folder. You can then tap and hold a file to select it, select other files as needed, and then tap the Delete icon (the trash can).

## CLEARING YOUR CACHED DATA AND MISCELLANEOUS FILES

If you've deleted all other content you can spare from your device, but you're still short of space, you may want to clear your cached data and delete your miscellaneous files.

You can clear your cached data by tapping the Cached Data button and then tapping the OK button in the Clear Cached Data? dialog box (see Figure 1.19).

**FIGURE 1.19**

*You can clear cached data to free up space on your Android device.*

You can tap this button to display the Misc Files screen, which provides controls for selecting the files and deleting them. Normally, the miscellaneous files take up only a small amount of space.

*This page intentionally left blank*

# Index



## Symbols

---

2-step verification (Gmail), 205–208  
3G network, 122–123  
4G network, 122–123

## A

---

AAC (Advanced Audio Coding),  
380–381  
About Phone button, 17  
About Tablet button, 17  
accelerometers, 13  
accessibility settings in Chrome,  
246, 254  
accessing  
Camera app, 356–357  
devices  
Android File Transfer, 60  
HTC Manager app, 61–62  
Motorola Device Manager  
app, 61  
Samsung Kies app, 61  
Windows Explorer, 60  
Windows File Explorer, 60  
Google Now, 282

Access Point Name (APN) setting, 123  
access points, 123  
accounts  
Email app  
deleting, 227–228  
security, 212–213  
setting up, 210–211, 213–227  
Gmail accounts  
action confirmations, 184  
adding, 180  
archiving email messages, 198–200  
attachments, 197  
Auto-Advance feature, 184, 200  
blocking senders, 200  
configuring, 181–190  
conversation list, 192–196  
Inbox settings, 185–188  
labels, 190–192, 198–199  
navigating, 192  
phishing, 200  
reading email messages, 195–196  
sender image, 183  
sending email messages, 196–197  
settings, 180–181  
showing message actions, 184  
signature, 189  
spam, 200  
Vacation Responder feature,  
189–190



- writing email messages,*  
196–197
- Google account
  - configuring,* 247–248
  - signing in,* 250
- nonowner account, 36
- owner account, 36
- Play Store account, 164–166
- Samsung account, 448
- user accounts
  - creating,* 34–36
  - deleting,* 39
  - switching among,* 38–39
- Action Memo, 481
- adding
  - apps to Home screen, 89
  - contacts, 291–292
  - documents, 306
  - Gmail accounts, 180
  - Home screens, 87–88
  - web addresses to Home screen,  
91–92
  - widgets to Home screen, 89–91
  - widgets to lock screen, 108
- Add New User dialog box, 35
- Add to Homescreen dialog box,  
91–92
- Add to Playlist dialog box, 401
- adjusting volume levels, 19–20
- Advanced Audio Coding (AAC),  
380–381
- Air Command, 481
- Airplane mode, 43–44, 119–120
- alarm volume level, 19
- allowing apps from unknown  
sources, 169
- alternate characters, 24
- Android Beam, 479
- Android Developer website, 376
- Android File Transfer
  - downloading, 65
  - ejecting the disk image, 65
  - features, 60
  - file management, 70–71
  - installing, 65–66
  - running, 70–71
  - size limit on files, 71
- Android File Transfer for Mac  
app, 60
- Android for Work, 307
- Android operating system (OS)  
devices, 15
- updates, 17
- versions, 16–18
- Android SDK, 376
- Android skins
  - defined, 17
  - features, 15
  - functionality, 17
  - Home screens, 88
  - OS updates, 17
  - Samsung's TouchWiz skin,  
17–18
  - Settings app, 8
  - slow devices, 17
  - wallpapers, 94
- animations (TouchWiz), 484
- App icon (Home screen), 4
- App Info screen, 22, 173
- Apple iCloud service, 60
- Apple iTunes, 60
- Apple iTunes Match, 378
- Application and Content  
Restrictions screen, 37–38
- AppLock app, 171
- apps
  - adding to Home screen, 89
  - allowing apps from unknown  
sources, 169
  - App Info screen, 173
  - clearing an app's cache, data, or  
defaults, 174
  - closing, 173
  - defaults, 174
  - deleting, 54–55
  - forcing an app to stop, 173
  - Google's Play Store app, 161,  
164–166
  - hiding HTC Sense, 500
  - HTC Sense, 487
  - installing, 161–163
  - keyboard shortcuts, 170–171
  - killing, 178
  - launching, 2
  - locking, 171
  - Menu button, 8–9
  - moving on Home screen, 89
  - notifications, 20
  - clearing,* 22–23
  - turning on/off,* 22
  - open-source licenses, 401
  - package files, 167–169
  - permissions, 161–163
  - preferences, 176–177
  - Recent Apps button, 4
  - Recent Apps list, 22
  - Recent Apps screen, 171–173
  - refunds, 163
  - running, 170–171
  - Samsung Apps app, 465
  - screen lock, 38
  - Settings app
    - Display button,* 13
    - features,* 3, 8
    - opening,* 7–8
    - skins,* 8
  - sideloading, 166–170
  - sorting (HTC Sense), 498–500
  - switching, 172
  - unhiding (HTC Sense), 500
  - uninstalling, 174–175
  - updating, 74–75, 165
- Apps button, 4
- Apps screen, 4–5
  - HTC Sense, 498–500
  - launching apps, 2
  - TouchWiz, 453–454
- archiving
  - email messages, 183, 198–200
  - hangouts, 350–351
- arranging Home screens, 94
- ASTRO File Manager, 51, 167
- ASTRO File Manager Pro, 51
- attachments, 231–232
- Audacity audio editor app, 384
- audio volume levels, 19–20
- audio encoders, 380
- audio files
  - deleting, 56
  - formats, 380
- audio zoom (Camera app), 472
- authentication of Facebook  
account, 426–431
- Auto-Advance feature  
(Gmail), 184
- Autofill forms, 248, 250–251
- auto-fitting email messages, 183
- automatic checking for software  
updates, 74
- automatic rotation, 13
- Auto mode (Camera app), 468
- Auto-Rotate Screen box, 13
- Auto Sign-In (Chrome), 250
- Auto-Update Apps dialog  
box, 165

## B

Back button, 4  
 backup methods, 76–79  
 bandwidth management with  
   Chrome, 258–259  
 battery, 18, 40–47  
 Battery screen, 40  
 Bcc, 230  
 Bcc (email), 197  
 Beauty Face mode (Camera  
   app), 468  
 Bing search engine, 250  
 bit rate, 380  
 BlinkFeed feature (HTC Sense),  
   492–494, 496  
 blinking light, 22  
 blocking  
   offensive words, 28  
   phone calls, 335–336  
 blocking Caller ID, 333  
 blocking people in Facebook,  
   423–426  
 blocking senders in Gmail, 200  
 Bluetooth devices  
   connecting, 150–152  
   loading files, 72  
   transferring files via Bluetooth,  
     152–153  
 Bluetooth Pairing Request dialog  
   box, 151  
 Bluetooth tethering, 146,  
   153–155  
 bookmarks, 248, 476–477  
 bookmarks (Chrome), 263–265  
 booting into Safe mode, 175–176  
 browsers  
   Chrome, 476  
   default browser, 261  
   Internet app, 474–476  
     *bookmarks*, 476–477  
     *Incognito mode*, 479  
     *navigating among windows*,  
       477–478  
     *Quick Access screen*, 478–479  
     *Saved Pages list*, 476  
     *syncing Internet browsing*, 479  
     *web page shortcuts*, 479  
 browsing web, 259–267

budget devices, 18  
 buttons  
   HTC Sense, 486  
   TouchWiz, 448–449  
 buying music, 391–392

## C

CA (certificate authority), 212  
 cached data, 56–57  
 Calendar app  
   capabilities, 295–296  
   display options, 298  
   events  
     *creating*, 299  
     *invitations*, 299–300  
   notifications, 297  
   Quick Responses, 297  
   reminders, 297  
   settings, 296–298  
   setting up, 296–298  
   sharing calendars, 300  
   time zone, 297  
   view options, 298–299  
 Call Control app, 336  
 Caller ID, 332–333  
 Caller ID blocking, 333  
 Caller ID by Google feature, 328  
 call forwarding, 332  
 call log, 320–322  
 Call Settings screen (Phone app),  
   328–329  
 Call Waiting, 332–333  
 Camera app  
   accessing, 356–357  
   audio zoom, 472  
   Auto mode, 468  
   Beauty Face mode, 468  
   Camera mode, 354–355  
   camera shake, 362  
   configuring, 357–360  
   Dual Camera mode, 469  
   Effects list, 472  
   Exposure Value, 473  
   Flash, 472  
   Flash feature, 364–365  
   focus, 471  
   focusing, 361  
   grid, 363–364  
   Grid Lines, 473  
   HDR, 364–365, 472  
   HTC Sense, 505–513  
   installing, 354  
   launching, 467  
   Lens Blur feature, 369–372  
   Lens Blur mode, 355  
   location settings, 360  
   location tags, 472  
   lock screen, 356–357  
   manual exposure, 360, 362–363  
   Modes list, 355–356  
   navigating, 354–356  
   opening, 354  
   Panorama feature, 369  
   Panorama mode, 355, 469  
   photo editing, 372–375  
   photos  
     *reviewing*, 365–367  
     *taking*, 360–365  
   Photo Sphere feature, 368–369  
   Photo Sphere mode, 355  
   quality settings, 358–360  
   Recording Mode, 472  
   Remote Viewfinder, 473  
   resolution, 358–360  
   settings, 357–360, 467–474  
   Shot & More mode, 468–469  
   storage location, 472  
   switching cameras, 365  
   timer, 363, 472  
   updating, 354  
   Video mode, 355  
   video size, 471  
   video stabilization, 472  
   Virtual Tour mode, 469  
   Voice Control feature, 474  
   Volume Key, 473  
   White Balance, 473  
   zooming in/out, 361, 467  
 camera shake, 362  
 capturing screenshots, 376, 481  
 car charger, 46  
 carriers, connecting to a different  
   carrier, 123–124  
 CBR (constant bit rate), 380  
 Cc (email), 197, 230  
 CDs, ripping, 381–385  
 cellular connections  
   access points, 123  
   connecting to a different car-  
     rier, 123–124  
   data roaming, 121–122  
   4G network, 122–123  
   managing, 120  
   Mobile Network Settings  
     screen, 120–122

- sharing Internet connection, 146–150, 153–155
  - 3G network, 122–123
  - virtual private networking (VPN), 155–159
  - certificate authority (CA), 212
  - charge cycle, 47
  - chargers, 45–46
  - chat
    - Facebook, 412
    - Google Hangouts, 338–351
  - check boxes, 9–10
  - check (defined), 10
  - checking free space, 52–54
  - Choose Input Method dialog box, 104
  - Choose Keyboard Layout dialog box, 31
  - Choose Screen Lock screen (Settings app), 3
  - Choose Wallpaper From dialog box, 95
  - choosing
    - device, 18
    - launchers, 97
    - search engine, 250
  - Chrome, 476
    - accessibility, 254
    - Autofill forms, 248, 250–251
    - Auto Sign-In, 250
    - bandwidth management, 258–259
    - bookmarks, 248, 263–265
    - Chrome to Mobile setting, 250
    - configuring Google account, 247–248
    - Content Settings, 255–257
    - cookies, 254–255
    - ‘Do Not Track’ screen, 253
    - encryption, 249
    - history, 248, 265
    - incognito web browsing, 266–267
    - installing, 246, 268–269
    - JavaScript, 256
    - passwords, 249–250
    - pop-ups, 256
    - preloading web pages, 258–259
    - privacy, 252–254
    - Save Passwords feature, 251
    - search engines, 250
    - sending web pages to your device, 269–270
    - settings, 246, 252–257
    - tabs, 249, 261–263, 265
    - Usage and Crash reports, 253
    - web browsing, 259–267
  - Chromecast device, 310–316
  - Chrome to Mobile feature, 268–270
  - Clear Cache button, 23
  - Clear Data button, 23
  - clearing notifications, 20–23
  - Clock widget, 4
  - closed networks, 131–132
  - closing apps, 173
  - cloud printer, 307–309
  - Commute Sharing screen (Google Now), 279
  - computers
    - controlling your computer from your device, 309–310
    - syncing information between computer and device, 60, 69–70
  - conference phone calls, 324–325
  - configuring
    - access points, 123
    - Camera app, 357–360
    - Gmail, 181–190
    - Google account, 247–248
    - input options, 102–105
    - Internet calling, 334
    - IP settings, 140–142
    - lock screen, 105
    - Phone app, 327–329
    - Play Music app, 398–401
    - Play Store account, 164–166
    - Twitter, 437, 439–442
  - connecting
    - Bluetooth devices, 150–152
    - devices to Windows, 64
    - to a different carrier, 123–124
    - to Wi-Fi networks, 130–132
  - Connect to Device dialog box, 315
  - constant bit rate (CBR), 380
  - contacts
    - adding, 291–292
    - display options, 292–293
    - exporting, 294–295
    - Facebook, 408–409
    - Facebook Messenger, 411, 413
    - Google Now, 279–280
    - importing, 294–295
    - joining contact records, 293–294
    - managing, 291
    - People app, 291–295
    - ringtones, 291
    - separating contact records, 293–294
    - SIM Card, 294
  - Content Settings (Chrome), 255–257
  - controlling your computer from your device, 309–310
  - controls, 9–10
  - conversation list (Gmail), 192–196
  - cookies, 254–255
  - creating
    - documents, 306
    - email messages, 229–232
    - events, 299
    - folders, 305–306
    - playlists, 401–403
    - restricted profile, 37–38
    - user accounts, 34–36
  - Cupcake, 16
  - customizing
    - Google Now, 272–275
    - Home screen (HTC Sense), 496–497
    - Home screens, 88
    - HTC BlinkFeed, 494, 496
    - ringtones, 334–335
  - CyberGhost VPN, 155
- ## D
- 
- data
    - cached data, 56–57
    - decrypting, 115–117
    - encryption, 113–115, 249
    - factory data reset, 115–117
    - screen lock, 38
  - data hogs, 125–126
  - data plan
    - data limit, 124–128
    - identifying data hogs, 125–126
    - warnings, 125
  - data roaming, 121–122
  - data usage (Google Drive), 304
  - Data Usage tool, 124–128
  - declining phone calls, 325–326
  - decryption, 115–117
  - default launcher, 96, 99–102

- defaults
  - apps, 174
  - browser, 261
  - Home screens, 94
- Delete App Data? dialog box, 23
- deleting
  - apps, 54–55
  - audio files, 56
  - Email app accounts, 227–228
  - email messages, 183
  - files, 56
  - folders, 93
  - hangouts, 351
  - Home screens, 87–89
  - items from Home screen, 94
  - launchers, 101
  - location history, 111–112
  - maps, 288
  - photos, 55–56
  - pictures, 55–56
  - restricted profiles, 39
  - songs, 397–398
  - user accounts, 39
  - videos, 55–56
- devices
  - accessing
    - Android File Transfer*, 60
    - HTC Manager app*, 61–62
    - Motorola Device Manager app*, 61
    - Samsung Kies app*, 61
    - Windows Explorer*, 60
    - Windows File Explorer*, 60
  - backup methods, 76–79
  - battery, 18
  - budget devices, 18
  - choosing, 18
  - connecting to Windows, 64
  - controlling your computer from
    - your device, 309–310
  - decrypting, 115–117
  - drivers, 64
  - encryption, 112–115
  - finding out which version of
    - Android is running, 16–17
  - hard reset, 75, 117–118
  - operating system (OS), 15
  - owner information, 108
  - rebooting into Safe mode,
    - 175–176
  - recharging, 45–47
  - Remote Find and Wiping, 81–86
  - remote locking and wiping,
    - 81–86
  - restoring, 79–81

- ringing, 84
- rooting, 49
- shared devices and security,
  - 39–40
- skins, 15
- software updates, 72–74
- syncing with a computer, 60,
  - 69–70
- DHCP (Dynamic Host Configuration Protocol), 140
- dialog boxes, 11–12
- dial pad touch tones (Phone app), 329
- dictation, 31–32
- dictionary, 28–29
- digital certificates, 135–137, 212
- disabling data roaming, 121–122
- Display button (Settings app), 13
- displaying
  - calendars, 298
  - contacts, 292–293
- Divide app, 307
- documents
  - adding, 306
  - creating, 306
  - downloading, 303
  - filtering, 302
  - keeping on your device, 306
  - navigating, 302
  - opening, 303
  - printing
    - cloud printer*, 308–309
    - HP Print Serve Plugin*, 308
    - local printer*, 307–308
    - on existing printer*, 309
    - options*, 307
  - scanning, 306
  - searching, 304
  - sorting, 303
  - uploading, 306
  - viewing information about, 304
- Do Not Disturb app, 336
- 'Do Not Track' screen, 253
- Donut, 16
- double-tap, 12
- doubleTwist app, 61, 386–387
- downloading
  - Android File Transfer*, 65
  - documents, 303
  - Facebook, 407
  - songs, 396

- wallpapers, 96
- drag, 12
- drivers, 64
- Dropbox app
  - Home screen, 93
  - loading files, 72
- Dual Camera mode (Camera app), 469
- Dual Capture Mode (HTC Sense Camera app), 513
- Dvorak keyboard layout, 31
- Dynamic Host Configuration Protocol (DHCP), 140

## E

- Éclair, 16
- Easter Egg, 112
- editing photos, 372, 374–375
- Effects list (Camera app), 472
- email
  - Gmail
    - 2-step verification*, 205–208
    - action confirmations*, 184
    - archiving email messages*, 198–200
    - attachments*, 197
    - Auto-Advance feature*, 184
    - blocking senders*, 200
    - configuring*, 181–190
    - conversation list*, 192–196
    - Inbox settings*, 185–188
    - labeling email messages*, 198–199
    - labels*, 190–192
    - navigating*, 192
    - phishing*, 200
    - reading email messages*, 195–196
    - searching*, 201–205
    - sender image*, 183
    - sending email messages*, 196–197
    - showing message actions*, 184
    - signature*, 189
    - spam*, 200
    - Vacation Responder feature*, 189–190
    - writing email messages*, 196, 197
  - Gmail accounts
    - adding*, 180



- configuring*, 183
- settings*, 180–181
- mail servers, 211, 212
- transferring files, 72
- Email app
  - accounts, 210–211
  - account setup, 213–227
  - deleting accounts, 227–228
  - email messages
    - attachments*, 231–232
    - creating*, 229–232
    - drafts*, 238
    - forwarding*, 235–236
    - reading*, 232–235
    - receiving*, 232–235
    - replying to*, 235–236
  - features, 209
  - mailboxes, 238–239
  - Quick Responses feature, 236–238
  - security, 212–213
  - settings, 240–243
- email messages
  - archiving, 183, 198–200
  - attachments, 197, 231–232
  - Auto-Advance feature, 184
  - auto-fitting, 183
  - Bcc, 230
  - Cc, 230
  - creating, 229–232
  - deleting, 183
  - drafts, 238
  - forwarding, 235–236
  - labeling, 198–199
  - notifications, 188
  - phishing, 200
  - reading, 195–196, 232–235
  - receiving, 232–235
  - replying all, 183
  - replying to, 235–236
  - searching, 201–205
  - sending, 196–197, 229–232
  - spam, 200
  - syncing, 190
  - writing, 196–197
- emojis, 33
- emoticons, 33
- enabling data roaming, 121–122
- encryption, 112–115, 249, 304
- entering text
  - dictation, 31–32
  - hardware keyboard, 29–31
  - onscreen keyboard, 24–26

- Equalizer app, 403–405
- ES File Explorer, 51, 167
- events
  - creating, 299
  - invitations, 299–300
- Exchange mail server technology, 211–212
- Exchange Server accounts, 220–227
- exporting contacts, 294–295
- Exposure Value (Camera app), 473
- external memory, 68
- Extract Certificate dialog box, 135–136
- Extreme Call Blocker app, 336

## F

- Facebook
  - Activity Log, 420, 422
  - blocking people, 423
  - chat, 412
  - contacts, 408–409
  - downloading, 407
  - multiple accounts, 431–433
  - News Feed, 417
  - privacy, 417–420, 422–426
  - removing Facebook accounts, 433–434
  - settings, 415–434
  - two-factor authentication, 426–431
- Facebook Messenger, 409–415
- Face Unlock method, 105–106
- factory data reset, 115–117
- FAT file system, 50
- Favorites tray, 4
- File Beam (Touch to Send) app, 169
- file manager, installing, 167
- file managers, 51–52, 167
- files
  - cached data, 56–57
  - deleting downloaded files, 56
  - FAT file system, 50
  - loading
    - Bluetooth*, 72
    - Dropbox*, 72
    - Google Drive*, 72
  - Near Field Communication (NFC)*, 72
  - SD card*, 71–72
  - wireless connections*, 72
- managing with File Transfer, 70–71
- storage, 47–48
- transferring
  - email*, 72
  - to another device via Bluetooth*, 152–153
- filtering
  - documents, 302
  - folders, 302
- finding
  - version of Android, 16–17
  - widgets, 89
- Fixed Dialing Numbers (FDN), 330–331
- FLAC (Free Lossless Audio Codec), 380, 384
- Flash feature (Camera app), 364–365, 472
- focus (Camera app), 361, 471
- Folder icon (Home screen), 4
- folders
  - creating, 305–306
  - deleting, 93
  - filtering, 302
  - Home screens, 92–93
  - naming, 93
  - navigating, 302
  - opening, 303
  - searching, 304
  - sorting, 303
  - viewing information about, 304
- Force Stop? dialog box, 23, 173
- forcing an app to stop, 173
- forgetting a network, 145–146
- formatting SD card, 50–51
- forms, 248, 250–251
- forwarding
  - email messages, 235–236
  - phone calls, 332
- fractions, 25
- Free Lossless Audio Codec (FLAC), 380, 384
- free space
  - checking, 52–54
  - recovering, 54–57
- Froyo, 16

## G

- GALAXY Apps, 465
- gestures, 12, 452–453, 488, 502–503
- Gesture Typing feature, 25–26
- Gingerbread, 16
- Gmail
  - action confirmations, 184
  - archiving, 198–200
  - Auto-Advance feature, 184
  - blocking senders, 200
    - configuring*, 181–190
    - conversation list*, 192–196
  - Inbox settings, 185–188
  - labels, 190–192, 198–199
  - navigating, 192
  - phishing, 200
  - reading email messages, 195–196
  - searching, 201–205
  - sender image, 183
  - sending, 196–197
  - showing message actions, 184
  - signature, 189
  - spam, 200
  - 2-step verification, 205–208
  - Vacation Responder feature, 189–190
  - writing, 196–197
- Gmail accounts
  - adding, 180
  - settings, 180–181
- Go Launcher EX, 98
- Google account
  - configuring*, 247–248
  - signing in, 250
- Google Backup, restoring devices, 79–80
- Google Drive app
  - cache size, 304
  - data usage, 304
  - documents
    - adding*, 306
    - creating*, 306
    - keeping on your device*, 306
    - scanning*, 306
    - uploading*, 306
  - encryption, 304
  - folders
    - creating*, 305–306
  - launching, 301
  - loading files, 72
- My Drive screen, 301
  - navigating, 302–304
  - settings, 301, 304
  - setting up, 301
- Google Earth shortcut (Maps app), 285
- Google Hangouts app, 338–351
- Google Keyboard, 103–104
- Google Now
  - accessing, 282
  - capabilities, 272
  - Commute Sharing screen, 279
  - contacts, 279–280
  - customizing, 272–275
  - defined, 4
  - installing, 272
  - language settings, 276
  - location settings, 279
  - lock screen, 282
  - navigating, 272–273
  - Personal Results feature, 279
  - reminders, 282–284
  - Search Engine Storage option, 280–281
  - settings, 275–282
  - setting up, 272
  - Work and Home places, 275
- Google Now Launcher
  - defined, 97
  - wallpaper, 95–96
  - widgets, 91
- Google Search box (Home screen), 3
- Google search engine, 250
- Google Sky Map app, 291
- Google's Play Music app, 377–378, 387–401
- Google's Play Store app, 161, 164–166
- Google Translate, 256
- Google Voice app, 338
- Google Voice Typing feature, 31–32, 103
- Gracenote music database service, 384, 504
- Grid Lines (Camera app), 363–364, 473

## H

- hard reset, 75, 117–118
- hardware keyboard, 29–31
- HDR Camera app, 364–365, 472
- headset microphone, 32
- hiding
  - apps, 500
  - keyboard, 24
- history
  - Chrome, 248, 265
  - Phone app, 320–322
- Home button, 4, 486
- Home screen, 2–4
  - HTC Sense, 492, 494, 496–497
  - TouchWiz, 449–451
- Home screen panel indicator, 4
- Home screens
  - adding, 87–88
  - apps
    - adding*, 89
    - moving*, 89
  - customizing, 88
  - defaults, 94
  - deleting, 87–89
  - Dropbox app, 93
  - folders, 92–93
  - rearranging, 94
  - removing items, 94
  - repositioning items, 93
  - skins, 88
  - wallpaper, 94–96
  - web addresses, adding, 91–92
  - widgets, 89–91
- Honeycomb, 16
- hotspots, 127–128
- HP Print Service Plugin, 308
- HTC Manager app, 61–62
- HTC Sense
  - apps, 487
    - hiding*, 500
    - sorting*, 498–500
    - unhiding*, 500
  - Apps screen, 498–500
  - BlinkFeed feature, 492–494, 496
  - buttons, 486
  - camera, 505–513
  - gestures, 488, 502–503
  - grid size of Apps screen, 500
  - Home button, 486
  - Home screen, 492, 494, 496–497
  - Kid Mode, 492
  - lock screen, 490–491
  - music, 503–505

Music app, 503–504  
 navigating, 486–487  
 Phone app, 501–503  
 Play Music app, 505  
 Quick Settings panel, 489–490  
 ringtones, 504–505  
 security, 491  
 Security screen, 491  
 Sense skin, 485  
 status bar, 497–498  
 swiping, 488  
 tabs, 487  
 tapping, 488  
 UltraPixel technology, 505  
 unlocking, 486

HTC Zoe feature (HTC Sense Camera app), 513

---

## I

Ice Cream Sandwich, 16

iCloud service, 60

IMAP mail server technology, 211–212

Import/Export Contacts dialog box, 294

importing  
   contacts, 294–295  
   music, 68–69  
   photos, 64, 68–69  
   videos, 64, 68–69

Improve Face Matching feature, 106

Incognito mode (Internet app), 479

incognito web browsing, 266–267

input options  
   configuring, 102–105  
   Language & Input screen, 102–103

Input Options dialog box, 105

installing  
   Android File Transfer, 65–66  
   Android SDK, 376  
   apps, 161–163  
   Camera app, 354  
   Chrome, 246, 268–269  
   digital certificates, 135–137  
   Facebook Messenger, 409  
   file managers, 167  
   Google Now, 272

launchers, 96, 99  
   sync apps, 62–63

Instant Mixes screen (Play Music app), 393

internal memory, 68

Internet app, 474–476  
   bookmarks, 476–477  
   Incognito mode, 479  
   navigating among windows, 477–478  
   Quick Access screen, 478–479  
   Saved Pages list, 476  
   syncing Internet browsing, 479  
   web page shortcuts, 479

Internet calling, 334

Internet Mail Access Protocol (IMAP), 211

Internet sharing, 146–150, 153–155

invitations, 299–300

IP settings, 140–142

IPVanish, 155

iTunes, 60

iTunes Match, 378

---

## J

JavaScript, 256

Jelly Bean, 16

joining contact records, 293–294

---

## K

keeping documents on your device, 306

Keep Wi-Fi On During Sleep dialog box, 139

keyboards  
   emoji, 33  
   Google Keyboard, 103  
   Hacker's Keyboard, 34  
   hardware keyboard, 29–31  
   onscreen, 24–26  
   selecting, 103–104  
   Smart Keyboard Pro, 34  
   SwiftKey keyboard, 34

keyboard shortcuts for apps, 170–171

Kid Mode (HTC Sense), 492

Kies app, 61, 385

killing apps, 178

KitKat, 16

KitKat Easter Egg, 112

KitKat External SD Card Patch, 49

---

## L

labeling email messages, 190–192, 198–199

Language & Input screen, 102–103

language settings  
   Facebook, 416–417  
   Google Now, 276

launchers  
   choosing, 97  
   default launcher, 96, 99–102  
   defined, 96  
   deleting, 101  
   Go Launcher EX, 98  
   Google Now Launcher, 97  
   installing, 96, 99  
   Nova Launcher, 97  
   permissions, 98  
   switching, 100  
   wallpaper, 95

launching  
   apps, 2  
   Camera app, 467  
   Google Drive app, 301  
   sync apps, 67–68  
   widgets, 89–91

layout of keyboard  
   hardware keyboard, 31  
   onscreen keyboard, 24

lenses, 368

listening to music, 378

Listen Now screen (Play Music app), 392

lithium-ion battery, 46–47

live wallpapers, 95

loading  
   files  
     Bluetooth, 72  
     Dropbox, 72  
     Google Drive, 72  
     Near Field Communication (NFC), 72  
     SD card, 71–72  
     wireless connections, 72

local printer, 307–308

location settings, 109–111, 256  
 Camera app, 360  
 Facebook Messenger, 413  
 Google Now, 279  
 Twitter, 435, 437

location tags (Camera app), 472

location tracking, 44

locking  
 apps, 171  
 HTC Sense, 486  
 remote locking and wiping, 81–86

locking settings, 106–107

lock screen, 2–3  
 Camera app, 356–357  
 configuring, 105  
 Face Unlock method, 105–106  
 Google Now, 282  
 HTC Sense, 490–491  
 owner information, 108  
 Password Unlock method, 106  
 Pattern Unlock method, 106  
 PIN Unlock method, 106  
 Slide Unlock method, 105  
 unlocking, 2  
 widgets, 107–108

Lock Screen Previews dialog box, 491

lossless compression, 380

lossy compression, 380

## M

MAC address, 140

mail servers, 211–212, 216–220

managing  
 cellular connections, 120  
 contacts, 291  
 files, 70–71

Maps app  
 capabilities, 284  
 Google Earth shortcut, 285  
 navigating, 284–286  
 saving maps for offline use, 287–288  
 settings, 289–290

media  
 file storage space, 47–48  
 volume levels, 19–20

Memo, 466

memory, 68

Menu button (apps), 8–9

menus, 8–9

merging  
 hangouts, 350  
 phone calls, 324–325

microphones, 32

mobile hotspots, 127–128

Mobile Network Settings screen, 120–122

Motorola Device Manager app, 61

moving apps on Home screen, 89

MP3 files, 379

multiperson phone calls, 322–325

multiuser feature for tablets, 34–36

Multi Window feature (TouchWiz), 462–465

music  
 buying, 391–392  
 CDs, ripping, 381–385  
 Chromecast device, 315–316  
 deleting, 397–398  
 downloading, 396  
 Equalizer, 403–405  
 formats supported, 379–381  
 HTC Sense, 503–505  
 importing, 68–69  
 listening to, 378  
 playing, 394–396  
 playlists, 401–403  
 Play Music app, 377–378  
 streaming, 378, 406  
 syncing songs, 386–391  
 transcoding files, 385–386  
 transferring, 378–379

Music app (HTC Sense), 503–504

My Drive screen (Google Drive), 301

My Library screen (Play Music app), 392–393

My Magazine (TouchWiz), 450

## N

naming folders, 93

navigating  
 Apps screen, 2, 4–5  
 Camera app, 354–356  
 controls, 9–10  
 dialog boxes, 11–12  
 documents, 302  
 Email app mailboxes, 238–239

folders, 302

Gmail, 192

Google Drive app, 302–304

Google Now, 272–273

Home screen, 2–4

HTC Sense, 486–487

Internet app, 477–478

lock screen, 2–3

Maps app, 284–286

menus, 8–9

radio buttons, 10–11

TouchWiz, 449–451

Twitter, 435–436

Nearby Places feature (Phone app), 328

Near Field Communication (NFC)  
 loading files, 72  
 S Beam, 480

New Playlist dialog box, 402–403

nonowner account, 36

notification light, 22

notification-management  
 apps, 23

notifications  
 apps, 20  
 Calendar app, 297  
 clearing, 20–23  
 email messages, 188  
 Facebook, 416  
 Facebook Messenger, 412–415  
 recovering, 21  
 responding, 20  
 TouchWiz, 455–456  
 turning on/off, 22  
 Twitter, 435, 439–441  
 volume levels, 19

Notifications pane, 20

Notifications panel, 5–6

Nova Launcher, 97

numbers, typing, 24

## O

offensive words, blocking, 28

Ogg Vorbis, 380, 384

onscreen keyboard, 24–26

opening  
 Camera app, 354  
 documents, 303  
 folders, 303

open-source licenses, 401

## operating system (OS)

- devices, 15
  - updating, 17
  - versions, 16–18
- options, turning on/off, 9–10
- owner account, 36
- owner information, 108

---

**P**

- package files for apps, 167–169
- Pandora, 378, 406
- Panorama mode (Camera app), 469
- passcode, 2
- passwords in Chrome, 249–251
- Password Unlock method, 106
- Pattern Unlock method, 106
- PCM (Pulse Code Modulation), 381
- People app, 291–295
- permissions
- apps, 161–163
  - launchers, 98
- personal dictionary, 28–29
- Personal Results feature (Google Now), 279
- phishing, 200
- Phone app
- Caller ID, 332–333
  - Call Waiting, 332–333
  - configuring, 327–329
  - dial pad touch tones, 329
  - Fixed Dialing Numbers (FDN), 330–331
  - history, 320–322
  - HTC Sense, 501–503
  - layout, 318
  - look, 318
  - opening, 317
  - Quick Responses feature, 330
  - ringtones, 329
  - settings, 327–329
  - TTY Mode, 331
  - vibrate option, 329
  - voicemail, 329
- phone calls
- blocking, 335–336
  - Caller ID by Google feature, 328
  - call forwarding, 332
  - call log, 320–322
  - conference phone calls, 324–325

- custom ringtones, 334–335
  - declining, 325–326
  - Frequently Contacted list, 320
  - Google Voice app, 338
  - Internet calling, 334
  - limiting outgoing calls with Fixed Dialing Numbers (FDN), 330–331
  - making, 318–320
  - merging, 324–325
  - multiperson, 322–325
  - Nearby Places feature, 328
  - receiving, 325–326
  - screening, 335–336
  - Smail Dialer, 322
  - Speed Dial list, 318–320
  - taking, 325–326
  - text responses to phone calls, 327
- PhotoInfo Eraser app, 360
- photos
- deleting, 55–56
  - editing, 372, 374–375
  - importing, 64, 68–69
  - lens blur, 369–372
  - panoramas, 369
  - reviewing, 365–367
  - taking, 360–365
- Photos app, 372, 374–375
- PIN, 2
- pinch in, 12
- pinch out, 13
- PIN Unlock method, 106
- Pixelgarde Free app, 360
- playing songs, 394–396
- playlists, 401–403
- Playlists screen (Play Music app), 392
- Play Music app, 377–378, 387–393, 398–401
- Chromecast device, 315–316
  - HTC Sense device, 505
- Play Store app, 161, 164–166
- POP3 mail server technology, 211–212
- pop-ups, 256
- portable chargers, 45
- Portable Wi-Fi Hotspot feature, 146, 148–150
- ports for email servers, 216–220
- Post Office Protocol (POP3) mail server technology, 211

- preferences for apps, 176–177
- Preferred Network Type dialog box, 122–123
- preloading web pages, 258–259
- preventing screen from rotating, 13
- PrinterShare app, 308–309
- printing documents
- cloud printer, 308–309
  - HP Print Service Plugin, 308
  - local printer, 307–308
  - on existing printer, 309
  - options, 307
- privacy
- Chrome settings, 246, 252–254
  - decrypting, 115–117
  - encryption, 112–115
  - Facebook, 417–420, 422–426
  - location settings, 109–111
- proxy server, 142–143
- Pulse Code Modulation (PCM), 381
- pulsing light, 22

---

**Q**

- Quick Access screen (Internet app), 478–479
- Quick Responses Calendar app, 297
- Quick Responses feature (Email app), 236–238
- Quick Responses feature (Phone app), 330
- Quick Settings panel, 6–7, 489–490
- QWERTY keyboard layout, 31

---

**R**

- radio buttons, 10–11
- reading email messages, 195–196, 232–235
- real fractions, 25
- rearranging Home screens, 94
- rebooting into Safe mode, 175–176
- receiving
- email messages, 232–235
  - phone calls, 325–326

Recent Apps button, 4  
 Recent Apps list, 22  
 Recent Apps screen, 171–173  
 recharging devices, 45–47  
 Recording Mode (Camera app), 472  
 recovering  
   from update or restore problems, 75  
   notifications, 21  
   space, 54–57  
 reformatting SD card, 50–51  
 refunds for apps, 163  
 reminders  
   Calendar app, 297  
   Google Now, 282–284  
 Remote Desktop feature, 310  
 Remote Find and Wiping, 81–86  
 remote locking and wiping, 81–86  
 Remote Viewfinder (Camera app), 473  
 removing  
   Facebook accounts, 433–434  
   items from Home screen, 94  
 renaming maps, 288  
 replying to email messages, 183, 235–236  
 Report a Problem dialog box, 163  
 repositioning items on Home screen, 93  
 resetting app preferences, 176–177  
 responding to notifications, 20  
 restarting, 75  
 restoring devices, 79–81  
 restricted profiles, 34, 37–39  
 reviewing photos, 365–367  
 ringing devices, 84  
 Ringtone Maker from Big Bang app, 335  
 ringtones, 11, 329, 334–335  
   contacts, 291  
   distinctive ringtone for urgent updates, 282  
   HTC Sense, 504–505  
   volume levels, 19  
 ripping CDs, 381–385  
 rooting devices, 49

rotating screen, 13  
 rule of thirds, 364  
 running  
   apps, 170–171  
   sync apps, 63, 67–68

## S

Safe mode, 175–176  
 Samsung account, 448  
 Samsung Apps app, 465  
 Samsung Hub app, 465  
 Samsung Kies app, 61, 385  
 Samsung's TouchWiz skin, 17–18  
 Save Passwords feature (Chrome), 251  
 saving maps for offline use, 287–288  
 S Beam, 479–480  
 scanning documents, 306  
 screen  
   Apps screen, 4–5  
   Home screen (HTC Sense), 492, 494, 496–497  
 screening phone calls, 335–336  
 screen lock, 38  
 screens  
   App Info screen, 173  
   Apps screen  
     HTC Sense, 498–500  
     launching apps, 2  
     TouchWiz, 453–454  
   automatic rotation, 13  
   Home screens, 2–4  
     adding, 87–88  
     apps, 89  
     customizing, 88  
     defaults, 94  
     deleting, 87–89  
     Dropbox app, 93  
     folders, 92–93  
     rearranging, 94  
     removing items, 94  
     repositioning items, 93  
     skins, 88  
     TouchWiz, 449–451  
     wallpaper, 94–96  
     web addresses, 91–92  
     widgets, 89–91  
   lock screen, 2–3  
     Camera app, 356–357  
     configuring, 105  
     Face Unlock method, 105–106  
     Google Now, 282  
     HTC Sense, 490–491  
     owner information, 108  
     Password Unlock method, 106  
     Pattern Unlock method, 106  
     PIN Unlock method, 106  
     Slide Unlock method, 105  
     widgets, 107–108  
   preventing from rotating, 13  
   Recent Apps screen, 171–173  
   Security screen (HTC Sense), 491  
 screenshots, capturing, 376, 481  
 SD card, 18, 48–51, 71–72  
 search engines, 3, 250  
 Search Engine Storage option (Google Now), 280–281  
 searching  
   documents, 304  
   folders, 304  
   Gmail, 201–205  
   Twitter, 436  
 Secure Sockets Layer (SSL), 212  
 security  
   closed Wi-Fi networks, 131–132  
   Cloud Print, 308  
   digital certificates, 212  
   Email app, 212–213  
   HTC Sense, 491  
   lock screen, 2–3  
   shared devices, 39–40  
   Twitter, 442, 444–445  
   2-step verification (Gmail), 205–208  
 Security screen (HTC Sense), 491  
 selecting keyboards, 103–104  
 sending email messages, 196–197, 229–232  
 sensors, 13  
 separating contact records, 293–294  
 service set identifier (SSID), 131  
 settings  
   Access Point Name (APN) setting, 123  
   Calendar app, 296–298  
   Camera app, 357–360, 467–474  
   Chrome, 246, 252–257  
   Email app, 240–243  
   Facebook, 415–434  
   Facebook Messenger, 412–415  
   Gmail accounts, 180–181  
   Google Drive app, 301, 304

- Google Now, 272, 275–282
- hard reset, 117–118
- HTC Sense Camera app, 508–513
- launcher default, 99–102
- location settings, 109–111, 256
- locking settings, 106–107
- Maps app, 289–290
- Mobile Network Settings screen, 120–122
- Phone app, 327–329
- Quick Settings panel, 6–7
- Text Correction feature, 26–28
- TouchWiz, 455–460
- Twitter, 437, 439–442
- volume levels, 19–20
- wallpaper, 94–96
- Wi-Fi, 137–139
- Settings app
  - Choose Screen Lock screen, 3
  - Display button, 13
  - opening, 7–8
  - skins, 8
- Settings Shortcut widget, 21
- setting up vEmail app accounts, 213–227
- Set Up User Now? dialog box, 36
- shared devices and security, 39–40
- sharing
  - calendars, 300
  - Internet connection, 146–150, 153–155
- Shazam app, 405
- S Health, 466
- shooting video, 375–376
- shortcut for sync app, 63
- Shot & More mode (Camera app), 468–469
- sideloading apps, 166–170
- signatures (Gmail), 189
- signing in to Google account, 250
- SIM Card
  - contacts, 294
  - lock, 336–337
- Simple Mail Transfer Protocol (SMTP), 211
- skins
  - defined, 17
  - features, 15
  - functionality, 17
  - Home screens, 88
- HTC Sense skin, 485
- OS updates, 17
- Settings app, 8
- slow devices, 17
- TouchWiz skin
  - animations, 484
  - Apps screen, 453–454
  - buttons, 448–449
  - features, 447
  - gestures, 452–453
  - Home screen, 449–451
  - Multi Window feature, 462–465
  - My Magazine, 450
  - navigating, 449–451
  - notifications, 455–456
  - Quick Settings bar, 455–456
  - Quick Settings panel, 457–458
  - Samsung Apps app, 465
  - settings, 455–460
  - Settings screen, 458–460
  - S Voice, 449
  - Toolbox, 460–461
  - turning on/off features, 482–484
  - versions, 447
  - wallpapers, 94
- Sleep dialog box, 43
- Slide Unlock method, 105
- Smail Dialer, 322
- Smart Keyboard Pro, 34
- SMS, configuring in Hangouts, 343–345
- SMTP mail server technology, 211–212
- S Note, 466
- soft buttons
  - HTC Sense, 486
  - TouchWiz, 448–449
- software updates, 72–74
- songs
  - downloading, 396
  - playing, 394–396
  - playlists, 401–403
- sorting
  - apps, 498–500
  - documents, 303
  - folders, 303
- SoundHound app, 406
- sounds
  - Facebook Messenger, 413
  - Twitter, 437
- spam, 200
- spare battery, 45
- spare charger, 46
- special characters, 24
- spelling, 26–28
- S Pen, 480–482
- S Planner, 466
- Spotify, 378, 406
- SSID (service set identifier), 131
- SSL (Secure Sockets Layer), 212
- STARTTLS, 213
- status bar (HTC Sense), 497–498
- status bar (Home screen), 3
- storage
  - checking, 52–54
  - recovering space, 54–57
- storage location (Camera app), 472
- Storage screen, 52–54
- storage space, 47–48
- S Translator, 466
- streaming Chromecast device, 311
- streaming music, 378, 406
- StrongVPN, 155
- stylus, 480–482
- suggestions, 26
- S Voice, 449, 465, 484
- SwiftKey keyboard, 34
- swipe, 12, 487–488
- switching
  - apps, 172
  - launchers, 100
  - layouts for onscreen keyboard, 24
  - user accounts, 38–39
- switching cameras, 365
- sync apps
  - Android File Transfer, 60
  - downloading, 65
  - file management, 70–71
  - installing, 65–66
  - running, 70–71
  - size limit on files, 71
  - Android File Transfer for Mac app, 60
  - backups, 78–79
  - doubleTwist, 61
  - HTC Manager app, 61–62
  - installing, 62–63
  - Kies, 61



- launching, 67–68
- Motorola Device Manager app, 61
- running, 63, 67–68
- shortcuts, 63
- syncing
  - email messages, 190
  - information between computer and device, 69–70
  - with a computer, 60
- syncing contacts with Facebook, 408–409
- syncing Internet browsing with Internet app, 479
- syncing songs, 386–391
- Sync Manager, 80–81

## T

---

- tablets
  - decrypting, 115–117
  - encryption, 113–115
  - Google Voice app, 338
  - hard reset, 117–118
  - multiuser feature, 34–36
- tabs
  - Chrome, 249, 261–265
  - HTC Sense, 487
- taking
  - phone calls, 325–326
  - photos, 360–365
- tap, 12, 488
- tap and hold, 12
- task-killer apps, 178
- telephoto lenses, 368
- tethering, 146–147, 153–155
- Tethering & Portable Hotspot screen, 146–147
- text
  - dictation, 31–32
  - entering
    - with *hardware keyboard*, 29–31
    - with *onscreen keyboard*, 24–26
- Text Correction feature, 26–28
- text responses to phone calls, 327
- three dots (Menu button), 8–9
- timer (Camera app), 363, 472
- time zone (Calendar app), 297
- TLS (Transport Layer Security), 212
- Toolbox (TouchWiz), 460–461
- Total Audio Converter app, 384
- Total Audio Converter for Windows app, 386
- TouchWiz skin
  - animations, 484
  - Apps screen, 453–454
  - buttons, 448–449
  - features, 447
  - gestures, 452–453
  - Home screen, 449–451
  - Multi Window feature, 462–465
  - My Magazine, 450
  - navigating, 449–451
  - notifications, 455–456
  - Quick Settings bar, 455–456
  - Quick Settings panel, 457–458
  - Samsung Apps app, 465
  - settings, 455–460
  - Settings screen, 458–460
  - S Voice, 449
  - Toolbox, 460–461
  - turning on/off features, 482–484
  - versions, 447
- TouchWiz skin (Samsung), 17–18
- TrackID app, 406
- transcoding files, 385–386
- transferring
  - files via email, 72
  - music, 378–379
- transferring files to another device via Bluetooth, 152–153
- translation services, 256, 466
- Transport Layer Security (TLS), 212
- tripod, 367
- troubleshooting update or restore problems, 75
- TTY Mode, 331
- Tuneln Radio, 406
- turning on/off
  - Airplane mode, 120
  - Gesture Typing feature, 25–26
  - lock screen, 3
  - notification light, 22
  - notifications, 22
  - options, 9–10
  - TouchWiz features, 482–484
  - Wi-Fi, 128–129
- Twitter
  - configuring, 437, 439–442
  - Home screen, 435

- location settings, 435
- Login Verification, 442, 444–445
- messages, 436
- multiple accounts, 442, 445
- navigating, 435–436
- notifications, 435, 439–441
- searching, 436
- security, 442, 444–445
- settings, 437, 439–442
- signing in, 434–435
- sounds, 437
- two-factor authentication in Facebook, 426–431
- typing
  - alternate characters, 24
  - dictation, 31–32
  - Gesture Typing feature, 25–26
  - Google Voice Typing feature, 103
  - numbers, 24
  - real fractions, 25
  - special characters, 24
  - suggestions, 26
  - Text Correction feature, 26–28

## U

---

- UltraPixel technology (HTC Sense), 505
- Ultra Power Saving mode, 45
- uncheck (defined), 10
- unhiding apps (HTC Sense), 500
- uninstalling apps, 174–175
- unlocking HTC Sense, 486
- unlocking the lock screen, 2
- updating
  - apps, 74–75, 165
  - Camera app, 354
  - maps, 288
  - operating system, 17
  - software, 72–74
- upgrading battery, 45
- uploading documents, 306
- USB cable, 46
- USB On-the-Go memory stick, 168
- USB OTG, 29, 30
- USB tethering, 146, 147
- Use Details screen, 42
- User Account Control dialog box, 62–63



user accounts  
   creating, 34–36  
   deleting, 39  
   switching among, 38–39  
 user reviews of wallpapers, 96  
 users  
   multiuser feature for tablets, 34–36  
   restricted profile, 37–38  
   shared devices, 39–40  
 Users screen, 35

## V

Vacation Responder feature (Gmail), 189–190  
 variable bit rate (VBR), 380  
 VBR (variable bit rate), 380  
 version numbers and names, 16–18  
 videos  
   deleting, 55–56  
   importing, 64, 68–69  
   shooting, 375–376  
 video size (Camera app), 471  
 video stabilization (Camera app), 472  
 viewing calendars, 298–299  
 Virtual Network Computing (VNC), 310  
 virtual private networking (VPN), 155–159  
 Virtual Tour mode (Camera app), 469  
 VNC (Virtual Network Computing), 310  
 Voice Control feature (Camera app), 474  
 voicemail, 329  
 Voice Typing feature, 31–32  
 Volume Key (Camera app), 473  
 volume levels, 19–20  
 Volumes dialog box, 19  
 VPN (virtual private networking), 155–159

## W

wallpaper  
   downloading, 96  
   live wallpapers, 95  
   setting, 94–96  
   user reviews, 96  
 warnings about data plan limits, 125  
 WAV (Waveform Audio File Format), 381  
 web addresses, adding to Home screen, 91–92  
 web browsing, 259–267  
 web page shortcuts (Internet app), 479  
 White Balance (Camera app), 473  
 whitelists, 139–140  
 widgets  
   adding to Home screen, 89–91  
   adding to lock screen, 108  
   defined, 4  
   finding, 89  
   lock screen, 107–108  
 Wi-Fi  
   advanced Wi-Fi settings, 137–139  
   closed networks, 131–132  
   connecting to Wi-Fi networks, 130–132  
   digital certificates, 135–137  
   forgetting a network, 145–146  
   improving connections, 144–145  
   MAC address, 140  
   proxy server, 142–143  
   settings, 137–139  
   sharing Internet connection, 146–150, 153–155  
   turning on/off, 128–129  
   virtual private networking (VPN), 155–159  
   whitelists, 139–140  
 Wi-Fi analyzer app, 145  
 Wi-Fi Direct, 133–135  
 Wi-Fi Frequency Band dialog box, 139  
 Wi-Fi Protected Setup (WPS), 132–133  
 Wi-Fi stumbler app, 145  
 Windows Explorer, 60  
 wireless connections  
   digital certificates, 135–137  
   forgetting a network, 145–146  
   improving, 144–145  
   IP settings, 140–142  
   loading files, 72  
   proxy server, 142–143  
   sharing Internet connection, 146–150, 153–155  
   virtual private networking (VPN), 155–159  
 Work and Home places (Google Now), 275  
 WPS (Wi-Fi Protected Setup), 132–133  
 writing email messages, 196–197

## X

XLD app, 386

## Y

Yahoo! search engine, 250

## Z

Zoe feature (HTC Sense Camera app), 513  
 zooming in/out (Camera app), 361, 467  
 zoom lenses, 368