

Table 4-12 *CiscoIPPhoneMenu Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneMenu> <Title>Title text goes here</Title> <Prompt>Prompt text goes here</Prompt> <MenuItem> <Name>The name of each menu item</Name> <URL>The URL associated with the menu item</URL> </MenuItem> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL or URI of soft key</URL> <Position>Position information of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneMenu></pre>	<pre>CiscoIPPhoneMenu Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters Up to 100 instances of MenuItem Name: ANSI string up to 64 characters URL: ANSI string up to 256 characters Up to 8 instances of SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8</pre>	<pre>SoftKey:Select SoftKey:Exit</pre>

Table 4-13 *CiscoIPPhoneText Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneText> <Title>Title text goes here</Title> <Prompt>The prompt text goes here</Prompt> <Text>The text to be displayed as the message body goes here</Text> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL or URI of soft key</URL> <Position>Position information of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneText></pre>	<pre>CiscoIPPhoneText Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters Text: ANSI string up to 4000 characters Up to 8 instances of SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8</pre>	<pre>SoftKey:Update SoftKey:Exit</pre>

Table 4-14 *CiscoIPPhoneInput Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre> <CiscoIPPhoneInput> <Title>Directory title goes here</Title> <Prompt>Prompt text goes here</Prompt> <URL>The target URL for the completed input goes here</URL> <InputItem> <DisplayName>Name of the input field to display</DisplayName> <QueryStringParam>The parameter to be added to the target URL</QueryStringParam> <InputFlags>The flag specifying the type of allowable input</InputFlags> <DefaultValue>The default display name</DefaultValue> </InputItem> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL or URI of soft key</URL> <Position>Position information of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneInput> </pre>	<pre> CiscoIPPhoneInput Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters URL: ANSI string up to 256 characters Up to 5 instances of InputItem DisplayName: ANSI string up to 32 characters QueryStringParam: ANSI string up to 32 characters InputFlags: ANSI string up to 3 characters DefaultValue: ANSI string up to 32 characters Up to 8 SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8 </pre>	<pre> SoftKey:Submit SoftKey:<< SoftKey:Cancel </pre>

Table 4-15 *CiscoIPPhoneDirectory Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneDirectory> <Title>Directory title goes here</Title> <Prompt>Prompt text goes here</Prompt> <DirectoryEntry> <Name>The name of the directory entry</Name> <Telephone>The telephone number for the entry</Telephone> </DirectoryEntry> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL or URI of soft key</URL> <Position>Position information of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneDirectory></pre>	<pre>CiscoIPPhoneDirectory Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters Up to 32 instances of DirectoryEntry Name: ANSI string up to 32 characters Telephone: ANSI string up to 32 characters Up to 8 instances of SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8</pre>	<pre>SoftKey:Dial SoftKey:EditDial SoftKey:Cancel</pre>

Table 4-16 *CiscoIPPhoneImage Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneImage> <Title>Image title goes here</Title> <Prompt>Prompt text goes here</Prompt> <LocationX>Position information of graphic</LocationX> <LocationY>Position information of graphic</LocationY> <Width>Size information for the graphic</Width> <Height>Size information for the graphic</Height> <Depth>Number of bits per pixel</Depth> <Data>Packed pixel data</Data> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL of soft key</URL> <Position>Numerical position of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneImage></pre>	<pre>CiscoIPPhoneImage Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters LocationX: Numeric value from -1 to 133 LocationY: Numeric value from -1 to 65 Width: Numeric value from 1 to 133 Height: Numeric value from 1 to 65 Depth: Numeric value from 1 to 2 Data: Hexadecimal value up to 2200 Up to 8 instances of SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8</pre>	<pre>SoftKey:Update SoftKey:Exit</pre>

Table 4-17 *CiscoIPPhoneGraphicMenu Object Quick Reference*

Definition	Range	SoftKey:URLs
<pre> <CiscoIPPhoneGraphicMenu> <Title>Menu title goes here</Title> <Prompt>Prompt text goes here</Prompt> <LocationX>Position information of graphic</LocationX> <LocationY>Position information of graphic</LocationY> <Width>Size information for the graphic</Width> <Height>Size information for the graphic</Height> <Depth>Number of bits per pixel</Depth> <Data>Packed pixel data</Data> <MenuItem> <Name>The name of each menu item</Name> <URL>The URL associated with the menu item</URL> </MenuItem> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL of soft key</URL> <Position>Numerical position of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneGraphicMenu> </pre>	<pre> CiscoIPPhoneGraphicMenu Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters LocationX: Numeric value from -1 to 133 LocationY: Numeric value from -1 to 65 Width: Numeric value from 1 to 133 Height: Numeric value from 1 to 65 Depth: Numeric value from 1 to 2 Data: Hexadecimal value up to 2200 Up to 12 instances of MenuItem Name: ANSI string up to 64 characters URL: ANSI string up to 256 characters Up to 8 instances of SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8 </pre>	<pre> SoftKey:Update SoftKey:Exit </pre>

Table 4-18 *CiscoIPPhoneIconMenu Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneIconMenu> <Title>Title text goes here</Title> <Prompt>Prompt text goes here</Prompt> <MenuItem> <Name>The name of each menu item</Name> <URL>The URL associated with the menu item</URL> <IconIndex>Indicates what IconItem to display</IconIndex> </MenuItem> <IconItem> <Index>Numeric identifier of the custom icon</IconIndex> <Width>Size information for the graphic</Width> <Height>Size information for the graphic</Height> <Depth>Number of bits per pixel</Depth> <Data>Packed pixel data</Data> </IconItem> <SoftKeyItem> <Name>Name of soft key</Name> <URL>URL of soft key</URL> <Position>Numerical position of the soft key</Position> </SoftKeyItem> </CiscoIPPhoneIconMenu></pre>	<pre>CiscoIPPhoneIconMenu Title: ANSI string up to 32 characters Prompt: ANSI string up to 32 characters Up to 100 instances of MenuItem Name: ANSI string up to 64 characters URL: ANSI string up to 256 characters IconIndex: Numeric value from 0 to 9 Up to 10 instances of IconItem Index: Numeric value from 0 to 9 Width: Numeric value from 1 to 16 Height: Numeric value from 1 to 10 Depth: Numeric value from 1 to 2 Data: Hexadecimal value up to 50 Up to 8 instances of SoftKeyItem Name: ANSI string up to 32 characters URL: ANSI string up to 256 characters Position: Single-digit numeric value from 1 to 8</pre>	<pre>SoftKey:Select SoftKey:Exit</pre>

Table 4-19 *CiscoIPPhoneExecute Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneExecute> <ExecuteItem URL="The action you want the phone to take"/> </CiscoIPPhoneExecute></pre>	<pre>CiscoIPPhoneIconExecute Up to 3 instances of ExecuteItem URL: ANSI string up to 256 characters</pre>	

Table 4-20 *CiscoIPPhoneResponse Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneResponse> <ResponseItem Status="the success or failure of the action" Data="the information associated with the request" URL="the URL or URI specified in the Execute object"/> </CiscoIPPhoneResponse></pre>	<pre>CiscoIPPhoneIconResponse Up to 3 instances of ResponseItem Status: Unsigned16 Data: ANSI string up to 32 characters URL: ANSI string up to 256 characters</pre>	

Table 4-21 *CiscoIPPhoneError Object Quick Reference*

Definition	Range	SoftKey:URIs
<pre><CiscoIPPhoneError Number="x"/></pre>	<pre>Number: An error code in the range 1 to 4</pre>	