

SECOND EDITION

# My GoPro HERO<sup>5</sup> Camera



Jason R. Rich

**que**<sup>®</sup>

800 East 96th Street,  
Indianapolis, Indiana 46240 USA

# My GoPro HERO<sup>5</sup> Camera, Second Edition

**Copyright © 2017 by Pearson Education, Inc.**

All rights reserved. Printed in the United States of America. This publication is protected by copyright, and permission must be obtained from the publisher prior to any prohibited reproduction, storage in a retrieval system, or transmission in any form or by any means, electronic, mechanical, photocopying, recording, or likewise. For information regarding permissions, request forms, and the appropriate contacts within the Pearson Education Global Rights & Permissions Department, please visit [www.pearsoned.com/permissions/](http://www.pearsoned.com/permissions/). No patent liability is assumed with respect to the use of the information contained herein. Although every precaution has been taken in the preparation of this book, the publisher and author assume no responsibility for errors or omissions. Nor is any liability assumed for damages resulting from the use of the information contained herein.

ISBN-13: 978-0-7897-5830-9

ISBN-10: 0-7897-5830-X

Library of Congress Control Number: 2017935906

First Printing: May 2017

## Trademarks

All terms mentioned in this book that are known to be trademarks or service marks have been appropriately capitalized. Que Publishing cannot attest to the accuracy of this information. Use of a term in this book should not be regarded as affecting the validity of any trademark or service mark. GoPro is a registered trademark of GoPro, Inc. This book is not affiliated with or sponsored by GoPro, Inc.

## Warning and Disclaimer

Every effort has been made to make this book as complete and as accurate as possible, but no warranty or fitness is implied. The information provided is on an “as is” basis. The author and the publisher shall have neither liability nor responsibility to any person or entity with respect to any loss or damages arising from the information contained in this book.

## Special Sales

For information about buying this title in bulk quantities, or for special sales opportunities (which may include electronic versions; custom cover designs; and content particular to your business, training goals, marketing focus, or branding interests), please contact our corporate sales department at [corpsales@pearsoned.com](mailto:corpsales@pearsoned.com) or (800) 382-3419.

For government sales inquiries, please contact [governmentsales@pearsoned.com](mailto:governmentsales@pearsoned.com).

For questions about sales outside the U.S., please contact [intlcs@pearson.com](mailto:intlcs@pearson.com).

### Editor-in-Chief

Greg Wiegand

### Senior Acquisitions Editor

Laura Norman

### Development Editor

Charlotte Kughen

### Managing Editor

Sandra Schroeder

### Editorial Services

The Wordsmithery LLC

### Indexer

Cheryl Lenser

### Proofreader

The Wordsmithery LLC

### Technical Editor

Paul Sihvonon-Binder

### Editorial Assistant

Cindy Teeters

### Designer

Chuti Prasertsith

### Cover Art

Jason R. Rich

### Compositor

Bronkella Publishing

### Graphics

TJ Graham Art

# Contents at a Glance

<b>Chapter 1</b>	Overview of the GoPro HERO Cameras .....	<b>3</b>
<b>Chapter 2</b>	Getting Started with Your GoPro HERO5 Black .....	<b>27</b>
<b>Chapter 3</b>	Getting Started with Your HERO5 Session or HERO Session .....	<b>61</b>
<b>Chapter 4</b>	Overview of GoPro HERO Mounts .....	<b>83</b>
<b>Chapter 5</b>	Must-Have GoPro Camera Accessories .....	<b>109</b>
<b>Chapter 6</b>	Choosing the Best Memory Cards .....	<b>125</b>
<b>Chapter 7</b>	Keeping Your Batteries Charged .....	<b>139</b>
<b>Chapter 8</b>	Remotely Controlling Your Camera .....	<b>149</b>
<b>Chapter 9</b>	Shooting High-Resolution Photos .....	<b>179</b>
<b>Chapter 10</b>	Strategies for Taking Professional-Quality Digital Pictures .....	<b>199</b>
<b>Chapter 11</b>	Shooting HD Video .....	<b>223</b>
<b>Chapter 12</b>	Capturing Sound and Using Artificial Light .....	<b>247</b>
<b>Chapter 13</b>	Strategies for Shooting Awesome HD Video .....	<b>263</b>
<b>Chapter 14</b>	Discovering the GoPro QUIK Desktop Software .....	<b>281</b>
<b>Chapter 15</b>	Using Mobile Devices with Your GoPro Camera .....	<b>315</b>
<b>Chapter 16</b>	Getting to Know the GoPro Plus Online Service .....	<b>353</b>
<b>Chapter 17</b>	Troubleshooting Camera-Related Problems and Overcoming Shooting Challenges .....	<b>371</b>
	Appendix: Additional GoPro Resources .....	<b>389</b>
	Index .....	<b>397</b>
<b>Chapter 18</b>	Taking Flight with the GoPro Karma Drone (ONLINE ONLY)	

Find the online chapter and other helpful information on this book's website at [quepublishing.com/title/9780789758309](http://quepublishing.com/title/9780789758309).

# Table of Contents

1

## Overview of the GoPro HERO Cameras 3

An Entirely New Shooting Experience .....	5
Understanding Digital Camera Resolution .....	7
Choosing the Right GoPro Camera .....	9
The GoPro HERO Session .....	12
The GoPro HERO5 Session .....	14
The GoPro HERO5 Black .....	15
Getting the Best Results with a Mount .....	18
Using GoPro Accessories .....	20
The GoPro Mobile Apps .....	20
The GoPro QUIK Desktop Software .....	22
Start Gathering Your GoPro Equipment .....	23

2

## Getting Started with Your GoPro HERO5 Black 27

Ten Improvements to the HERO5 Black .....	27
What Comes with the HERO5 Black .....	29
Choosing an FOV .....	30
Narrow .....	31
Linear .....	31
Medium .....	32
Wide .....	32
SuperView .....	32
Overview of the HERO5 Black's Body .....	32
The Front of the Camera .....	33
The Back of the Camera .....	35
The Right Side of the Camera .....	36
The Left Side of the Camera .....	37
The Top of the Camera .....	41
The Bottom of the Camera .....	42
Exploring the LCD Status Screen .....	42
Exploring the Camera's Full-Color Touchscreen .....	43
Setting Up the Camera for the First Time .....	46
Customizing Your HERO5 Black .....	47
Using Voice Commands .....	51

Updating Your Camera's Operating System .....	53
Update Using the GoPro Capture Mobile App .....	53
Update Using the QUIK Desktop Software .....	56
Update the Camera Manually .....	58

### **3 Getting Started with Your HERO5 Session or HERO Session 61**

Pros and Cons of the HERO Session and HERO5 Session .....	62
Pros .....	62
Cons .....	63
What Comes with the HERO Session and HERO5 Session .....	64
Turning On or Off Your Camera .....	66
Overview of the Camera's Body .....	67
The Front of the Camera .....	67
The Back of the Camera .....	69
The Top of the Camera .....	70
The Bottom of the Camera .....	71
The Right and Left Sides of the Camera .....	74
Setting Up the Camera for the First Time .....	77
Set Up the Camera .....	78
Using Voice Commands .....	78
Turn on Voice Control .....	79
Viewing or Playing Back Your Content .....	79
Updating the Camera's Operating System .....	80

### **4 Overview of GoPro HERO Mounts 83**

Using the Proper Housing .....	84
Use the GoPro Quick Release Buckle and Thumb Screw .....	85
Choosing the Best Mount for the Situation .....	87
Planning Your Shots and Choosing the Best Equipment .....	88
Attaching Mounts to Yourself or Your Equipment .....	90
Accessories that Enhance Shot Stability .....	91
Overview of GoPro Mounts .....	92
Mounts Available from GoPro .....	93
Popular Third-Party Mount Options .....	102
Finding and Purchasing Mounts and Accessories .....	106

## 5 **Must-Have GoPro Camera Accessories** **109**

Using The GoPro Smart Remote .....	110
The Anatomy of the Smart Remote .....	110
Charge the Smart Remote .....	111
Pair Your HERO5 Black Camera with the Smart Remote .....	112
Pair Your HERO5 Session Camera with the Smart Remote .....	114
Working with the Smart Remote .....	116
Using the REMO for Voice Control .....	118
Using a Quik Key to Transfer Your Content .....	119
Hitting the Road with the Seeker .....	121
More Useful GoPro Accessories .....	122
The Floaty Won't Let Your GoPro Sink .....	122

## 6 **Choosing the Best Memory Cards** **125**

The Importance of Speed .....	126
Storage Capacity .....	128
Where to Shop for microSD Memory Cards .....	130
Inserting a Memory Card into Your GoPro Camera .....	131
Insert a microSD Memory Card in the HERO5 Black .....	131
Insert a microSD Memory Card in the HERO5 Session .....	133
Format a microSD Memory Card That's Inserted in the HERO5 Black .....	134

## 7 **Keeping Your Batteries Charged** **139**

Estimating Battery Life .....	141
Using Compatible HERO5 Black Batteries .....	142
Inserting a Battery in Your HERO5 Black .....	143
Connecting Any GoPro Camera to an External Power Source .....	145
Increasing Battery Life While Shooting .....	146

**Controlling Your Camera 149**

Analyzing Your Shooting Situation .....	149
Choosing How to Control Your Camera .....	151
Voice Commands .....	152
The Smart Remote .....	152
The Capture Mobile App .....	153
Preparing to Shoot .....	154
Adjusting Your Camera Mode, Shooting Mode, and Related Settings .....	155
Work with the HERO5 Black's Touchscreen .....	156
Select Advanced Options on the HERO5 Black .....	158
Adjust Settings on the HERO5 Session .....	159
Getting Acquainted with Your Camera's Shooting Modes and Settings .....	162
Camera Modes .....	163
Understanding Advanced Shooting Features .....	169
Aspect Ratio .....	170
Auto Low Light .....	170
Color .....	171
Exposure Control with Auto Exposure .....	171
Exposure Control with Locked Exposure .....	172
Exposure Value Compensation (EV Comp) .....	172
GPS .....	172
ISO/ISO Minimum/ISO Maximum .....	172
Manual Audio Control .....	173
Protune .....	173
RAW Audio .....	174
RAW Format .....	175
Sharpness .....	175
Video Stabilization .....	175
White Balance .....	176
Wide Dynamic Range (WDR) .....	176

**Shooting High-Resolution Photos 179**

Comparing GoPro Camera Models for Taking Pictures .....	181
Working with Protune .....	183
Access the Protune Menu Using the HERO5 Black .....	183
Adjusting White Balance .....	187

Adjusting Color .....	188
Adjusting ISO Minimum and ISO Maximum .....	188
Adjusting Sharpness .....	190
Adjusting EV Comp .....	191
Using the QuikCapture Feature .....	192
Setting Your HERO5 Black's Default Mode .....	192
Options for Viewing Your Photos .....	194
View Your Photos on the HERO5 Black's Touchscreen .....	195

## **Strategies for Taking Professional-Quality Digital Pictures**

**199**

Don't Forget to Prepare .....	200
Choose an Interesting Subject .....	201
Shoot Action from a First- or Third-Person Perspective .....	203
Take Interesting Pictures of People .....	205
Capture the Perfect Selfie .....	206
Photograph Animals and Pets .....	208
Capture a Fast-Moving Subject .....	209
Shoot Visually Interesting Objects .....	209
Take Vivid Underwater Photos .....	210
Set Your Camera to the Best Mode .....	211
Using Your Camera's Time Lapse Photo Option .....	212
Taking Advantage of WDR .....	212
Use a Viewfinder with Your Camera When Taking Photos .....	214
Select the Most Appropriate Mount .....	215
Purchase Mounts That Offer the Most Flexibility .....	215
Pay Attention to Your Primary Light Source .....	216
Use the Rule of Thirds .....	217
Consider Your Shooting Angle .....	219
Properly Handle Low-Light Situations .....	220
Pay Attention to the Surroundings .....	220
Edit Your Photos After They've Been Shot .....	221

<b>11</b>	<b>Shooting HD Video</b>	<b>223</b>
	The Skill and Art of Videography .....	224
	Comparison of GoPro Camera Models for Shooting Video .....	225
	The GoPro HERO5 Black's Shooting Modes .....	228
	Video Shooting Mode .....	229
	Video+Photo Shooting Mode .....	232
	Looping Video Mode .....	233
	Time Lapse Video .....	233
	Advanced Video Features .....	234
	The HiLight Tagging Function .....	234
	Add HiLights When Previewing Video on the HERO5 Black's Screen .....	235
	Create HiLight Tags Using the Capture App or Smart Remote .....	236
	Working with Protune .....	237
	Adjusting White Balance .....	238
	Adjusting Color .....	239
	Adjusting ISO Limit .....	239
	Adjusting Shutter Speed .....	240
	Adjusting Sharpness .....	240
	Adjusting EV Comp .....	240
	Adjusting Audio .....	240
	Additional Options with the Capture Mobile App .....	241
	Switching Between Shooting Modes .....	242
	Control the Camera Using the Smart Remote .....	243
	Stabilizing the Camera .....	245
<b>12</b>	<b>Capturing Sound and Using Artificial Light</b>	<b>247</b>
	Recording High-Quality Sound .....	248
	Using the Camera's Built-In Microphone .....	249
	Connecting an External Microphone .....	251
	Adding Sound Effects and Music .....	254
	Achieving Good Lighting .....	255
	Setting Your Camera's Lighting Options .....	256
	Set Exposure Control (HERO5 Black) .....	256
	Using External Lighting Options .....	258
	Choosing the Best Continuous Lighting Solution for Your Shooting Situation .....	259

## 13 Strategies for Shooting Awesome HD Video 263

Shooting Strategies .....	264
Planning Is Essential .....	265
Being Prepared .....	266
Choosing the Shooting Resolution .....	268
Selecting the Best FPS Rate .....	271
Deciding Which FOV Option to Use .....	272
Planning Your Shots .....	274
Using Lighting to Your Advantage .....	276
Using Slow and Steady Movement .....	277
Marking Your Best Shots .....	278
Shoot Plenty of Raw Footage, Then Edit Later .....	278

## 14 Discovering the GoPro QUIK Desktop Software 281

Understanding the Video Editor's Role .....	283
Overview of Video Editing .....	284
Getting Started with the GoPro QUIK Desktop Software .....	286
Download and Install the Software .....	286
Import Your Content into the QUIK Desktop Software .....	289
Getting to Know the QUIK Desktop Software .....	294
Create a Mini-Video Production in Create Mode .....	298
Add GPS Details to Action Scenes .....	300
Getting to Know GoPro Studio's Layout .....	302
Transferring Raw Video Content to Your Computer .....	304
Editing in GoPro Studio .....	305
Using the Editing Tools .....	306
Enhancing Flawed Video Footage .....	307
Using Sound .....	308
Saving, Exporting, and Sharing Your Video Projects .....	309
Video-Editing Tips .....	309
Focus On Your Intended Audience .....	310
Take an Organized Approach to Editing .....	311
Use Shots That Will Keep Your Audience's Attention .....	311
Use Titles and Captions to Your Advantage .....	312
Don't Expect Hollywood-Style Results Immediately .....	313

## 15 Using Mobile Devices with Your GoPro Camera 315

Getting to Know GoPro's Mobile App Trio .....	316
Installing the Apps on Your Mobile Device .....	318
Install on an iPhone or iPad .....	318
Install on an Android Device .....	319
Pairing the Capture App with Your Camera .....	320
Pair the HERO5 Black with Capture .....	322
Taking Control of Your Camera Using the Capture App .....	326
The Camera Screen .....	328
The Media Screen .....	329
The Viewfinder Screen .....	333
Overview of the QUIK Mobile App .....	339
Edit Videos Using the QUIK Mobile App .....	340
Acquainting Yourself with the Splice Mobile App .....	346

## 16 Getting to Know the GoPro Plus Online Service 353

Getting to Know GoPro Plus .....	354
Setting Up Your GoPro Plus Account .....	355
Create a GoPro Plus Account .....	356
Using the Auto Upload Feature with Your HERO5	
Black Camera .....	357
Set Up the Auto Upload Feature .....	358
Using GoPro Plus with Your HERO Session or HERO5	
Session Camera .....	360
Accessing Stored Content from the QUIK Mobile App	
or QUIK Desktop Software .....	361
Access Content from GoPro Plus Using the QUIK	
Mobile App .....	361
Access Content from GoPro Plus Using the QUIK	
Desktop Software .....	364
Accessing GoPro Plus Content from Any Web Browser .....	365

## 17 Troubleshooting Camera-Related Problems and Overcoming Shooting Challenges 371

Troubleshooting Camera-Related Problems .....	372
The Camera Won't Turn On .....	372
The Camera Is On, But Unresponsive .....	373
The Touchscreen Does Not Respond .....	375

The Camera Won't Connect with the Capture App or Smart Remote .....	375
The HERO5 Black's Lens Fogs Up in a Super Suit .....	376
The Status Screen Says No SD, Full, or SD ERR .....	376
The Temperature Icon Is Displayed .....	378
Water Spots Have Formed on the Camera's Lens .....	378
Video Playback Is Choppy on the Computer .....	378
The Menus Are Different .....	379
The Computer Doesn't Recognize the Camera .....	379
The Camera Is Physically Damaged .....	379
Overcoming Common Shooting Mistakes .....	381
Your Photos or Videos Are Overexposed .....	381
Video Is Too Shaky .....	381
The Camera Mount Doesn't Maintain Its Position .....	382
When Shooting In Low Light, Photos or Video are Blurry or Underexposed .....	382
Too Much Fish-Eye Effect .....	382
The Colors Aren't as Vibrant as They Should Be .....	383
The Memory Card Fills Up Too Fast When I'm Shooting .....	384
Recover Photos or Video Accidentally Deleted from the MicroSD Memory Card .....	384
The Memory Card Is Full, but You Want to Keep Shooting .....	385
The Audio Is Poor Quality .....	385
Wind Noise Is Ruining the Audio .....	386
Finding Creative Inspiration .....	388

**A****Additional GoPro Resources****389**

Following GoPro on Social Media .....	390
Getting Help from GoPro .....	390
Keep Track of Your GoPro Information .....	391
Getting More with These Resources .....	391
Photo-Editing Software .....	392
Video-Editing Software .....	392
Third-Party Mobile Apps .....	393

Special Interest Groups .....	395
Free Online Video Tutorials .....	395
Creating a Detailed Shot List .....	395
GoPro Video Shot List .....	396
Index .....	397

Find the online chapter and other helpful information on this book's website at [quepublishing.com/title/9780789758309](http://quepublishing.com/title/9780789758309).

## About the Author

**Jason R. Rich** ([www.jasonrich.com](http://www.jasonrich.com)) is an accomplished author, journalist, and photographer, as well as an avid traveler. Some of his recently published books for Que include: *iPad and iPhone Tips and Tricks*, Sixth Edition, *My Digital Photography for Seniors*, *My Digital Travel for Seniors*, and *My Digital Entertainment for Seniors*.

As a photographer, Jason's work appears with his articles in major daily newspapers, national magazines and online, as well as within his various books. He also works with professional actors, models, and recording artists to develop their portfolios and take their headshots. Jason also continues to pursue travel and animal photography.

Through his work as an enrichment lecturer, he often offers digital photography workshops and classes aboard cruise ships operated by Royal Caribbean, Princess Cruise Lines, Norwegian Cruise Lines, and Celebrity Cruise Lines, as well as through Adult Education programs in the New England area. Please follow Jason on Twitter (@JasonRich7) and Instagram (@JasonRich7).

## Dedication

*This book is dedicated to my family and friends, including my niece Natalie, my nephew Parker, and my Yorkshire Terrier Rusty, who is always by my side as I'm writing.*

## Acknowledgments

Thanks once again to Laura Norman and Greg Wiegand at Pearson Education for inviting me to work on this project, and for their ongoing support. I'd also like to thank the production team whose talents helped to make this book a reality.

Thanks also to you, the newest members of the global GoPro community. You are about to embark on a fun and exciting photography and videography adventure, as you learn how to fully use your GoPro camera.

## We Want to Hear from You!

As the reader of this book, *you* are our most important critic and commentator. We value your opinion and want to know what we're doing right, what we could do better, what areas you'd like to see us publish in, and any other words of wisdom you're willing to pass our way.

We welcome your comments. You can email or write to let us know what you did or didn't like about this book—as well as what we can do to make our books better.

*Please note that we cannot help you with technical problems related to the topic of this book.*

When you write, please be sure to include this book's title and author as well as your name and email address. We will carefully review your comments and share them with the author and editors who worked on the book.

Email: [feedback@quepublishing.com](mailto:feedback@quepublishing.com)

Mail: Que Publishing  
ATTN: Reader Feedback  
800 East 96th Street  
Indianapolis, IN 46240 USA

## Reader Services

Register your copy of *My GoPro HERO5 Camera* at [quepublishing.com](http://quepublishing.com) for convenient access to downloads, updates, and corrections as they become available. To start the registration process, go to [quepublishing.com/register](http://quepublishing.com/register) and log in or create an account\*. Enter the product ISBN, 978-0-7897-5830-9, and click Submit. Once the process is complete, you will find any available bonus content under Registered Products.

\*Be sure to check the box that you would like to hear from us in order to receive exclusive discounts on future editions of this product.





The GoPro allows you to shoot  
HD video virtually anywhere.

This chapter covers what you need to know about your GoPro camera's video shooting modes, resolutions, features, and functions. Topics to be covered include:

---

- Choosing the Video, Video+Photo, Looping, and Time Lapse Video shooting modes built into the HERO5 Black and HERO5 Session, and the Video and Looping shooting modes offered by the HERO Session
- Determining the best video resolution to shoot with based on your situation or needs
- Navigating through the video-related menus using the camera's controls

# 11

## Shooting HD Video

If you want to shoot HD video in traditional shooting situations, there are literally thousands of video cameras to choose from. In fact, your smartphone or tablet probably has a decent quality HD video camera built in.

However, if you want to capture stunning, clear, and extremely high-quality video in and around water, snow, or other harsh conditions; capture first-person shots by mounting the camera onto yourself or your equipment; or mount the camera in a tight space and at a specific angle to capture your subject perfectly, these are the situations where your GoPro camera is designed to truly excel.

Especially when shooting with the HERO5 Black or HERO5 Session, your camera is chock full of video-related features and functions, and it gives you plenty of options for shooting resolution, frames per second (FPS), and field of view (FOV) combinations.

When you use a mount that's best suited for your shooting situation, you quickly discover that what's possible using your GoPro camera is limited only by your imagination and not by the technology built into the camera or its design.

## Video-Related Shooting Modes

The GoPro HERO5 Black and HERO5 Session offer three main video-related shooting modes—Video, Video+Photo, and Looping. There's also a Time Lapse Video shooting mode. Each of these shooting modes offers a variety of adjustable settings, as well as several advanced shooting features, such as Protune, Video Stabilization, and Location Capture (GPS), that give you powerful tools as a videographer.

### >>> *Go Further*

#### GPS DOES MORE THAN RECORD LOCATION

When the GPS feature of your HERO5 Black is turned on, and you shoot video, the camera is able to capture and record precise information related to your location, speed, altitude, g-force, elevation gain, distance traveled, and directional movements. This metadata information gets stored with the video footage, and can be accessed by the QUIK Desktop software's Telemetry feature. It can then be displayed, in a customizable format, as part of your edited video.

To use this feature, make sure you turn on the GPS feature prior to shooting video. Access the Preferences menu, scroll down to the GPS feature, and make sure it's turned on.

How you incorporate and display the captured metadata into your videos is covered in Chapter 14, "Discovering the GoPro QUIK Desktop Software."

## The Skill and Art of Videography

As stated in other chapters of this book, digital photography and videography are both skills and art forms. This chapter focuses on helping you understand how to use each camera's shooting modes that relate to shooting video, as well as the options related to them. In other words, the focus is on the skill aspect of videography using your GoPro camera.

Because shooting video typically also requires you to record audio, and lighting is an essential element of good quality video, the focus of Chapter 12, "Capturing Sound and Using Artificial Light," is on these two important aspects of videography.

Chapter 13, “Strategies for Shooting Awesome HD Video,” then shows you how to put this knowledge to work, and incorporate your own creativity, as well as proven video-shooting strategies, to help you consistently shoot the highest-quality and most visually interesting videos possible using the GoPro camera and related equipment that’s at your disposal. In other words, the next chapter is all about the art of shooting video.

After you capture your raw video footage, you need to edit it using the free GoPro QUIK Desktop software for the PC or Mac (see Chapter 14), or you can use any third-party video-editing software on your computer or mobile device.

---

## Using the QUIK Mobile App for Editing

The QUIK mobile app is also a powerful video-editing tool for use while on the go. Content can be transferred directly to your mobile device, edited, and then shared online—without the use of a computer.

---

When you’re planning your video shots and ultimately shooting video, keep in mind that you’ll most likely be editing the raw footage before you show it off to other people, so your ultimate goal should be to quickly set the scene and tell some type of story and/or illicit some type of emotion from your viewers. Especially if you’ll be sharing your videos online, it’s a good idea to keep them short, meaning you need to edit together your best footage in a way that makes sense and is entertaining to the people watching.

---

## Understand Your Goals When Shooting Video

Your goals when shooting video need to be capturing your subject(s) in the best way possible and using the most appropriate camera features, functions, and settings so that you wind up with an overabundance of quality content when you begin editing the video.

---

# Comparison of GoPro Camera Models for Shooting Video

Each GoPro camera model offers a different selection of video features and functions and is capable of shooting at a variety of different resolutions.

Because the top-of-the-line HERO5 Black includes all of the video features and functions to be covered in this chapter, this is the camera model that I primarily discuss. Tables 11.1 through 11.3 describe the shooting resolutions, FOV, and FPS options available for the HERO5 Black, HERO5 Session, and HERO Session, respectively.

## The SuperView FOV Sets the GoPro Cameras Apart

The SuperView FOV allows you to capture a truly immersive, ultra-wide angle field of view. With this FOV, more content is captured around the edges of the frame, which allows you to showcase more detail when playing back video on a high-definition, widescreen television set or monitor.

SuperView is ideal for capturing first-person perspective shots, but you achieve better results when the camera is mounted to yourself or your equipment or you use a tripod or stabilizer because the camera becomes more sensitive to subtle shaking, vibration, or movement when you're working with SuperView.

## *It's Not All Good*

### Shooting Better Video Quality Requires More Battery Power

Shooting extremely high-quality video using the HERO5 Black and HERO5 Session requires more battery power, and the camera itself actually heats while you're shooting. If you're shooting in a hot climate at an extremely high-resolution, it's possible for the camera to overheat. When this occurs, you see a warning message on the status screen. The content you've recorded thus far is saved, and the camera automatically shuts down. Allow the camera to cool down before you resume filming.

**Table 11.1** HERO5 Black Options

Video Resolution	FPS	FOV	Screen Resolution	Aspect Ratio
480p	240	Wide	848 × 480	16:9
720p	30	Narrow, Medium, Wide	1280 × 720	16:9
720p	100	SuperView	1280 × 720	16:9
720p	60, 120	Narrow, Medium, Wide, SuperView	1280 × 720	16:9
720p	240	Narrow	1280 × 720	16:9

Video Resolution	FPS	FOV	Screen Resolution	Aspect Ratio
960p	60, 120	Wide	1280 × 960	4:3
1080p	24, 30, 48, 60	Narrow, Linear, Medium, Wide, SuperView	1920 × 1080	16:9
1080p	80	SuperView	1920 × 1080	16:9
1080p	90	Wide	1920 × 1080	16:9
1080p	120	Narrow, Wide	1920 × 1080	16:9
1440p	24, 30, 48, 60, 90	Wide	1920 × 1140	4:3
2.7K (4:3)	30	Wide	2704 × 2028	4:4
2.7K	30	Linear, Medium, Wide, SuperView	2704 × 1520	16:9
2.7K	24, 48, 60	Linear, Medium, Wide	2704 × 1520	16:9
4K	24	Wide, SuperView	3840 × 2160	16:9
4K	30	Wide	3840 × 2160	16:9

**Table 11.2 HERO5 Session Options**

Video Resolution	FPS	FOV	Screen Resolution	Aspect Ratio
720p	30, 60	Medium, Wide, SuperView	1280 × 720	16:9
720p	120	Wide	1280 × 720	16:9
960p	30, 60, 100	Wide	1280 × 720	4:3
1080p	24, 30	Narrow, Linear, Medium, Wide, SuperView	1920 × 1080	16:9
1080p	60	Linear, Wide, SuperView	1920 × 1080	16:9
1080p	90	Wide	1920 × 1080	16:9
1440p	24, 30, 48, 60	Wide	1920 × 1440	4:3
2.7K (4:3)	30	Wide	2704 × 1520	4:3
2.7K	24, 30	Linear, Medium, Wide, SuperView	2704 × 1520	16:9
2.7K	48	Medium	2704 × 1520	16:9
4K	30	Wide	3840 × 2160	16:9

**Table 11.3 HERO Session Options**

<b>Video Resolution</b>	<b>FPS</b>	<b>FOV</b>	<b>Screen Resolution</b>	<b>Aspect Ratio</b>
WVGA	120	Ultra Wide	848 × 480	16:9
720p	30, 60, 100	Medium, Ultra Wide	1280 × 720	16:9
720p SuperView	30, 60	Ultra Wide	1280 × 720	16:9
960p	30, 60	Ultra Wide	1280 × 960	4:3
1080p	30, 60	Medium, Ultra Wide	1920 × 1080	16:9
1080p SuperView	30, 48	Ultra Wide	1920 × 1080	16:9
1440p	30	Ultra Wide	1920 × 1440	4:3

## The GoPro HERO5 Black's Shooting Modes

The HERO5 Black offers four video-shooting modes—Video, Video + Photo, Looping, and Time Lapse Video—each of which is useful for specific types of shooting situations. You will find, however, that you'll use the Video shooting mode the majority of the time.

When adjusting video settings, three of the more important decisions you'll make, based on your shooting situation, as well as your own creativity and what you're trying to achieve, will be about the most appropriate shooting resolution, FPS rate, and FOV.

The Video shooting mode allows you to activate and adjust a series of advanced features, including Protune, Video Stabilization, Auto Low Light, and Manual Audio Control. The Protune feature offers a selection of user-adjustable settings, which are explained later in this chapter.

---

### Only Available in Video Shooting Mode

Protune does not work with the Video + Photo, Looping, or Time Lapse Video shooting modes.

---

---

## More About Resolution, FPS, and FOV

When it comes to selecting the appropriate resolution, FPS, and FOV, read Chapter 13 for information about how these settings affect your ability to edit and later showcase what you've shot.

---

---

## Don't Forget to Set Your Camera's Default Shooting Mode

After you've selected a video shooting mode and have adjusted its options, your selections remain active until you manually change them, or until you turn off the GoPro camera. The next time you turn on the camera, its Default shooting mode (and related settings) is automatically activated. You can adjust the Default shooting mode from the camera's Preferences menu.

---

## Video Shooting Mode

This shooting mode allows you to capture HD video, complete with audio. Whether you're holding the camera, have it mounted on yourself or your equipment, or you position it using a mount, extension pole, stabilizer, or tripod, when you press the Shutter button, the camera begins recording and continues until you press the Shutter button a second time.

When you press the Shutter button, the camera beeps once to let you know recording has started. As you're recording, the red status lights on the camera flash, indicating that recording is underway. When you press the Shutter button to stop recording, the camera beeps three times to indicate recording has stopped.

Following are the options you can adjust before you begin recording:

- **Resolution**—The available Resolution options vary based on the camera you're using. As you saw in Table 11.1, the most comprehensive selection of Resolution options is offered by the HERO5 Black camera.
- **Frames Per Second (FPS)**—The FPS options are dependent on your choice of resolution.
- **Field of View (FOV)**—FOV is also based on which resolution and FPS options you select. FOV determines how much you'll take advantage of the camera's fixed wide angle lens, and how much of what's in front of and to the sides of the camera's lens will be caught in the frame and recorded.

- **Auto Low Light**—When turned on, the camera automatically compensates for low light or changing light as you're shooting video. This is a useful feature to use when shooting in the evening or at night or when you're indoors and minimal lighting is available. It also works well when the camera is moving between well lit and poorly lit areas while shooting video.
- **Protune**—When turned on, this option allows you to manually adjust specific camera settings that are otherwise controlled automatically by the camera. Protune-related options for video include Color, White Balance, ISO Limit, Shutter, EV Comp, Sharpness, and Audio. When you turn on the Protune feature, the Protune submenu is displayed. From this menu, it's possible to adjust each setting.

---

## Use the QuikCapture Feature

When QuikCapture is active, you're able to turn on the camera and have it automatically begin shooting video when you press the Shutter button once. Set up your camera within an appropriate housing or mount and adjust the shooting angle. With the camera turned off, press the Shutter button. Your camera turns itself on, beeps multiple times, and automatically begins shooting. To quit shooting, press the Shutter button again. The camera saves the video and turns itself off.

Refer to the "Turn On/Off the QuikCapture Feature" sidebar in Chapter 9, "Shooting High-Resolution Photos," for information about how to turn on the QuikCapture feature.

---

## Turn On and Customize the Protune and Advanced Features for Video

After you've set the HERO5 Black to the Video shooting mode, follow these steps to access and adjust the Protune settings:

1. From the viewfinder screen, place your finger near the right edge of the touchscreen and swipe to the left.



2. Scroll through the advanced settings menu until you see the Protune option. If you want to adjust one of the other advanced settings, such as Video Stabilization, Auto Low Light, or Manual Audio Control, tap its menu screen to access that feature's submenu.
3. Tap the Protune On/Off icon to turn on the feature.
4. From the Protune submenu screen, tap each option you want to manually adjust.

## Different Options

The Protune submenu in Video mode is slightly different than the Protune submenu for the Photo shooting mode.


5. Each Protune option, including Color, White Balance, ISO Limit, Shutter, EV Comp, Sharpness, and Audio, has a separate submenu screen where you can select specific settings for the option. Shown here is the Sharpness option submenu screen.



6. Return to the viewfinder screen by placing your finger near the left edge of the touchscreen and swiping to the right. The viewfinder screen displays icons representing the Protune features you've activated or customized.
7. Press the Shutter button when you're ready to begin filming (not shown).

### HERO/HERO5 Session Users

To access the Protune and other advanced video features from the HERO and HERO5 Session cameras, you need to use the Smart Remote or wirelessly link your camera with your smartphone or tablet and use the Capture mobile app. You can't access or adjust the Protune options directly from the camera.



## Video+Photo Shooting Mode

This shooting mode allows you to shoot HD video and simultaneously take digital images at a predetermined resolution and time interval. After you select the Video+Photo shooting mode, you choose your video Resolution, FPS, FOV, and Interval settings. Protune is not available with this shooting mode.

The video content files are stored separately from the photo files on your camera's memory card, although both are created at the same time.

### Resolution Options

The Resolution options for the Video + Photo shooting mode are limited compared to the Video shooting mode. The FOV you set for the video is automatically used for taking photos.

## Looping Video Mode

This video option allows you to select a time interval, such as 5, 20, 60, or 120 minutes, and have the camera capture and record video during that time period. When the selected time period ends, if you press the Shutter button, the video recording is saved onto the microSD memory card and a new recording begins.

However, if you fail to press the Shutter button at the end of the time period, the recording will not be saved, and the camera begins recording again.

If you set the Max option on the Interval submenu for the Looping Video feature, the camera keeps recording HD video (using the settings you choose) until the microSD memory card reaches its capacity. At this point, you can either save the footage, or allow the camera to automatically erase the previously recorded footage and begin recording again until the camera's memory card is filled.

With the Looping shooting mode, you can adjust the resolution, FPS, FOV, and interval, but Protune is not available. Compared to the Video shooting mode, your resolution and related settings are more limited.

---

### The Camera Records Separate Video Files

As the Looping video files are recorded and saved to your camera's memory card, each loop you opt to save is stored as a separate file. This makes it easier to find and edit specific files later.

---

## Time Lapse Video

To access this shooting mode, you first need to choose the Time Lapse camera mode. Then, prior to shooting, you can adjust the resolution, interval, and FOV options. Protune is not available. The resolution and FOV options are more limited than what's available for the Video shooting mode.

---

### What's the Difference?

Time Lapse Video, Time Lapse Photo, and Night Lapse Photo differ in that the Time Lapse Video option creates a series of individual images at the time interval you choose, and they're saved as a single video file that you watch like a normal video clip. The other two Time Lapse modes save the photos as individual digital images, which you can then view and work with separately.

---

## Advanced Video Features

In addition to the Protune options related to video, you can choose from some other advanced video while shooting video on the HERO5 Black and HERO5 Session: Video Stabilization, Auto Low Light, and Manual Audio Control.

You should use Video Stabilization when you're mounting the camera to something that vibrates, like a boat, car, or airplane. This feature will reduce the negative effect the vibration has on the video you shoot.

Use Auto Low Light when you're shooting in low light situations or when you'll be moving the camera between low light and well-lit areas while shooting video. This feature works only when you're shooting using an FPS rate of 30 or higher.

Manual Audio Control allows you to choose which of the camera's audio filters will be used, based on the shooting situation. Typically, the camera records audio in stereo. In windy situations, however, you can turn on a special filter to help control the negative effect wind has on your video's audio. Manual Audio control enables you to manually turn on or off the stereo or wind filter.

The RAW Audio feature allows you to record video with sound, but save the video file and audio file separately on your camera's memory card. Then you can use audio-editing software on your computer to enhance or edit the audio before you merge it with the video file.

## The HiLight Tagging Function

One of the skills you'll need to fine tune as you become a videographer is keeping track of what raw footage you might want to use later as you edit. In many situations, you will shoot 5, 10, or even 20 times more video footage than you'll actually feature in your final video project.

As you're filming, one feature that can help you keep track of awesome scenes or shots is what GoPro refers to as the HiLight tagging feature. If you want to mark a specific moment or shot so you can quickly find it later when editing, simply press the Mode button on the side of the HERO5 Black while filming.

## That Was Sick!

Instead of manually pressing the Mode button to use the HiLight tag feature while shooting, you can turn on the Voice Command feature and simply say, "GoPro HiLight," or "That was sick!" This feature works with the HERO5 Black and HERO5 Session.

### Add HiLights When Previewing Video on the HERO5 Black's Screen

It's also possible to HiLight tag video as you're previewing it on the HERO5 Black's screen:

1. Place your finger near the left edge of the viewfinder screen and swipe to the right to access the Gallery screen (not shown).
2. Scroll through the Gallery to find the thumbnail that represents the video (or photo) you want to view, and then tap on that thumbnail.
3. Tap the Play icon to watch the video on the camera's touch-screen.
4. As the video is playing, tap the HiLight icon to add a tag at a particular moment. A time slider is displayed along the bottom of the screen, and your tag is recorded and saved.



5. When the video clip's playback is finished, the Play icon returns to the center of the screen. In the bottom-right corner you see how many HiLight tags have been selected and saved. Later, you'll be able to view these tags as you're playing back video using the QUIK app on your mobile device, or the QUIK Desktop software on your computer. The tags, however, will not become part of your final video production, which will be seen by audiences.



## Create HiLight Tags Using the Capture App or Smart Remote


Instead of pressing the Mode button on the side of the camera while filming, you can also create HiLight tags using the Smart Remote or Capture mobile app.

When using the Smart Remote to remotely control the camera, while the camera is filming, press the Settings/Tag button on the remote control unit to add a tag to the video file as it's being recorded.



Tag button on the Smart Remote

To add a HiLight tag using the Capture mobile app (shown here on an iPad), after you press the Shutter button to begin recording video, press the yellow HiLight Tag button.



## Working with Protune

The Protune (PT) feature is designed for more advanced GoPro users. It allows you to have greater manual control over specific camera settings related to shooting video.

Using Protune, you can capture higher quality results because the camera uses less data compression on your raw video footage, plus it does a better job of capturing natural colors within your shots. The raw digital video footage is then more compatible with higher-end and professional-level video-editing software, which means you can take full advantage of the more advanced editing tools built into that software.

When you turn on Protune, several advanced feature options become available, and you can adjust each. Keep in mind that you can set the Protune-related settings differently for each video and photo shooting mode.

The adjustable Protune options for the Video shooting mode include

- White Balance
- Color
- ISO Limit
- Shutter
- Sharpness
- EV Comp (Exposure Value Compensation)
- Audio

When Protune is turned off, the camera automatically adjusts each of these settings on your behalf, which requires that you make fewer decisions and do less tinkering with camera settings before shooting.

**Protune for Video menu**



## Adjusting White Balance

The White Balance settings allow the camera to adjust all of the colors and tones in each video frame based on what the camera perceives to be the color white in each frame. When this option is set to Auto (the default), the camera automatically analyzes each video frame as it's being shot and adjusts the color tone based on the conditions it senses.

You can use the White Balance submenu to manually set this feature to Auto, 3000K, 4000K, 4800K, 5500K, 6000K, 6500K, or Native. Here are some things to take into consideration when you're adjusting the White Balance setting:

- If you're shooting video in an area with natural warm light, such as incandescent lighting (indoors) or during a sunrise or sunset, consider selecting the 3000K White Balance option to capture more authentic colors.
- If you're shooting in areas lit by fluorescent lighting or in average daylight, select the 5500K White Balance option.
- When you're shooting in cool lighting (such as when outside in overcast conditions), use the 6500K White Balance option.
- If you plan to use higher-end video-editing software that offers White Balance controls when you later edit or enhance your raw footage, select the camera's Native White Balance option when actually shooting video.

## Adjusting Color

This option allows you to manually select the color profile used by the camera when shooting video. The default GoPro Color option uses the same color profile as when the Protune feature is turned off. When you select the Flat option, this allows you to more easily edit the color in your video later to showcase truly natural or authentic-looking colors within an image.

## Adjusting ISO Limit

This setting is used to manage the camera's sensitivity to light, especially when shooting in low-light situations. Based on which option you select, you can manage the brightness of your video footage, and somewhat control the unwanted graininess (or noise) captured within the footage by the camera due to poor lighting. ISO Limit options include 400, 800, 1200, 1600, 3200, or 6400.

To achieve brighter footage when shooting in low light, select the default 800 ISO Limit option. Bear in mind that at this setting, the video includes more noise (graininess), which takes away from the detail, image sharpness, and the vibrancy of colors that are depicted.

The 400 ISO Limit option results in slightly darker footage (when shooting in low light), but the video contains less noise than with the 800 ISO Limit option selected. As a result, your video showcases a bit more detail and sharpness.

If you're shooting indoors with decent (but not bright) lighting, choose the 200 ISO Limit option. When shooting outdoors in daylight, the ISO 100 Limit option generates the least amount of noise, resulting in sharper, brighter, and more vibrant colors.

## Adjusting Shutter Speed

You can determine how much of the ambient light the camera uses when shooting video by adjusting the amount of time the shutter remains open. The options available for this setting are determined by your FPS setting. Options include Auto (which allows the camera to adjust this setting automatically), as well as 1/30, 1/60, 1/120, and 1/240.

If you opt to tinker with this feature, it works best when your camera is mounted to a tripod and not moving while you shoot. Using the HERO5 Black, when you make an adjustment to the Shutter setting, you immediately see the effect of the change on the viewfinder screen.

## Adjusting Sharpness

When it comes to manually adjusting Sharpness while shooting video, Protune's Sharpness option offers three options: High (which is the default setting), Medium, and Low. Choose the High setting to achieve ultra-sharp image quality in your videos. Choose the Medium setting to capture what GoPro calls "moderately sharp" video footage, or use the Low option to capture softer video footage that showcases a bit less detail.

## Adjusting EV Comp

EV Comp, which stands for *Exposure Value Compensation*, also affects the brightness of video as it's being shot. If you're shooting in areas with contrasting lighting conditions, adjusting this setting can help you capture better quality video overall. The available EV Comp options range from -2.0 to 2.0, with the default option being 0.0.

## Adjusting Audio

When the Audio setting is turned on, your camera creates separate video and audio files when video is shot. You're then able to choose the level of processing the camera uses when recording the audio track. This level of processing relates to how much the camera attempts to remove unwanted noise (caused

by things such as wind) from your audio recordings. Options include Off, Low, Medium, or High. Use this feature if you plan to use audio-editing software on your computer to enhance or edit the audio track separately from the video, before merging the audio and video together into a final video presentation.

---


## Reset the Protune Options

When you select the Reset option related to a specific Protune menu, you return all the related options to their default settings. The changes back to their default settings apply only to the Protune options for that specific shooting mode.

---


## Additional Options with the Capture Mobile App

When using the Capture mobile app to remotely control the camera (in this case, the HERO5 Session), tap the Settings icon (which looks like a wrench) to reveal a comprehensive Settings menu for the camera. This menu includes the options that are available directly through the camera as well as some additional advanced settings, such as Spot Meter.



Settings icon

The Spot Meter feature on the HERO/HERO5 Session should be turned on when the lighting where the camera is positioned is different from where the camera is shooting—for example, if you're using the camera from the audience area of a dark theater and you're shooting video (or photos) of what's happening on a well lit stage.



Using the Settings menu of the Capture mobile app (shown in the figure on an iPad), you can use virtual switches to turn on or off some settings, such as Spot Meter. Tap the virtual switch to toggle between the on and off positions.

The options that allow you to choose from multiple options, such as Resolution, FPS, and FOV, display the currently selected option. Tap the > icon to reveal a submenu with additional options for that feature.

## Switching Between Shooting Modes

You can choose from four ways to switch between video-shooting modes and then adjust specific settings, including

- Directly from the camera
- With Voice commands (not available on the HERO Session)
- With the optional Smart Remote
- With the Capture app on your smartphone or tablet

## Control the Camera Using the Smart Remote

You pair the camera with the Smart Remote one time and then the remote mirrors the information displayed on the camera's status screen. You can adjust the camera mode, shooting mode, and related settings from up to 600 feet away. The Smart Remote works with all three camera models.

To adjust the camera shooting mode, follow these steps:


1. After the initial pairing, press the Power/Mode button on the Smart Remote to turn on the remote (and the camera).
2. Press the Power/Mode button repeatedly to scroll through the camera modes. When you see the setting you want, stop pressing the Power/Mode button. Here, the Video shooting mode has been selected.



3. To adjust the Resolution, FOV, and FPS options, press the Settings/Tag button once. The Resolution option is highlighted and displayed.
4. Scroll through the Resolution options for the camera mode you've selected by pressing the Shutter button. When the Resolution you desire is highlighted, press the Power/Mode button to select it. In this example, 1080p is selected.
5. The FPS option is highlighted next. Keep pressing the Shutter button until you see the desired resolution, and then press the Power/Mode button to select it. 60 FPS is selected in this example.
6. The FOV option is highlighted next. Again, keep pressing the Shutter button until you get to the desired resolution, and press the Power/Mode button to select it (not shown).
7. Repeat this process for the rest of the adjustable options, including the advanced shooting options (not shown).
8. When you've adjusted all the settings using the Smart Remote, highlight and select the Exit option. You're now ready to begin shooting. Press the Shutter button to begin.



Shutter button



---

## Adjusting Video Settings Using the Capture App

You can use the Capture mobile app to remotely adjust the camera mode, shooting mode, and related options, as well as to control the camera while shooting.

Chapter 15, “Using Mobile Devices with Your GoPro Camera,” covers how to pair the camera to the device and use the Capture mobile app.

---

## Stabilizing the Camera

Chances are that you purchased your GoPro camera to shoot video of yourself and others engaged in some type of action-oriented activity. As discussed in the next chapter, the key to shooting smooth and in-focus video is to keep the camera as steady as possible, avoiding unnecessary shaking or sudden movements.

The easiest way to do this is to place the camera in the Frame housing and then attach the most appropriate mount, based on the shooting situation. Make sure the mount is securely attached to your body or equipment so it can't move around. To achieve really smooth video, consider attaching the camera to an optional stabilizer. This helps you achieve more professional results.

### >>>Go Further

#### STABILIZER OPTIONS

Chapter 4 covers the GoPro Karma Grip stabilizer (\$299.99, <https://shop.gopro.com/stabilization>) and Sybrillo stabilizer (\$299.99, [www.sybrillo.com](http://www.sybrillo.com)). In addition, a company called Aetho (<http://aetho.co/aeon/>) has developed a different handheld stabilizer for the GoPro cameras, and a company called Slick Technologies offers a stabilizer (\$249.00, [www.slick.video](http://www.slick.video)) that can be attached between the camera housing and existing GoPro mounts.

A less expensive, one-axis stabilizer, called the WenPod X1 (\$129.99, [www.wenpod.com/en/x1/index.html](http://www.wenpod.com/en/x1/index.html)), is designed for mounting the camera on a motorcycle or bike, for example, and to capture smoother video while the vehicle is in motion.

To find similar stabilizer accessories that can dramatically improve the quality of your video, especially when shooting action, visit any search engine (such as Google, Yahoo!, or Bing), and enter the search phrase, *GoPro stabilizer*.

# Index

## Symbols

---

2.7K 4:3 resolution, 270  
2.7K resolution, 270  
2.7K Superview resolution, 270  
3-Way Mount, 19, 93  
4K resolution, 270  
    HD televisions, 9  
    video resolution, memory cards  
    for, 126  
4K Superview resolution, 271  
10app video editing app, 393  
360-degree content, 58  
480p resolution, 269  
720p resolution, 269  
720p Superview resolution, 269  
960p resolution, 269  
1080p resolution, 270  
1080p Superview resolution, 270  
1440p resolution, 270

## A

---

accessing  
    camera through housing, 33  
    content  
        *with QUIK Desktop software,*  
            364-365  
        *with QUIK mobile app, 361-363*  
        *from social media accounts,*  
            363-364  
        *with web browser, 365-369*  
    ports, 39  
accessories. *See also* housings; mounts  
    3-Way, 19, 93  
    Action Battery Grip, 146  
    Anti-Fog Inserts, 376  
    Auto Charger, 139  
    Capture P.O.V. clip, 122  
    continuous lighting, 259-261  
    Dual Battery Charger, 140  
    external lighting, 258  
    filters for underwater photos, 211  
    Floaty, 19, 122-123  
    GoPro 3.5mm Mic Adapter, 248,  
        251  
    GoPro Omni, 58  
    GoSpot, 122

- iStyle, 122
- Karma Grip, 19
- Karma Grip Extension Cable, 102
- Karma Mounting Ring, 102
- lights, 122
- Micro HDMI cable, 41, 74, 194
- microphones, 253
- Octomask dive masks, 19
- Portable Power Pack, 140, 146
- Pro 3.5mm Mic Adapter, 74
- QUIK Key, 13, 119-120, 194, 340
- REMO, 51, 79, 118-119, 152
- Seeker, 121
- shot stability, 91-92
- Smart Remote. *See* Smart Remote
- stabilizers, 264, 277
- Supercharger, 63, 139
- tether, 71
- The Handler, 19
- thumb screws, 87
- underwater lenses, 123
  - from Wasabi Power, 142
  - where to buy, 24, 106-107
- windscreens, 250
- accidental deletions, 384-385
- accounts (GoPro Plus), creating, 355-357
- Action Battery Grip, 146
- Adhesive Mounts, 94
- adhesives for mounts, 91
- Adobe Audition CC, 248
- advanced settings
  - icons, 163
  - in Protune, 187
    - Audio*, 240
    - Color*, 188, 239
    - EV Comp*, 191, 240
    - ISO Limit*, 239-240
    - ISO Minimum/Maximum*, 188-189
    - Sharpness*, 190, 240
    - Shutter Speed*, 240
    - White Balance*, 187, 238-239
- advanced shooting features, 169-170
  - aspect ratio, 170
  - auto low light, 170
  - color, 171
  - EV comp, 172
  - exposure control with auto exposure, 171
  - exposure control with locked exposure, 172
  - GPS, 172
  - ISO, 172
  - manual audio control, 173
  - Protune, 173-174
  - RAW audio, 174
  - RAW format, 175
  - sharpness, 175
  - video stabilization, 175
  - WDR (wide dynamic range), 176
  - white balance, 176
- Amazon.com, lighting accessories, 261
- analyzing shooting situation, 149-150
- Android devices
  - mobile app versions, 316
  - installing mobile apps, 319-320
- angle, adjusting, 86
- animal photos, 208
- Anti-Fog Inserts, 376
- Antix video-editing app, 393
- Apple Watch
  - Capture mobile app compatibility, 339
  - mobile apps on, 316
- App Settings icon (Capture mobile app), 329
- aspect ratio, 170
- attaching mounts, 90-91
- Audacity, 248
- audience
  - focus on, 310
  - maintaining attention, 311-312
- audio
  - editing, 248, 308-309
  - Manual Audio Control feature, 234
  - manual settings, 173
  - poor quality, 385-387
  - RAW Audio feature, 174, 234
  - recording, 248
    - adding sound effects and music*, 254-255
    - audio-editing software*, 248
    - with built-in microphone*, 249-250

*with external microphone, 251-253*  
*settings for, 249*  
*unwanted noise, 250*

Audio setting, 240

Auto Charger, 139

Auto Low Light feature, 170, 234, 256  
 when to use, 277

Auto Off settings, 48

Auto Rotation feature, 48, 276

Auto Upload feature, 357-360

## B

backing up video-editing work, 289

back of camera

HERO5 Black, 35

HERO5 Session, 69

HERO Session, 69

backpacks, 121

Ball Joint Buckle, 94

baseball cap mounts, 90

batteries

accessing through housing, 33

carrying extra, 29

charging, 139-141

charging time, 63

compatible HERO5 Black batteries,  
 142-143

conserving in Screensaver mode, 46  
 dead, 372

draining quickly, 45

estimating life of, 141-142

HERO5 Session camera, 13

HERO Session camera, 13

increasing life of, 146-147

inserting in HERO5 Black, 143-144

low battery warning, 146

Protune and, 183

removing from HERO5 Black, 144

troubleshooting, 140

viewing status, 47

when to replace, 372

battery door (HERO5 Black), opening/  
 closing, 42

Beep Volume settings, 47

Blue Water Snorkel Filter, 123

Bobber mount, 96

Bodyboard Mount, 95

bottom of camera

HERO5 Black, 42

HERO5 Session, 71

HERO Session, 71

Brightness settings, 48

buildings, as subject, 209-210

built-in microphone, recording audio,  
 249-250

Burst shooting mode, 167, 211, 197

buying

accessories, 24, 106-107

memory cards, 130-131

mounts, 106-107

replacement side door

*HERO5 Black, 39*

*HERO5 Session, 76*

*HERO Session, 76*

## C

Caddie Buddy mounts, 102

camera angle, adjusting, 86

Camera icon (Capture mobile app), 329

Camera Info (Settings menu), 337

camera mode, changing, 155

with HERO5 Black touchscreen, 156-159

with HERO5 Session status screen,  
 159-162

with HERO Session status screen, 159

camera models. *See also* names of specific  
 camera models

comparison, 9-11

connecting to HD TV, 41, 74

overheating, 50

pairing with Capture mobile app,  
 320-326

Photo mode comparison, 181-182

remote control

*with Capture mobile app, 153-154*

*with Smart Remote, 152-153*

*with voice commands, 152*

resetting, 35, 49

- serial number, finding, 58
- tracking information, 391
- troubleshooting
  - choppy video playback*, 378
  - computer doesn't recognize camera*, 379
  - dead battery*, 372
  - fogged lens*, 376
  - lack of connection with Capture app or Smart Remote*, 375
  - memory card error messages*, 376-377
  - menus differ from book*, 379
  - physical damage to camera*, 379-380
  - Temperature icon*, 378
  - unresponsive camera*, 373-375
  - unresponsive touchscreen*, 375
  - water spots on lens*, 378
- upgrades, 14
- video features comparison, 225-228
- where to buy, 24
- camera modes, 163
  - adjusting settings with Capture mobile app, 335-338
  - icons, 163
  - Photo, shooting modes for, 166-167
  - Time Lapse, shooting modes for, 167-169
  - tooggling with Capture mobile app, 334-335
  - Video, shooting modes for, 164-166
- Camera screen (Capture mobile app), 328-329
- Camera Settings options, importing content, 292-293
- Camera Software
  - compatibility with batteries, 142
  - updating, 53, 80, 298
    - with Capture mobile app*, 53-56
    - manually*, 58
    - with QUIK Desktop software*, 56-57
- Camera Status (Settings menu), 338
- candid photos, 206
- captions in video, 312
- Capture mobile app, 4, 20-21, 65, 118, 153-154
  - adding HiLights, 236-237
  - Apple Watch compatibility, 339
  - Camera screen, 328-329
    - capabilities of, 316
    - compatibility with mobile devices, 317
    - deleting memory card content, 332
    - lack of connection, troubleshooting, 375
    - main screen, 326
    - Media screen, 329-332
    - pairing with camera, 320-326
    - remotely controlling camera, 333-334
    - Smart Remote versus, 327-328
    - transferring content from memory card, 330-332
    - updating Camera Software with, 53-56
    - uploading content to GoPro Plus, 360
    - video settings, 241-242
    - Viewfinder screen, 333-338
- Capture P.O.V. clip, 122
- capturing still images from video, 295-297
- chargers, carrying extra, 29
- charging
  - batteries, 139-141
    - time required*, 63
    - when to replace*, 372
  - REMO accessory battery, 119
  - Smart Remote, 111
- checklists, equipment needed, 23
- Chesty mount, 90, 95
- choosing
  - continuous lighting accessories, 259-261
  - FOV options for shooting video, 272-273
  - FPS rate for shooting video, 271
  - mounts, 87-89, 215-216
  - resolution for shooting video, 268-271
  - subject (of photo), 201-203
- choppy video playback, troubleshooting, 378
- CineForm file format, 305
- cleaning lens, 34, 69, 122, 378
- clips (video), trimming, 294, 305
- Clip tool (QUIK Desktop software), 294
- closing
  - battery door (HERO5 Black), 42
  - side door
    - HERO5 Black*, 37-39
    - HERO5 Session*, 75
    - HERO Session*, 75

cloud services. *See* GoPro Plus

color adjustments in GoPro Studio, 307-308

Color setting, 171, 188, 239

colored filters for underwater photos, 211

colors, troubleshooting, 383

compatibility

- Capture mobile app and Apple Watch, 339
- of mobile apps, 316

compatible HERO5 Black batteries, 142-143

computer doesn't recognize camera, troubleshooting, 379

connecting

- to external power source, 145-146
- to HD TV, 41, 74

Connections (Settings menu), 338

conserving batteries in Screensaver mode, 46

content. *See* digital content

content type in thumbnail icons, 291

continuous lighting accessories, 259-261

converting time lapse video/photos, 295

copying video links, 345

copyright issues, 254, 343

cost

- GoPro Plus, 354, 357
- music, 254

Create Mode

- creating mini-videos, 298-300
- GoPro Studio software versus, 292

creative inspiration, 388

customizing HERO5 Black settings, 47-49

## D

damage to camera, troubleshooting, 379-380

Date and Time settings, 47

dead batteries, 372

Default mode, 48, 192-194, 229

default settings, resetting

- camera to, 49, 373-375
- Protune to, 186, 241

Delete (Settings menu), 337

deleting

- content
  - accidentally*, 384-385
  - from memory card*, 293, 332
- files from memory cards, 129
- music from videos, 343

digital content. *See also* photos; video

- online storage, 5
- resolution, 7-9
- transferring with Quik Key, 119-120
- viewing
  - HERO5 Session*, 79-80
  - HERO Session*, 79-80

digital technology, changes in, 17

dive masks, 19

downloading

- GoPro QUIK Desktop software, 56, 286-288
- GoPro Studio software, 287
- user manuals, 284

Dual Battery Charger, 140

dull colors, troubleshooting, 383

## E

editing

- audio, 248, 308-309
- outro, 348
- photos, 221
  - apps for*, 394
  - converting time lapse photos/video*, 295
  - software for*, 392
- video. *See also* QUIK Desktop software; GoPro Studio software
  - adding GPS details to scenes*, 300-301
  - adding HiLight tags*, 297-298
  - apps for*, 394
  - capturing still images*, 295-297
  - converting time lapse photos/video*, 295

*creating mini-videos in Create Mode,*  
298-300

*creating storyboards, 285-286*

*importing content, 289-293*

*including still photos in, 305*

*learning curve for, 313*

*organizing work, 311*

*overuse of special effects, 307*

*planning while shooting, 310*

*with QUIK mobile app, 340, 343-346*

*raw footage needed, 278*

*removing fish-eye effect, 282*

*role of video editor, 283-284*

*saving work, 289*

*as skill and art form, 282*

*software for, 392*

*with Splice mobile app, 346-351*

*steps in, 284-285*

*switching perspectives, 275*

*tips for, 309-313*

*titles and captions, 312*

*trimming clips, 294, 305*

Edit mode (GoPro Studio), 306

Edit Templates (GoPro Studio), 304

Effects Presets menu (GoPro Studio), 306

enhancing flawed video footage, 307-308

equipment checklist, 23

error messages, memory cards, 136-137,  
376-377

estimating battery life, 141-142

EV Comp setting, 172, 191, 240

exporting video projects, 309

Exposure Control option, 256-257

Exposure Control with Auto Exposure  
feature, 171

Exposure Control with Locked Exposure  
feature, 172

extending warranty, 379

external lighting accessories, 258

external microphones, 74, 251-253

external power sources, connecting to,  
145-146

## F

Facebook pages for GoPro information,  
395

fast-moving subjects, 209

Fetch Dog Harness, 95

field of view (FOV). *See* FOV (field of view)

files, deleting from memory cards, 129

filtering out wind noise, 386-387

filters for underwater photos, 211

finding serial number, 58

first-person perspective, 12

third-person perspective versus,  
203-205

fish-eye effect

avoiding, 31

correcting, 210

removing, 282

troubleshooting, 382-383

Floaty accessory, 19, 122-123

fogged lens, troubleshooting, 376

formatting memory cards

in HERO5 Black, 134-136

in HERO5 Session, 134

in HERO Session, 134

FOV (field of view), 8, 30

choosing for shooting video, 272-273

comparison of options, 179-180

defined, 151

fish-eye effect, avoiding, 31

Linear, 31

Medium, 32

Narrow, 31

for Photo camera mode, 166

SuperView, 32, 226

in Video camera mode, 165

Wide, 32

FPS (frames per second), 8

choosing for shooting video, 271

defined, 151

in Video camera mode, 165

Frame housing, 11, 18

accessing camera through, 33

inserting camera into, 73

Quick Release Buckle, 84-86  
removing camera from, 72

framing shots

creativity in, 202-203  
Rule of Thirds, 217-218  
shooting angle, 219  
surroundings of photo, 220

Framing tools (GoPro Studio), 308

front of camera

HERO5 Black, 33-35  
HERO5 Session, 67-69  
HERO Session, 67-69

Full error message, 376

## G

GoFix app, 393

Google Play Services, updating, 320

Gooseneck mount, 95

GoPole mounts, 103

GoPro

on social media, 390  
support, 390-391

GoPro 3.5mm Mic Adapter, 248, 251

GoPro Capture mobile app. *See* Capture mobile app

GoPro HERO5 Black. *See* HERO5 Black

GoPro HERO5 Session. *See* HERO5 Session

GoPro housings, benefits of, 85. *See also* housings

GoPro mounts. *See also* mounts

3-Way Mount, 93  
Adhesive Mounts, 94  
Ball Joint Buckle, 94  
Bodyboard Mount, 95  
Chesty, 95  
Fetch Dog Harness, 95  
Gooseneck, 95  
Gun/Rod/Bow Mount, 96  
Handlebar/Seatpost/Pole Mount, 96  
Handler, 96  
Head Strap + QuickClip Mount, 96  
Helmet Front Mount, 97  
Helmet Side Mount, 97

Jaws: Flex Clamp, 97

Karma Grip, 102

Large Tube Mount, 98

Low Profile Helmet Swivel Mount, 98

Mic Stand Mount, 98

NVG Mount, 99

Pro Handlebar/Seatpost/Pole Mount, 99

Pro Seat Rail Mount, 99

Removable Instrument Mounts, 99

Suction Cup, 99

Surfboard Mounts, 100

The Jam: Adjustable Music Mount, 100

The Strap, 100

Tripod Mounts, 100

Vented Helmet Strap Mount, 101

GoPro Omni accessory, 58

GoPro Plus, 5, 62, 288, 353

accessing content

*with QUIK Desktop software, 364-365*

*with QUIK mobile app, 361-363*

*from social media accounts, 363-364*

*with web browser, 365-369*

capabilities of, 354-355

creating account, 355-357

Private Links, 354, 368-369

savings via, 106

subscription fee, 354, 357

syncing content, 364

uploading content

*Auto Upload feature, 357-360*

*from HERO/HERO5 Session, 360*

GoPro Plus icon (Capture mobile app), 329

GoPro QUIK Desktop software. *See* QUIK Desktop software

GoPro Studio software, 23, 281

Create Mode versus, 292

downloading, 287

downloading user manual, 284

editing in, 305-306

*Edit mode, 306*

*enhancing flawed footage, 307-308*

*Framing tools, 308*

*sound editing, 308-309*

Edit Templates, 304

GPS metadata in, 301

including still photos in videos, 305

- interface, 302-303
- system requirements, 283
- transferring video content to, 304-305

GoPro Tripod Mount, 88

GoPro website, 88, 106

GoSpot accessory, 122

GoWorx mounts, 103

GPS details

- adding to video scenes, 300-301
- in GoPro Studio, 301

GPS feature, 48, 172, 224

Green Water Dive Filter, 123

grips, importance of, 275

Gun/Rod/Bow Mount, 96

## H

Handlebar/Seatpost/Pole Mount, 96

Handler mount, 19, 96

handles, importance of, 275

HD TV, connecting GoPro camera to, 41, 74

HD video (high-definition video), 7-9. *See also* video

Head Strap mount, 90

Head Strap + QuickClip Mount, 96

Helmet Front Mount, 90, 97

Helmet Side Mount, 90, 97

HERO5 Black

- audio settings, 249

- Auto Upload feature, 357-360

- body of, 32

- accessing through housing, 33*

- back of camera, 35*

- bottom of camera, 42*

- front of camera, 33-35*

- left side of camera, 37-40*

- right side of camera, 36*

- status screen, 42-43*

- top of camera, 41*

- touchscreen, 43-46, 156-159, 195*

- box contents, 29

Camera Software, updating, 53

- with Capture mobile app, 53-56*
- manually, 58*

- with QUIK Desktop software, 56-57*

comparison with other models, 9-11

compatible batteries, 142-143

control options, 30

customizing settings, 47-49

Default mode, 192-194

EV Comp settings, 191

Exposure Control option, 256-257

extra batteries, 29, 140

fogged lens, troubleshooting, 376

formatting memory card, 134-136

FOV (field of view) options, 8, 30

- Linear, 31*

- Medium, 32*

- Narrow, 31*

- SuperView, 32*

- Wide, 32*

improvements to, 27-29

included housing, 11, 18

initial setup, 46-49

inserting batteries, 143-144

inserting memory card, 131-132

pairing with Capture mobile app, 322-326

pairing with Smart Remote, 112-114

Protune, accessing menu, 183-186

remote control, 50

removing batteries, 144

removing memory card, 132

resolution, 7, 15

shooting modes, 45, 191

specs, 15-17

Super Suit housing, 84

turning on/off, 33

video features comparison, 226

video shooting modes, 224, 228

- Looping, 233*

- Time Lapse Video, 233*

- Video, 229-232*

- Video+Photo, 232*

voice commands, 51-52

WDR (Wide Dynamic Range), 212-213

White Balance options, 187

## HERO5 Session

- battery not holding charge, 140
- benefits of, 62-63
- body of, 67
  - back of camera, 69*
  - bottom of camera, 71*
  - front of camera, 67-69*
  - left side of camera, 74-76*
  - right side of camera, 74*
  - top of camera, 70-71*
- box contents, 64
- Camera Software, updating, 80
- comparison with other models, 9-11
- control options, 65
- formatting memory card, 134
- included housing, 11, 18
- initial setup, 77-78
- inserting into Frame housing, 73
- inserting memory card, 133-134
- limitations of, 63
- pairing with Capture mobile app, 321
- pairing with Smart Remote, 114-116
- Protune
  - accessing menu, 183*
  - accessing video options, 232*
- removing from Frame housing, 72
- resolution, 7, 15
- shooting modes, 67, 191
- specs, 14-15
- status screen, changing camera settings, 159-162
- turning on/off, 66
- uploading content to GoPro Plus, 360
- video features comparison, 227
- video-shooting modes, 224
- viewing content, 79-80
- voice commands, 78-79
- waterproofing, 77

## HERO Session

- battery not holding charge, 140
- benefits of, 62-63
- body of, 67
  - back of camera, 69*
  - bottom of camera, 71*
  - front of camera, 67-69*
  - left side of camera, 74-76*

*right side of camera, 74*

*top of camera, 70-71*

- box contents, 64
- Camera Software, updating, 80
- comparison with other models, 9-11
- control options, 65
- formatting memory card, 134
- included housing, 11, 18
- initial setup, 77-78
- inserting into Frame housing, 73
- limitations of, 61-63
- pairing with Capture mobile app, 321
- pairing with Smart Remote, 114
- Protune
  - accessing menu, 183*
  - accessing video options, 232*
- removing from Frame housing, 72
- resolution, 7, 13
- shooting modes, 67, 191
- specs, 12-14
- Spot Meter feature, 182
- status screen, changing camera settings, 159
- turning on/off, 66
- uploading content to GoPro Plus, 355, 360
- video features comparison, 228
- viewing content, 79-80
- waterproofing, 77

high-definition video (HD video), 7-9. *See also* video

high-resolution photos. *See* photos

HiLight tagging feature, 234, 278
 

- adding tags to video, 297-298
- with Capture app/Smart Remote, 236-237
- when previewing video, 235-236

Home icon (Capture mobile app), 329

## housings

- accessing camera through, 33
- Frame. *See* Frame housing
- GoPro, benefits of, 85
- inserting camera into, 73
- Karma Harness, 101
- removing camera from, 72

## Super Suit

*recording audio, 250**troubleshooting fogged lens, 376*

waterproof, 11, 18, 84

## I

icons, 162-163

importing video content into GoPro QUIK  
Desktop software, 289-293

increasing battery life, 146-147

information. *See* resources for information

initial setup

HERO5 Black, 46-49

HERO5 Session, 77-78

HERO Session, 77-78

inserting

batteries in HERO5 Black, 143-144

camera into Frame housing, 73

memory cards

*in HERO5 Black, 131-132**in HERO5 Session, 133-134*

The Inside Line blog, 390

Insignia mounts, 103

installing

GoPro QUIK Desktop software, 286-288

mobile apps

*on Android devices, 319-320**on iOS devices, 318-319*

insurance for cameras, 380

Internet connections when pairing camera  
and mobile app, 325

interval for time lapse videos, 168

iOS devices

installing mobile apps, 318-319

mobile app versions, 316

ISO Limit setting, 239-240

ISO Minimum/Maximum settings, 188-189

ISO settings, 172

iStyle accessories, 122

## J-K

The Jam: Adjustable Music Mount, 100

Jaws: Flex Clamp mount, 97

Joby mounts, 104

Karma drone, 101

Karma Grip, 19, 102

Karma Grip Extension Cable, 102

Karma Harness housing, 101

Karma Mounting Ring, 102

## L

Language settings, 49

Large Tube Mount, 98

LCD status screen. *See* status screen

LED settings, 47

left side of camera

HERO5 Black, 37-40

*opening/closing side door, 37-39**removing/reattaching side door, 40*

HERO5 Session, 74-76

*opening/closing side door, 75**removing/reattaching side door, 76*

HERO Session, 74-76

*opening/closing side door, 75**removing/reattaching side door, 76*

lens

cleaning, 34, 69, 122, 378

fogged up, 376

HERO5 Black, 34

HERO5 Session, 67-69

HERO Session, 67-69

underwater lenses, 123

water spots, troubleshooting, 378

Lens Corrector app, 394

lighting, 122

continuous lighting accessories,  
259-261

Exposure Control option, 256-257

external lighting accessories, 258

low light, compensating for, 382

poor lighting conditions, 213-214, 220,  
256

primary light source, 216-217, 381  
for video, 276-277

lights. *See* status lights

Linear FOV, 31

links to videos, copying, 345

Locate Camera option, 338

Locked Exposure option, 257

Logic Pro X, 248

Looping shooting mode, 165, 233

low battery warning, 146

low light, compensating for, 382. *See also*  
poor lighting conditions

Low Profile Helmet Swivel Mount, 98

Lume Cube Video Light, 260

## M

Manual Audio Control feature, 173, 234,  
249

manually updating Camera Software,  
58, 80

Media Gallery icon (Capture mobile app),  
329

Media screen (Capture mobile app),  
329-332

Medium FOV, 32

megapixels (MP), 7

memory cards, 12, 29, 64, 75

accidental deletions, 384-385

deleting

*content*, 293, 332

*files*, 129

error messages, 136-137, 376-377

formatting

*in HERO5 Black*, 134-136

*in HERO5 Session*, 134

*in HERO Session*, 134

inserting

*in HERO5 Black*, 131-132

*in HERO5 Session*, 133-134

lack of storage availability, 384-385

necessity of, 125

protecting, 136

removing from HERO5 Black, 132

speed of, 126-128

storage capacity of, 128-129

as temporary storage, 126

transferring content to mobile device,  
330-332

where to buy, 130-131

Memory Card icon (Capture mobile app),  
329

Menu button, 66, 69

menus differ from book, troubleshooting,  
379

metadata, 195, 300-301

Micro HDMI cable, 41, 74, 194

microphones, 248

built-in, recording audio, 249-250

external, 74

*recording audio*, 251-253

microSD memory cards. *See* memory cards

Mic Stand Mount, 98

mini-videos, creating in Create Mode,  
298-300

mobile apps. *See also* Capture mobile app;  
QUIK mobile app; Splice mobile app  
capabilities of, 315-317

compatibility with mobile devices, 316  
installing

*on Android devices*, 319-320

*on iOS devices*, 318-319

third-party, 393-394

mounts, 18-19. *See also* accessories

attaching, 90-91

choosing, 87-89, 215-216

GoPro. *See* GoPro mounts

purpose of, 18

Quick Release Buckles, 274

securing camera to, 34, 382

stabilizers, 245

third-party. *See* third-party mounts

thumb screws, 87

wearing, 90

where to buy, 106-107

MP (megapixels), 7

Multi-Shot Settings (Settings menu), 337

## music

- adding to video, 254-255
- copyright issues, 343
- deleting from videos, 343

musical instrument mounts, 99

## N

Narrow FOV, 31

Night Lapse Photo shooting mode, 168, 212, 233

Night Photo shooting mode, 166

Night shooting mode, 211

night vision goggles, 99

noise, recording audio, 250

NO SD error message, 376

NVG Mount, 99

## O

Octomask dive mask accessory, 88, 19

Octomask mounts, 88, 105

online services. *See* GoPro Plus

online video tutorials, 395

on/off controls. *See* turning on/off

## opening

- battery door, HERO5 Black, 42
- side door
  - HERO5 Black*, 37-39
  - HERO5 Session*, 75
  - HERO Session*, 75

operating system. *See* Camera Software

organizing when editing video, 311

outro, editing, 348

overexposure, 381

overheated camera, 50, 226

## P

## pairing

- Capture mobile app with camera, 320-326
- Smart Remote
  - with HERO5 Black*, 112-114
  - with HERO5 Session*, 114-116
  - with HERO Session*, 114

Peak Design Ltd mounts, 105

people, as subject of photo, 205-206

perspective, 12

- planning video shots, 274-276
- switching when editing video, 275
- traditional, 94

## Photo camera mode

- camera model comparison, 181-182
- shooting modes for, 166-167

photo-editing software, 392

## photography

- equipment checklist, 23
- perspectives, 12
- skill and creativity in, 6

## photos

- capturing from video, 295-297
- editing, 221
  - apps for*, 394
  - converting time lapse photos/video*, 295
  - software for*, 392
- including in videos, 305
- RAW format, 175
- shooting
  - analyzing situation*, 149-150
  - animals*, 208
  - Burst shooting mode*, 211
  - camera model comparison*, 181-182
  - choosing subject*, 201-203
  - creative inspiration for*, 388
  - Default mode*, 192-194
  - fast-moving subjects*, 209
  - first- versus third-person perspective*, 203-205
  - FOV options*, 179-180
  - mounts, choosing*, 215-216
  - Night Lapse shooting mode*, 212
  - Night shooting mode*, 211
  - of people*, 205-206
  - in poor lighting*, 213-214, 220
  - preparation for*, 154-155, 200-201
  - primary light source*, 216-217
  - Protune feature*, 183-187
  - QuikCapture feature*, 192
  - remotely with Capture mobile app*, 338

- Rule of Thirds*, 217-218
- selfies*, 206-208
- shooting angle*, 219
- surroundings of photo*, 220
- Time Lapse shooting mode*, 212
- underwater photos*, 210-211
- viewfinder usage*, 214-215
- visually interesting objects*, 209-210
- WDR (Wide Dynamic Range)*, 212-213
- shooting mistakes
  - accidental deletions*, 384-385
  - dull colors*, 383
  - fish-eye effect*, 382-383
  - lack of memory card storage*, 384-385
  - mount out of position*, 382
  - overexposure*, 381
- viewing, 194-195
  - Burst shooting mode*, 197
  - on HERO5 Black touchscreen*, 195
- Photo Settings (Settings menu), 336
- Photo shooting mode, 166
  - subcategories, 45, 67
- physical damage to camera, trouble-shooting, 379-380
- pixels, 7
- planning shots
  - photo, 88-89
  - video, 265, 274-276, 310
- playback speed, adjusting in Splice mobile app, 351
- Player screen (QUIK Desktop software), 294
- PolarPro filters, 123
- PolarPro mounts, 105
- poor lighting conditions, 213-214, 220, 256
- Portable Power Pack, 140, 146
- port compartment door. *See* side door
- ports
  - accessing, 33, 39
  - USB-C, 74
- posed photos, 206
- positioning primary light source, 381
- PowerGrip H20 & 500 Lumen LED Light Combo, 260
- powering on/off. *See* turning on/off

- Power/Mode button
  - HERO5 Black, 36
  - troubleshooting, 35
- power sources, connecting to, 145-146
- preparing
  - checklist for, 154-155
  - shooting photos, 200-201
  - shooting video, 266-267
- previewing. *See* viewing
- primary light source, 216-217, 381
- Private Links (GoPro Plus), 354, 368-369
- Pro 3.5mm Mic Adapter, 74
- Pro Handlebar/Seatpost/Pole Mount, 99
- Pro Seat Rail Mount, 99
- protecting memory cards, 136
- Protune, 129, 173-174, 183-187
  - accessing menu, 170, 183-186
  - advanced settings, 187
  - battery life and, 183
  - resetting options, 186, 241
  - video options, 237-238
    - Audio*, 240
    - Color*, 188, 239
    - customizing*, 230-232
    - EV Comp*, 191, 240
    - ISO Limit*, 239-240
    - ISO Minimum/Maximum*, 188-189
    - Sharpness*, 190, 240
    - Shutter Speed*, 240
    - White Balance*, 187, 238-239
- video-shooting modes and, 228

## Q

- Qudos Action Video Light, 259
- Quick-Release Anti-Vibration Locking Plug, 91
- Quick Release Buckle, 84-86, 274
- QuikCapture feature, 48, 66, 192, 230
- QUIK Desktop software, 5, 22, 281
  - accessing content from GoPro Plus, 364-365
  - adding GPS details to scenes, 300-301
  - adding HiLight tags, 297-298
  - capturing still images from video, 295-297

- creating mini-videos in Create Mode, 298-300
- downloading, 56
- downloading user manual, 284
- importing content, 289-293
- installing, 286-288
- Player screen, 294
- syncing content, 364
- system requirements, 283
- trimming clips, 294
- updating Camera Software, 56-57, 298

Quik Key, 13, 119-120, 194, 340

QUIK mobile app, 5, 20-21, 225

- accessing content
  - from GoPro Plus*, 361-363
  - from social media accounts*, 363-364
- capabilities of, 316, 339
- compatibility with mobile devices, 317
- editing videos, 340, 343-346
- main screen, 340

## R

RAW Audio feature, 174, 234

RAW Audio Track option, 249

RAW Format feature, 175

raw video

- amount needed, 278
- backing up, 289
- transferring to GoPro Studio, 304-305

read speed of memory cards, 127

reattaching side door

- HERO5 Black, 40
- HERO5 Session, 76
- HERO Session, 76

recharging batteries, 139-141

recording audio, 248

- adding sound effects and music, 254-255
- audio-editing software, 248
- with built-in microphone, 249-250
- with external microphone, 251-253
- settings for, 249
- unwanted noise, 250

recovering memory card data, 377

Remo accessory, 51, 79, 118-119, 152

remote control. *See also* Capture mobile app; Smart Remote

- HERO5 Black, 50
- with voice commands, 152

Removable Instrument Mounts, 99

removing

- batteries from HERO5 Black, 144
- camera from Frame housing, 72
- fish-eye effect, 282
- memory cards from HERO5 Black, 132
- side door
  - HERO5 Black*, 40
  - HERO5 Session*, 76
  - HERO Session*, 76

Removu mounts, 105

repairing damaged camera, 379-380

Replacement Parts package, 91

replacing

- batteries, 372
- side door, 378
  - HERO5 Black*, 39
  - HERO5 Session*, 76
  - HERO Session*, 76

Reset option (Protune), 241

resetting

- camera, 35, 49, 373-375
- Protune options, 186

resolution, 7-9

- choosing for shooting video, 268-271
- defined, 151
- HERO5 Black camera, 15
- HERO5 Session camera, 15
- HERO Session camera, 13
- for Photo camera mode, 166
- video
  - memory cards for*, 126
  - specs for camera models*, 15
- in Video camera mode, 165
- YouTube-supported resolutions, 271

resources for information

- Facebook pages, 395
- GoPro support, 390-391
- online video tutorials, 395

- social media, 390
- tracking camera information, 391
- right-clicking, 292
- right side of camera
  - HERO5 Black, 36
  - HERO5 Session, 74
  - HERO Session, 74
- Rode website, 252
- rotation, Auto Rotation feature, 276
- royalty-free music, 254
- Rule of Thirds, 217-218

## S

---

- Sandmarc filters, 123
- Sandmarc mounts, 106
- saving
  - video-editing work, 289
  - video projects, 309
- Screensaver settings, 46-48
- SD ERR error message, 377
- securing mounts, 34, 382
- Seeker accessory, 121
- selecting. *See* choosing
- selfies, 206-208
- serial number, finding, 58
- settings. *See also* camera modes; shooting modes
  - advanced shooting features, 169-170
    - aspect ratio*, 170
    - auto low light*, 170
    - color*, 171
    - EV comp*, 172
    - exposure control with auto exposure*, 171
    - exposure control with locked exposure*, 172
    - GPS*, 172
    - ISO*, 172
    - manual audio control*, 173
    - Protune*, 173-174
    - RAW audio*, 174
    - RAW format*, 175
    - sharpness*, 175
    - video stabilization*, 175
    - WDR (wide dynamic range)*, 176
    - white balance*, 176
  - changing, 155
    - with Capture mobile app*, 335-338
    - with HERO5 Black touchscreen*, 156-159
    - with HERO5 Session status screen*, 159-162
    - with HERO Session status screen*, 159
  - hierarchical nature of, 150
  - icons, 162-163
- setup
  - HERO5 Black, 46-49
  - HERO5 Session, 77-78
  - HERO Session, 77-78
- Setup (Settings menu), 337
- shaking. *See also* stabilizers
  - avoiding, 264, 277
  - troubleshooting, 381
- sharing
  - content in GoPro Plus, 354, 368-369
  - video clips, 294
- Sharpness setting, 175, 190, 240
- shooting
  - advanced features. *See* advanced shooting features
  - analyzing situation, 149-150
  - creative inspiration for, 388
  - increasing battery life during, 146-147
  - photos. *See* photos
  - preparation checklist, 154-155
  - troubleshooting
    - accidental deletions*, 384-385
    - dull colors*, 383
    - fish-eye effect*, 382-383
    - lack of memory card storage*, 384-385
    - mount out of position*, 382
    - overexposure*, 381
    - poor audio quality*, 385-387
    - shaky video*, 381
  - video. *See* video
  - virtual reality content, 391
- shooting angle, 219

## shooting mode

- adjusting settings with Capture mobile app, 335-338

- Burst, 211

- changing, 155

- with HERO5 Black touchscreen, 156-159

- with HERO5 Session status screen, 159-162

- with HERO Session status screen, 159

- Default, setting, 229

- HERO5 Black, 45

- HERO5 Session, 67

- HERO Session, 67

- icons, 162-163

- Night, 211

- Night Lapse, 212

- for Photo camera mode, 166-167

- switching between, 191, 242

- with Capture mobile app, 334-335

- with Smart Remote, 243-244

- Time Lapse, 167-169, 212

- for video, 164-166, 224, 228

- Looping, 233

- Time Lapse Video, 233

- Video, 229-232

- Video+Photo, 232

- Shop By Activity page (GoPro website), 88

- shot list, creating, 395-396

- shots (photo)

- planning, 88-89

- stabilizing, 91-92

- with Karma Grip, 102

- with Sybrillo, 102, 106

- traditional perspective, 94

- shots (video)

- planning, 274-276

- tagging, 278

- Shutter button, 41, 70

- shutter speed, 166, 212, 240

- side door

- HERO5 Black

- accessing ports, 39

- buying replacement, 39

- opening/closing, 37-39

- removing/reattaching, 40

- HERO5 Session

- buying replacement, 76

- opening/closing, 75

- removing/reattaching, 76

- HERO Session

- buying replacement, 76

- opening/closing, 75

- removing/reattaching, 76

- replacing, 378

- Smart Remote, 110, 152-153

- adding HiLights, 236-237

- body of, 110

- Capture mobile app versus, 327-328

- charging, 111

- controlling camera, 117-118

- lack of connection, troubleshooting, 375

- pairing

- with HERO5 Black, 112-114

- with HERO5 Session, 114-116

- with HERO Session, 114

- switching shooting modes, 243-244

- turning on/off, 116

- Wireless mode, turning on/off, 117

- social media

- accessing content, 363-364

- GoPro on, 390

- sound. *See* audio

- sound effects, adding to video, 254-255

- special effects, overuse, 307

- special interest groups for GoPro information, 395

- speed of memory cards, 126-128

- Splice mobile app

- capabilities of, 317

- compatibility with mobile devices, 317-318

- editing videos, 346-351

- previewing video, 351

- Spot Meter feature, 182, 242, 256, 276

- stabilizers, 264, 277

- stabilizing shots, 91-92, 245

- with Karma Grip, 102

- with Sybrillo, 102, 106

## T

### status lights

- HERO5 Black, 35
- HERO5 Session, 68
- HERO Session, 68
- when charging battery, 141

### status screen

- HERO5 Black, 35, 42-43
- HERO5 Session, 70-71, 159-162
- HERO Session, 70-71, 159

### StaybICam Video Stabilizer, 264

### Steadicam Curve, 277

### still images. *See* photos

### storage capacity of memory cards, 128-129

### storyboards, creating, 285-286

### The Strap mount, 100

### subject (of photo)

- choosing, 201-203
- fast-moving, 209
- framing. *See* framing shots

### subscription fees, GoPro Plus, 354, 357

### Suction Cup mount, 99

### Supercharger, 63, 139

### Super Suit housing, 11, 18, 84

- fogged lens, troubleshooting, 376
- recording audio, 250

### SuperView FOV, 32, 226

### support, contacting, 390-391

### Surfboard Mounts, 100

### surroundings of photo, framing, 220

### switching

- camera modes with Capture mobile app, 334-335
- perspective when editing video, 275
- shooting modes, 191, 242
  - with *Capture mobile app*, 334-335
  - with *Smart Remote*, 243-244

### Sybrillo stabilizer, 102, 106

### syncing GoPro Plus and QUIK Desktop content, 364

### system requirements, GoPro QUIK Desktop and GoPro Studio software, 283

### tagging shots, 278

### televisions, resolution, 9

### Temperature icon, 378

### tethering, 71

### tethers, 92

### third-party mobile apps, 393-394

### third-party mounts, 88

- Caddie Buddy, 102
- GoPole, 103
- GoWorx, 103
- Insignia, 103
- Joby, 104
- Octomask, 105
- Peak Design Ltd, 105
- PolarPro, 105
- Removu, 105
- Sandmarc, 106
- Sybrillo stabilizer, 102, 106
- Tiffen, 106

### third-person perspective, 12

- first-person perspective versus, 203-205

### thumbnail icons, content type in, 291

### thumb screws, 85-87

### Tiffen mounts, 106

### Tiffen Steadicam Curve, 277

### Time Lapse camera mode

- QuikCapture feature, 192
- shooting modes for, 167-169

### time lapse photos, converting to videos, 295

### Time Lapse Photo shooting mode, 168

- comparison with Time Lapse Video and Night Lapse Photo, 233

### Time Lapse shooting mode, 212

- subcategories, 45, 67

### time lapse videos, converting to photos, 295

### Time Lapse Video shooting mode, 168, 233

- comparison with Time Lapse Photo and Night Lapse Photo, 233

### titles in videos, 312

toggling. *See* switching

top of camera

HERO5 Black, 41

HERO5 Session, 70-71

HERO Session, 70-71

touchscreen

changing camera settings, 156-159

HERO5 Black, 35

*interacting with*, 45

*options*, 43-44

*Screensaver mode*, 46

unresponsive, troubleshooting, 375

viewing photos, 195

tracking camera information, 391

traditional perspective, 94

transferring

digital content with Quik Key, 119-120

memory card content to mobile device,  
330-332

video content to GoPro Studio, 304-305

trimming video clips, 305

Tripod Mounts, 100

tripods, 88

troubleshooting

batteries, not holding charge, 140

camera-related problems

*choppy video playback*, 378

*computer doesn't recognize camera*,  
379

*dead battery*, 372

*fogged lens*, 376

*lack of connection with Capture app  
or Smart Remote*, 375

*memory card error messages*,  
136-137, 376-377

*menus differ from book*, 379

*overheated camera*, 50, 226

*physical damage to camera*, 379-380

*Temperature icon*, 378

*unresponsive camera*, 373-375

*unresponsive touchscreen*, 375

*water spots on lens*, 378

low battery warning, 146

pairing process, 321, 326

Power/Mode button, 35

resetting camera, 35

shooting mistakes

*accidental deletions*, 384-385

*dull colors*, 383

*fish-eye effect*, 382-383

*lack of memory card storage*, 384-385

*mount out of position*, 382

*overexposure*, 381

*poor audio quality*, 385-387

*shaky video*, 381

voice commands, 152

turning on/off

GPS feature, 224

HERO5 Black, 33

HERO5 Session, 66

HERO Session, 66

QuikCapture feature, 192

REMO accessory, 119

Smart Remote, 116

voice control, 51, 79

Wireless mode, 117, 375

tutorial videos, 395

## U

underwater photos, 210-211

external lighting for, 258

lenses for, 123

unresponsive camera, troubleshooting,  
373-375

unresponsive touchscreen, trouble-  
shooting, 375

updating

Camera Software, 53, 80, 298

*with Capture mobile app*, 53-56

*manually*, 58

*with QUIK Desktop software*, 56-57

Google Play Services, 320

upgrades, 14

uploading digital content

Auto Upload feature, 357-360

to GoPro Studio, 304-305

from HERO/HERO5 Session, 360

upside down, shooting video, 276

USB-C port, 74, 145-146

user manuals, downloading, 284

# V

Vented Helmet Strap Mount, 101

## video

aspect ratio, 170

editing. *See also* QUIK Desktop

software; GoPro Studio software

*adding GPS details to scenes, 300-301*

*adding HiLight tags, 297-298*

*apps for, 394*

*capturing still images, 295-297*

*converting time lapse photos/video, 295*

*creating mini-videos in Create Mode, 298-300*

*creating storyboards, 285-286*

*importing content, 289-293*

*including still photos in, 305*

*learning curve for, 313*

*organizing work, 311*

*overuse of special effects, 307*

*planning while shooting, 310*

*with QUIK mobile app, 340, 343-346*

*raw footage needed, 278*

*removing fish-eye effect, 282*

*role of video editor, 283-284*

*saving work, 289*

*as skill and art form, 282*

*software for, 392*

*with Splice mobile app, 346-351*

*steps in, 284-285*

*switching perspectives, 275*

*tips for, 309-313*

*titles and captions, 312*

*trimming clips, 294, 305*

exporting projects, 309

FOV (field of view), 8

FPS (frames per second), 8

HD video, 7-9

HERO Session specs, 13

links, copying, 345

music, 343

recording audio, 248

*adding sound effects and music, 254-255*

*audio-editing software, 248*

*with built-in microphone, 249-250*

*with external microphone, 251-253*

*settings for, 249*

*unwanted noise, 250*

## resolution

*memory cards for, 126*

*specs for camera models, 15*

saving projects, 309

sharing clips, 294

shooting, 224-225

*advanced features, 234*

*analyzing situation, 149-150*

*camera model comparison, 225-228*

*Capture mobile app settings, 241-242*

*creating shot list, 395-396*

*creative inspiration for, 388*

*equipment checklist, 23*

*FOV options, choosing, 272-273*

*FPS rate, choosing, 271*

*goals of, 225*

*GPS feature, 224*

*HiLight tagging feature, 234-237*

*importance of smooth, steady motion, 264, 277*

*lighting, 276-277*

*overheated camera, 226*

*perspectives, 12*

*planning, 265*

*planning shots, 274-276*

*planning video, 265*

*preparation checklist, 154-155*

*preparing, 266-267*

*Protune feature, 237-238*

*raw footage, 278*

*resolution, choosing, 268-271*

*skill and creativity in, 6*

*stabilizers, 264*

*stabilizing camera, 245*

*tagging shots, 278*

*upside down, 276*

## shooting mistakes

*accidental deletions, 384-385*

*dull colors, 383*

*fish-eye effect, 382-383*

*lack of memory card storage, 384-385*

*mount out of position, 382*

- overexposure*, 381
  - poor audio quality*, 385-387
  - shakiness*, 381
- shooting modes, 224, 228
  - Looping*, 233
  - switching between*, 242-244
  - Time Lapse Video*, 233
  - Video*, 229-232
  - Video+Photo*, 232
- transferring content to GoPro Studio, 304-305
- viewing
  - choppy playback, troubleshooting*, 378
  - in Splice mobile app*, 351
- Video camera mode, shooting modes for, 164-166
- video-editing software, 392
- Video Format settings, 49
- Video+Photo shooting mode, 164, 232
- Video Settings (Settings menu), 336
- Video shooting mode, 164, 229-232
  - subcategories, 45, 67
- video stabilization, 18, 175, 234
- video tutorials, 395
- Viewfinder screen (Capture mobile app), 333-338
- viewfinder usage, 214-215
- viewing
  - battery status, 47
  - digital content
    - HERO5 Session*, 79-80
    - HERO Session*, 79-80
  - photos, 194-195
    - Burst shooting mode*, 197
    - on HERO5 Black touchscreen*, 195
  - status screen info, HERO5 Black, 43
  - video
    - adding HiLights*, 235-236
    - choppy playback, troubleshooting*, 378
    - in Splice mobile app*, 351
- virtual reality (VR) content, 58, 391
- visually interesting objects, as subject, 209-210

- voice commands, 4, 152
  - HERO5 Black, 51-52
  - HERO5 Session, 78-79
  - for HiLight tagging feature, 235
  - REMO accessory, 118-119

## W-Z

- warranty, extending, 379
- Wasabi Power, 142
- waterproof housings, 11, 18, 84
- waterproofing
  - HERO5 Session, 77
  - HERO Session, 77
- water spots on lens, troubleshooting, 378
- WavePad Audio Editing Software, 248
- WDR (Wide Dynamic Range), 176, 212-213
- wearing mounts, 90
- web browsers, accessing content from
  - GoPro Plus, 365-369
- websites
  - advanced Protune settings, 187
  - GoPro, 88, 106
  - memory card recommendations, 126
  - Rode (recording audio), 252
  - Wasabi Power, 142
  - YouTube copyright issues, 254
- White Balance setting, 176, 187, 238-239
- Wide FOV, 32
- wind noise filters, 173, 386-387
- windscreens, 250
- wireless connections, pairing. *See* pairing
- Wireless icon (Capture mobile app), 329
- Wireless mode, turning on/off, 117, 375
- write speed of memory cards, 126-127
- WVGA resolution, 269
- YouTube
  - copyright issues, 254
  - resolutions supported, 271